Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONN Lytio-2280

ONN AM/FM Digital Alarm Clock Radio

Model: Lytio-2280
Brand: ONN

Introduction

This manual provides comprehensive instructions for the ONN AM/FM Digital Alarm Clock Radio, Model Lytio-2280. It covers essential information regarding setup, daily operation, maintenance, and troubleshooting to ensure you get the most out of your device. Please read this manual thoroughly before using the product.

Product Overview

The ONN AM/FM Digital Alarm Clock Radio features a large LED display, dual alarms, snooze and sleep functions, and an integrated AM/FM radio with station presets. It can be powered by an AC adapter or batteries for portability.



Figure 1: Front view of the ONN AM/FM Digital Alarm Clock Radio. This image displays the large red LED time display and the array of control buttons located on the top panel, including power, radio, tune, snooze, dimmer, memory/preset, and volume controls.



Figure 2: Angled view of the ONN AM/FM Digital Alarm Clock Radio. This perspective highlights the large red LED display showing the time, along with the alarm indicator lights (Alarm 1 and Alarm 2) and PM indicator located on the left side of the display.

Setup

Powering the Device

The alarm clock radio can be powered in two ways:

1. **AC Power:** Connect the provided AC adapter to the DC IN jack on the back of the unit and plug the other end into a standard wall outlet.
2. **Battery Power (for backup):** For temporary power or during power outages, insert 2 x AAA batteries (not included) into the battery compartment on the bottom of the unit. Ensure correct polarity (+/-). Battery power primarily maintains time and alarm settings during power interruptions; the display may not illuminate fully on battery power alone.

Setting the Current Time

After connecting power, the display will flash. Follow these steps to set the correct time:

1. Press and hold the **TIME SET** button (usually located on the top panel). The hour digits will begin to flash.
2. Press the **HOUR** button repeatedly to adjust the hour. Pay attention to the PM indicator light if setting a PM time.
3. Press the **MINUTE** button repeatedly to adjust the minute.
4. Press the **TIME SET** button again to confirm and exit time setting mode.

Operating Instructions

Setting Alarms (Alarm 1 and Alarm 2)

This clock radio features dual alarms. You can set two independent alarm times.

1. Press and hold the **ALARM 1 SET** button. The Alarm 1 hour digits will flash.

2. Use the **HOUR** and **MINUTE** buttons to set the desired alarm time for Alarm 1.
3. Press **ALARM 1 SET** again to confirm.
4. To activate Alarm 1, press the **ALARM 1 ON/OFF** button until the Alarm 1 indicator light illuminates.
5. Repeat steps for **ALARM 2 SET** and **ALARM 2 ON/OFF** for the second alarm.

Using the AM/FM Radio

To listen to the radio:

1. Press the **RADIO ON/OFF** button to turn on the radio.
2. Press the **AM/FM** button to switch between AM and FM bands.
3. Use the **TUNE +** or **TUNE -** buttons to manually tune to a desired station. Press and hold to auto-scan for the next available station.
4. Adjust the volume using the **VOL +** or **VOL -** buttons.

Setting Radio Presets

You can store your favorite radio stations for quick access:

1. Tune to the desired station.
2. Press the **MEM/PRESET** button once. The preset number will flash.
3. Use the **TUNE +** or **TUNE -** buttons to select the desired preset number (e.g., P01, P02).
4. Press **MEM/PRESET** again to save the station to that preset.
5. To recall a preset station, press the **MEM/PRESET** button repeatedly to cycle through your saved stations.

Snooze and Sleep Functions

- **Snooze:** When the alarm sounds, press the **SNOOZE** button to temporarily silence the alarm for approximately 9 minutes. The alarm will sound again after the snooze period.
- **Sleep:** To fall asleep to the radio, press the **SLEEP** button. Each press will cycle through preset sleep times (e.g., 90, 60, 30, 15 minutes, OFF). The radio will automatically turn off after the selected duration.

Display Dimmer

To adjust the brightness of the LED display:

- Press the **DIMMER** button (if available) or the **SNOOZE** button (on some models) while the radio is off to cycle through different brightness levels (e.g., High, Medium, Low, Off).

Maintenance

To ensure the longevity and proper functioning of your ONN AM/FM Digital Alarm Clock Radio, follow these maintenance guidelines:

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.
- **Placement:** Place the unit on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation.
- **Battery Replacement:** If using batteries for backup, replace them annually or when the display shows signs of dimming during power outages. Dispose of old batteries responsibly.

Troubleshooting

If you encounter issues with your alarm clock radio, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No power / Display is off	Ensure the AC adapter is securely plugged into both the unit and a working wall outlet. Check if the power outlet is functional. If using battery backup, ensure batteries are inserted correctly and are not depleted. Note that the display may not fully illuminate on battery power alone.
Alarm does not sound	Verify that the alarm is set and activated (alarm indicator light is on). Check the alarm volume level. Ensure the alarm time is set correctly (AM/PM).
Poor radio reception	Extend the FM wire antenna fully for better FM reception. Rotate the unit for better AM reception (the AM antenna is internal). Move the unit away from other electronic devices that may cause interference.
Time/Alarm settings reset after power loss	Ensure backup batteries are installed and are not depleted. Replace old backup batteries with new ones.

Specifications

Brand	ONN
Model Number	Lytio-2280
Colour	Black
Product Dimensions	9.14 x 9.14 x 20.57 cm
Item Weight	410 g
Display Type	Digital LED (Red)
Power Source	AC Adapter (main), Battery (backup)
Special Features	Dual Alarms, Snooze, Sleep Timer, AM/FM Radio, Dimmable Display

Warranty and Support

For information regarding product warranty, technical support, or service, please refer to the original product packaging or contact the retailer from whom the product was purchased. Keep your purchase receipt as proof of purchase.

© 2024 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NHFH4YF

More documents and user manuals: **https://manuals.plus/**