Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KECHAODA A27

KECHAODA A27 Mini Mobile Phone User Manual

Model: A27

Introduction

This manual provides essential instructions for setting up, operating, and maintaining your KECHAODA A27 Mini Mobile Phone. Please read this manual carefully before using your device to ensure proper functionality and longevity.

Package Contents

Verify that all items are present in the box:

- KECHAODA A27 Mini Mobile Phone
- USB Charging Cable
- Battery
- User Manual (this document)

Note: A charger adapter is not included in the box. Please use a compatible Micro USB charger.

Device Overview



Front view of the KECHAODA A27 Mini Mobile Phone, showing the keypad and small display.



Back view of the KECHAODA A27 Mini Mobile Phone, featuring the KECHAODA logo and speaker grille.



Side view of the KECHAODA A27 Mini Mobile Phone, showing the slim profile and side buttons.



Top/bottom view of the KECHAODA A27 Mini Mobile Phone, highlighting the Micro USB port.

Setup

1. Installing the Battery

1. Gently remove the back cover of the phone.
2. Align the battery contacts with the phone's terminals.
3. Insert the battery into its compartment.
4. Replace the back cover until it clicks into place.

2. Inserting SIM Cards

The KECHAODA A27 supports Dual SIM functionality.

1. With the back cover and battery removed, locate the SIM card slots.
2. Insert your SIM cards into the designated slots, ensuring the gold contacts face downwards.
3. Reinstall the battery and back cover.

3. Inserting an External Memory Card

The phone supports an external memory card for additional storage.

1. With the back cover and battery removed, locate the external memory card slot.
2. Insert the memory card into the slot until it is securely in place.
3. Reinstall the battery and back cover.

4. Charging the Phone

Before first use, fully charge the phone's battery.

1. Connect the Micro USB charging cable to the phone's charging port.
2. Connect the other end of the USB cable to a compatible USB charger adapter (not included) or a computer's USB port.
3. The charging indicator on the phone will show the charging status.
4. It is recommended to charge the mobile for approximately half an hour and then remove it from charging.

Operating Instructions

1. Power On/Off

- To power on, press and hold the Power/End Call button until the screen lights up.
- To power off, press and hold the Power/End Call button, then select "Power off" from the options.

2. Making Calls

1. From the home screen, dial the desired phone number using the keypad.
2. Press the Call button (usually green) to initiate the call.
3. To end a call, press the Power/End Call button (usually red).

3. Sending Messages

1. Navigate to the "Messages" menu.
2. Select "Create new message" or "New SMS".
3. Enter the recipient's number and type your message using the keypad.
4. Press "Send".

4. Using the Camera

The phone features a VGA rear camera.

1. Access the "Camera" application from the main menu.
2. Frame your shot using the display.
3. Press the designated button (often the center navigation key) to capture a photo.

5. Bluetooth Connectivity

The KECHAODA A27 supports Bluetooth for wireless connections.

1. Go to "Settings" and then "Bluetooth".
2. Turn Bluetooth on.
3. Search for available devices and pair with your desired device.

6. MP3 Player

You can play MP3 audio files stored on your external memory card.

1. Ensure an external memory card with MP3 files is inserted.
2. Navigate to the "MP3 Player" or "Music" application.
3. Select and play your desired audio files.

Maintenance and Care

- Keep the phone dry. Moisture can damage electronic circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and warp plastic parts.
- Do not drop, knock, or shake the phone. Rough handling can break internal circuit boards.
- Clean the phone with a soft, dry cloth. Do not use harsh chemicals or cleaning solvents.
- Handle the battery with care. Do not puncture, incinerate, or disassemble the battery.

Troubleshooting

Problem	Possible Solution
Phone does not power on.	Ensure the battery is correctly installed and charged. Connect the charger and try again.
Cannot make or receive calls.	Check if SIM cards are properly inserted. Verify network signal strength. Contact your service provider if issues persist.
Battery drains quickly.	Reduce screen brightness. Close unused applications. Limit background processes. If the battery is old, consider replacing it.
Bluetooth not connecting.	Ensure Bluetooth is enabled on both devices. Make sure devices are within range. Try restarting both devices.

Specifications

Brand	KECHAODA
Model	A27
Operating System	Symbian 9.3
CPU Model	Cortex A7
Memory Storage Capacity	16 GB
Screen Size	0.66 Inches
Colour	Black
SIM Card Slot Count	Dual SIM
Connector Type	Micro USB

Form Factor	Bar
Human Interface Types	Keypad
Headphones Jack	3.5 mm
Product Features	Bluetooth, Dual SIM, MP3, USB
Material	Plastic
Camera Description	VGA rear camera
Battery Description	Lithium-Ion
Battery Power	300 mAh
Item Weight	100 Grams
Item Dimensions	7 x 3 x 1.5 Centimeters
Cellular Technology	2G
Wireless Provider	Unlocked for All Carriers
Model Year	2019

Product Overview Video

Your browser does not support the video tag.

Official product overview video for the KECHAODA A27 Mini Mobile Phone, demonstrating its features and design.

Warranty and Support

The KECHAODA A27 Mini Mobile Phone comes with a**1 Year Manufacturer Warranty**.
For warranty claims or technical support, please contact the manufacturer:

- **Manufacturer:** Dharam & Company, SNENZHEN KECHAODA TECHOLOGY CO LTD
- **Contact Information:** Dharam & Company

Please retain your proof of purchase for warranty purposes.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NL9GTC9

More documents and user manuals: **https://manuals.plus/**