Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro JAMO-HCS-4000

Passion-Electro Replacement Remote Control for JAMO-HCS-4000 User Manual

Model: JAMO-HCS-4000

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Passion-Electro replacement remote control for the JAMO-HCS-4000 home cinema system. This remote is designed to replicate all functions of your original JAMO-HCS-4000 remote control without requiring any programming.
Please read this manual carefully before using the remote control to ensure proper functionality and to maximize your user experience.

2. Package Contents

- 1 x Passion-Electro Replacement Remote Control for JAMO-HCS-4000

Note: Batteries are not included and must be purchased separately.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V batteries (LR03) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back view of the remote control with the battery compartment.



Figure 2: Close-up of the battery compartment, ready for battery insertion.

Once batteries are installed, the remote control is ready for use. No additional programming is required.

4. Operating Instructions

This replacement remote control is designed to function identically to your original JAMO-HCS-4000 remote. Simply point the remote control towards your JAMO-HCS-4000 system and press the desired buttons.



Figure 3: Front view of the remote control, displaying all buttons.

4.1 Key Functions Overview

The remote features standard buttons for controlling your JAMO-HCS-4000 system. While the exact layout may vary slightly from the original, the functionality of each button is maintained.

- **Power Button:** Turns the system on or off.
- **Numeric Keypad:** For direct channel input or menu navigation.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes channels or navigates through lists.
- **Mute Button:** Silences the audio output.
- **Navigation Buttons (Arrow Keys, OK):** For menu navigation and selection.
- **Source/Input Button:** Selects different input sources (e.g., TV, DVD, AUX).
- **Menu Button:** Accesses the system's main menu.
- **Playback Controls:** Play, Pause, Stop, Fast Forward, Rewind (if applicable to your system).



Figure 4: Angled view of the remote control, highlighting the button arrangement.

5. Maintenance

5.1 Cleaning

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-

abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V). Remove batteries if the remote will not be used for an extended period to prevent leakage.

6. Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the JAMO-HCS-4000 system's infrared receiver.
  - Check if the batteries are correctly inserted with the correct polarity (+/-).
  - Replace old batteries with new AAA 1.5V batteries.
  - Ensure there are no obstructions between the remote and the system.
- **Intermittent response:**
  - Batteries may be low. Replace them.
  - Clean the remote's infrared emitter and the system's receiver window.
- **Specific button not working:**
  - This remote is designed to replicate all original functions. If a specific button does not work, ensure your JAMO-HCS-4000 system supports that function with its original remote.
  - If the issue persists, contact customer support.

7. Specifications

Model	JAMO-HCS-4000 Replacement Remote
Brand	Passion-Electro
Color	Black
Power Source	2 x AAA 1.5V Batteries (LR03)
Compatibility	JAMO-HCS-4000 Home Cinema System
Programming Required	No
Country of Origin	China

8. Warranty and Support

For any questions, issues, or support regarding your Passion-Electro replacement remote control, please contact the seller or manufacturer directly. Please refer to your purchase documentation for specific warranty details.
Note: This manual is for informational purposes only. Product specifications and appearance are subject to change without notice.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NNG6KZC

More documents and user manuals: **https://manuals.plus/**