Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro 32DTH401

Replacement Remote Control for TELEFUNKEN 32DTH401

Brand: Passion-Electro | **Model:** 32DTH401

1. Introduction

This manual provides instructions for the Passion-Electro Replacement Remote Control, specifically designed for the TELEFUNKEN 32DTH401 television model. This remote is a specialized replacement, not a generic universal remote, ensuring full compatibility and access to all functions of your original remote control.

Key Features:

- Access to all original remote control functions.
- No programming required; ready to use out of the box.
- Equipped with an LED indicator for operational feedback.
- High-quality construction for reliable performance.



Figure 1.1: Front view of the replacement remote control, showing its button layout.

2. Setup

The Passion-Electro Replacement Remote Control requires no complex setup or programming. Simply install the batteries, and it will be ready for immediate use with your TELEFUNKEN 32DTH401 TV.

2.1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA (LR03) 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. **Note: Batteries are not supplied with the remote control.**
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 2.1: Back view of the remote control, highlighting the battery compartment.

3. Operating Instructions

Once batteries are installed, the remote control is ready to operate your TELEFUNKEN 32DTH401 TV. Point the remote directly at the TV's infrared receiver for optimal performance.

3.1. Basic Functions

- **Power Button:** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Volume Up/Down (V+/V-):** Adjusts the sound volume.
- **Channel Up/Down (P+/P-):** Changes the TV channel.
- **Mute:** Silences the TV audio.
- **Source/Input:** Cycles through available input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Menu:** Opens the TV's main menu.
- **Exit/Back:** Closes menus or returns to the previous screen.



Figure 3.1: Angled view of the remote, illustrating various function buttons.



Figure 3.2: Different angled view of the remote, showing additional button details.

4. Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your remote control.

4.1. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild,

non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

4.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA 1.5V). Do not mix old and new batteries, or different types of batteries.

4.3. Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common troubleshooting steps:

- **Remote not responding:**
  - Ensure there is a clear line of sight between the remote control and the TV's infrared receiver.
  - Check if the batteries are inserted correctly, observing the positive (+) and negative (-) polarities.
  - Replace the batteries with fresh ones. Weak batteries are a common cause of remote control issues.
- **Specific buttons not working:**
  - Ensure the remote is clean and there is no debris obstructing the buttons.
  - If only certain buttons are unresponsive after checking batteries, the remote may require replacement.

If the problem persists after trying these steps, please contact the seller for further assistance.

6. Specifications

Attribute	Detail
Brand	Passion-Electro
Color	Black
Battery Type	2 x AAA (LR03) 1.5V (not included)
Manufacturer	Passion-Electro
Country of Origin	China
ASIN	B07NNGP5KB

Date First Available on Amazon.com.be	March 22, 2019

7. Warranty and Support

For information regarding warranty coverage or technical support for your Passion-Electro Replacement Remote Control, please refer to the seller or your point of purchase. Specific warranty details and support contacts are not provided in this manual.
Please retain your proof of purchase for any warranty claims.

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NNGP5KB

More documents and user manuals: **https://manuals.plus/**