Handy Gourmet JB8228BGE

Handy Gourmet Eco Friendly Microwave Pressure Cooker

Model: JB8228BGE

User Instruction Manual

Product Overview

The Handy Gourmet Eco Friendly Microwave Pressure Cooker is designed for quick and easy meal preparation in your microwave. Made with 40% less plastic than standard microwave cookware, it features a natural wheat fiber look and textured feel, promoting an environmentally conscious cooking experience.

This versatile cooker can be used for various cooking needs, including preparing rice, chicken, pasta, and vegetables.



Image: The Handy Gourmet Eco Friendly Microwave Pressure Cooker, showcasing its beige, textured finish and eco-friendly packaging.

What's Included

Your Handy Gourmet Eco Friendly Microwave Pressure Cooker package includes:

- Microwave Pressure Cooker Pot with Lid
- Measuring Cup
- Spatula
- Recipes Booklet



Image: All components of the microwave pressure cooker, including the main pot, lid, measuring cup, and spatula.

Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging.
2. **Wash:** Before first use, wash the pressure cooker pot, lid, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry.
3. **Inspect:** Ensure all parts are free from damage. Do not use if any part is cracked or broken.

Operating Instructions

This microwave pressure cooker simplifies meal preparation. Follow these general steps for cooking:

1. **Add Ingredients:** Place your desired ingredients into the pressure cooker pot. Refer to the included recipe booklet for specific ingredient quantities and preparation.
2. **Seal the Lid:** Place the lid securely on the pot and engage the side clips to seal it.
3. **Adjust Steam Vent:** Rotate the knob on the lid to open or close the steam vent as required by your recipe. For pressure cooking, the vent should typically be closed.
4. **Microwave:** Place the sealed pressure cooker into your microwave. Cook according to your recipe's instructions, noting that cooking times may vary based on microwave wattage and food type.
5. **Release Pressure:** After cooking, allow the cooker to stand for a few minutes to naturally release pressure. Carefully open the steam vent if it was closed, then unclip the lid.
6. **Serve:** Your meal is ready to serve.

For detailed recipes and cooking times, consult the included recipe booklet.

Your browser does not support the video tag.

Video: Official product demonstration of the Handy Gourmet Eco Friendly Microwave Pressure Cooker, showing how to add ingredients, seal the lid, adjust the steam vent, and microwave for cooking.

Maintenance and Care

- **Cleaning:** The microwave pressure cooker is dishwasher safe. For best results, wash immediately after use to prevent food from drying onto surfaces.
- **Storage:** Store the cooker in a dry place when not in use.
- **Avoid Abrasives:** Do not use abrasive cleaners or scouring pads, as these can damage the surface of the cooker.

Troubleshooting

Problem	Possible Cause	Solution
Food not cooking evenly	Incorrect cooking time or power level; uneven distribution of ingredients.	Adjust microwave cooking time or power. Stir ingredients halfway through cooking if possible. Ensure ingredients are cut into similar sizes.
Water/liquid leaking in microwave	Lid not properly sealed; overfilling the cooker; steam vent not correctly positioned.	Ensure the lid is securely clipped and the steam vent is in the correct position for pressure cooking. Do not exceed the maximum fill line. Reduce liquid if necessary.

Problem	Possible Cause	Solution
Lid difficult to open or close	Food residue on rim; lid or pot warped.	Clean the rim of the pot and lid thoroughly. If the lid or pot appears warped, discontinue use.

Specifications

- **Brand:** Handy Gourmet
- **Model Number:** JB8228BGE
- **Capacity:** 2 Liters
- **Material:** Plastic, Natural Wheat Fiber
- **Color:** Beige
- **Finish Type:** Textured
- **Product Dimensions:** 2.36"D x 7.48"W x 2.59"H
- **Special Feature:** Manual Operation
- **Control Method:** Touch
- **Operation Mode:** Manual
- **Dishwasher Safe:** Yes
- **Voltage:** 120 Volts (for microwave compatibility)
- **Item Weight:** 10.2 ounces
- **Manufacturer:** Jobar International, Inc.

Warranty and Support

For warranty information or product support, please contact Jobar International, Inc., the manufacturer. Refer to the product packaging or their official website for contact details.

© 2026 Handy Gourmet. All rights reserved.