Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2019032502

YING RAY Replacement Remote Control Instruction Manual

For Daikin Air Conditioners (Models BRC4C153, BRC4C154, BRC4C156, BRC4C157, BRC4C159, BRC4C160, BRC4C161)

1. Introduction

This manual provides instructions for the YING RAY replacement remote control, designed for use with various Daikin air conditioner models. This remote offers essential functions for controlling your air conditioning unit, ensuring comfortable indoor climate management. It is compatible with Daikin models BRC4C153, BRC4C154, BRC4C156, BRC4C157, BRC4C159, BRC4C160, and BRC4C161.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the cover back into place until it clicks securely.

2.2 Initial Use

This replacement remote control is pre-programmed for compatible Daikin air conditioner models. No additional pairing or setup is typically required after battery installation. Point the remote towards your air conditioner unit and press the **ON/OFF** button to test functionality.

3. Operating Instructions

Familiarize yourself with the remote control's buttons and display for optimal use.



Figure 1: Front view of the remote control with the protective cover closed.

3.1 Basic Functions

- **ON/OFF Button:** Press to turn the air conditioner unit on or off.
- **UP (▲) Button:** Increases the temperature setting or adjusts other parameters upwards.

- **DOWN (▼) Button:** Decreases the temperature setting or adjusts other parameters downwards.
- **FAN Button:** Cycles through fan speed settings (e.g., Auto, Low, Medium, High).



Figure 2: Front view of the remote control with the protective cover open, showing advanced controls.

3.2 Advanced Functions (Under Cover)

- **TEMP TIME Button:** Used for setting or viewing temperature-related timers.
- **RESERVE CANCEL Button:** Used to cancel a reserved or programmed operation.
- **TIMER Button:** Activates or adjusts the timer functions for scheduled operation.
- **MODE Button:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SWING Button:** Controls the louver swing function for air distribution.
- **TEST Button:** Used for diagnostic purposes or initial setup by service personnel. Avoid pressing during normal operation unless instructed.
- **Light/Display Button (Eye icon):** Toggles the display backlight or an indicator light.

The remote control displays temperature in Celsius.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's display becomes dim or its range decreases. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these can damage the remote's surface or internal components.

5. Troubleshooting

5.1 Common Issues

- **Remote not responding:**
  - Check battery orientation and ensure they are fresh.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Verify the remote is within the operating range (up to 10 meters).
- **Air conditioner not responding to commands:**
  - Confirm the air conditioner unit is powered on.
  - Ensure the remote is pointed directly at the air conditioner's infrared receiver.

5.2 Buzzer Indications

The remote control may provide audible feedback through a buzzer. Refer to the following indications:

- **2 Short Beeps:** Indicates normal receiving of a command by the air conditioner.
- **1 Long Beep:** Indicates that the operation mode is unchangeable at the current time.
- **3 Short Beeps:** Indicates the unit is under centralized control, meaning some functions may be overridden by a central system.

6. Specifications

Brand	YING RAY

Model Number	2019032502
Compatible Devices	Daikin Air Conditioners (BRC4C153, BRC4C154, BRC4C156, BRC4C157, BRC4C159, BRC4C160, BRC4C161)
Connectivity Technology	Infrared
Maximum Range	10 Meters
Controller Type	Button Control
Power Source	2 x AAA Batteries (not included)
Display Unit	Celsius

7. Warranty and Support

For any issues or inquiries regarding your YING RAY replacement remote control, please contact the seller or manufacturer directly through your purchase platform. Keep your purchase receipt as proof of purchase for any potential warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NQ9D47V

More documents and user manuals: **https://manuals.plus/**