Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Stihl DYNAMIC BT-PC

STIHL DYNAMIC BT-PC Ear Protection Bar with Bluetooth and Polycarbonate Visor User Manual

Model: DYNAMIC BT-PC

Introduction

This manual provides essential instructions for the safe and effective use of your STIHL DYNAMIC BT-PC Ear Protection Bar with Bluetooth and Polycarbonate Visor. Please read this manual thoroughly before initial use and retain it for future reference.

The STIHL DYNAMIC BT-PC is designed to provide hearing protection in noisy environments while allowing for wireless audio streaming via Bluetooth 4.0. It also features an integrated polycarbonate visor for facial protection.



Image: The STIHL DYNAMIC BT-PC Ear Protection Bar, featuring orange earmuffs, a black headband, and a clear polycarbonate visor attached to the front.

Safety Information

- Always inspect the ear protection and visor for damage before each use. Do not use if damaged.
- Ensure the earmuffs fit snugly over your ears to provide effective hearing protection.
- The polycarbonate visor provides protection against light impacts and splashes. It is not a substitute for safety glasses or a full face shield in high-impact situations.
- Clean the visor regularly to maintain clear visibility.
- Do not modify the device. Use only genuine STIHL replacement parts.
- Keep the device away from extreme temperatures and moisture.

Components Overview

The STIHL DYNAMIC BT-PC consists of the following main components:

- **Adjustable Headband:** For comfortable and secure fit.
- **Earmuffs:** Provide hearing protection and house the Bluetooth audio components.
- **Polycarbonate Visor:** Attaches to the headband for facial protection.
- **Control Buttons:** Located on the earmuffs for power, volume, and Bluetooth functions.
- **AUX Input:** For connecting non-Bluetooth devices.

- **Charging Port:** For recharging the internal battery.

Setup

1. Initial Charging

Before first use, fully charge the device. Connect the provided charging cable to the charging port on the earmuff and to a suitable USB power source. The charging indicator light will show the charging status. A full charge provides approximately 38 hours of battery life.

2. Adjusting the Headband and Visor

1. Place the ear protection bar on your head.
2. Adjust the headband slides on both sides until the earmuffs comfortably cover your ears and the headband rests securely on your head.
3. Ensure the polycarbonate visor is positioned correctly to protect your face without obstructing your vision. The visor can be flipped up when not needed.

Operating Instructions

1. Power On/Off

- To power on: Press and hold the power button until the indicator light illuminates.
- To power off: Press and hold the power button until the indicator light turns off.

2. Bluetooth Pairing

1. Ensure the device is powered on.
2. Activate Bluetooth on your smartphone or audio device.
3. Search for available Bluetooth devices. The STIHL DYNAMIC BT-PC will appear as "STIHL BT" or similar.
4. Select "STIHL BT" to pair. A confirmation tone will sound upon successful pairing.
5. The device uses Bluetooth 4.0 for stable wireless connection.

3. Audio Playback and Volume Control

- Once paired, you can stream audio from your connected device.
- Use the volume buttons on the earmuff to adjust the audio level.
- Playback controls (play/pause, skip track) may also be available depending on the device and connected application.

4. Using the AUX Input

For devices without Bluetooth, connect an audio cable (not included) from your device's headphone jack to the AUX input port on the earmuff. The device will automatically switch to AUX input mode.

Maintenance

Cleaning

- **Earmuffs:** Wipe with a damp cloth and mild soap. Do not immerse in water.
- **Polycarbonate Visor:** Clean with a soft cloth and a mild, non-abrasive cleaner specifically designed for plastics. Avoid harsh chemicals that can scratch or damage the visor.

- **Headband:** Wipe clean with a damp cloth.

Storage

Store the ear protection bar in a clean, dry place away from direct sunlight and extreme temperatures. Ensure the visor is protected from scratches.

Battery Care

To prolong battery life, charge the device regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device fully.
Cannot pair via Bluetooth.	Bluetooth not enabled on source device; device not in pairing mode; too far from source.	Ensure Bluetooth is active on your device. Power cycle the ear protection. Move closer to the source device.
No audio output.	Volume too low; incorrect input mode (Bluetooth/AUX); device not paired/connected.	Increase volume. Check Bluetooth connection or AUX cable. Ensure correct input mode is active.
Visor is scratched or unclear.	Improper cleaning; wear and tear.	Clean with appropriate materials. Replace visor if severely damaged.

Specifications

- **Model:** STIHL DYNAMIC BT-PC
- **Connectivity:** Bluetooth 4.0, AUX Input
- **Battery Life:** Approximately 38 hours
- **Visor Material:** Polycarbonate
- **Manufacturer:** STIHL
- **Country of Origin:** Made in Germany
- **Care Instructions:** Machine Wash (*Note: This specification likely refers to removable ear cushions. Follow specific cleaning instructions above for the main unit.*)

Warranty and Support

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official STIHL website. Keep your proof of purchase for warranty claims.

Manufacturer: STIHL

ASIN: B07NXVNKKW (Product Specific)

Parent ASIN: B0DJYFB3XX (General Model)

© 2024 STIHL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NXVNKKW

More documents and user manuals: **https://manuals.plus/**