Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sharper Image 1013625

Sharper Image LED Word Digital Clock Instruction Manual

Model: 1013625

Introduction

The Sharper Image LED Word Digital Clock displays time in five-minute increments using illuminated words instead of traditional numbers. This manual provides instructions for setting up, operating, and maintaining your clock.



Image: The Sharper Image LED Word Digital Clock, showcasing its unique word-based time display.

Package Contents

- 1x Sharper Image LED Word Digital Clock
- 1x USB Power Cable
- 1x USB Adapter



Image: The clock and its included power accessories.

Setup Instructions

1. **Power Connection:** Connect the included USB power cable to the clock and then to the USB adapter. Plug the adapter into a standard power outlet. The word display will flash twice upon successful connection.

SHARPER IMAGE®

INCLUDES

1x word clock 1x USB POWER CORD 1x USB adapter

POWER

The word clock is powered by connecting the included usb cable and adapter to a power outlet or by connecting the cable to a 5v usb power. Use UI certified adapter only (5v dc, a1).

SETTING THE CLOCK

1. Connect the clock to a power source. The word will flash 2 times.
2. The clock will display "it is tweleve o'clock (right).
3. Move the time forward by pushing and holding the time advance button, or backwards by pushing and holding the time reverse button.
4. When you have reached the desired time, release the button and the clock will display the time in the five minute segments.

READING THE CLOCK

- Every five minutes, the clock will change its display.
- The clock is read from top to bottom.
- The clock displays the time in terms of minutes until the hour

  Up to 30 minutes and then minutes until the hour.

  0 it is: Five minutes past, ten minutes past, fifteen minutes past, twenty minutes past, twenty five past, minutes past (hour).

  0 it is: Twenty five minutes to, twenty minutes to, fifteen minutes to, ten minutes, to five minutes to (hour).



READS: IT IS TWELVE O'OCLOCK



READS: IT IS FIFTEEN MINUTUES TO THREE



READS: IT IS TEN MINUTUES PAST FOUR

Image: Power input and control buttons on the side of the clock.

2. **Initial Display:** The clock will initially display "IT IS TWELVE O'CLOCK".
3. **Setting the Time:** Use the "Advance" (+) and "Reverse" (-) buttons located on the side of the clock to adjust the time. Press and hold the respective button to move the time forward or backward.



Image: The side of the clock showing the power port and time adjustment buttons.

4. **Confirming Time:** Once the desired time is displayed, release the button. The clock will then display the time in five-minute segments.

For a visual guide on setting the time, please refer to the video below:

Your browser does not support the video tag.

Video: Demonstrates the setup and time-setting process for the Sharper Image Word Clock.

Operating Instructions

The Sharper Image LED Word Digital Clock displays time in a unique word format, updating every five minutes.

Reading the Clock:

- The clock changes its display every five minutes.
- Time is read from top to bottom.
- The display indicates time in terms of minutes past or minutes to the hour.
- For example:

- "IT IS FIVE MINUTES PAST THREE"
- "IT IS TWENTY MINUTES TO FOUR"



Image: Visual guide for understanding the word clock's time display.

Maintenance

This clock is designed for low maintenance. To clean, gently wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

Troubleshooting

- **Clock Not Lighting Up:** Ensure the USB power cable is securely connected to both the clock and the USB adapter, and that the adapter is plugged into a functional power outlet.
- **Time Not Updating:** Verify the clock is receiving continuous power. If power is interrupted, the clock may need to be reset using the (+) and (-) buttons.
- **Brightness Adjustment:** Some models may feature a dimmer function. Refer to the product packaging or manufacturer's website for specific instructions on adjusting brightness, if available.

- **Battery Backup:** The clock primarily operates via corded electric power. While the product specifications mention "3 Unknown batteries required," these are typically for backup to retain settings during power outages, not for continuous operation. Batteries are not included.

Specifications

Feature	Detail
Brand	Sharper Image
Model Number	1013625
Color	Black Finish
Display Type	Digital (Word Display)
Product Dimensions	7.75"W x 7.75"H
Power Source	Corded Electric (USB)
Material	Metal, Plastic
Mounting Type	Wall Mount, Desk/Shelf
Item Weight	16 ounces (1 pound)
Batteries Required	3 Unknown batteries (for backup, not included)

Warranty and Support

This product comes with a Limited Warranty. For warranty claims, technical support, or further assistance, please contact Sharper Image customer service or visit their official website. Keep your purchase receipt for warranty validation.

© 2025 Sharper Image. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NXWXQYH

More documents and user manuals: **https://manuals.plus/**