wirsh CM-119A

wirsh CM-119A Single-Serve Coffee Maker Instruction Manual

Model: CM-119A | Brand: wirsh

1. Introduction

Thank you for choosing the wirsh CM-119A Single-Serve Coffee Maker. This appliance is designed to provide you with a convenient and efficient way to enjoy freshly brewed coffee or tea. Featuring an illuminated LCD display with a programmable 24-hour timer, you can easily set your preferred brewing time. The coffee maker is compatible with various coffee grounds types and includes a reusable mesh filter, promoting an eco-friendly brewing experience. It also comes with a 14oz food-grade stainless steel travel mug, perfect for enjoying your beverage on the go.

2. Important Safety Information

Please read all instructions carefully before using the appliance. Keep this manual for future reference.

- Always ensure the appliance is unplugged before cleaning or when not in use.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Avoid contact with hot surfaces. Use handles or knobs.
- Do not operate the appliance with a damaged cord or plug.
- Use only cold, fresh water for brewing.
- Ensure the lid is securely closed during operation.
- Do not open the lid during the brewing cycle to avoid scalding.
- This appliance is for household use only.

3. Package Contents

Verify that all items are present in the box:

- 1 x wirsh Single-Serve Coffee Maker

- 1 x Reusable Coffee Filter
- 1 x Filter Funnel
- 1 x 14oz Double-Wall Stainless Steel Travel Mug
- 1 x Easy-Drink Lid for Travel Mug
- 1 x Instruction Manual
- 1 x wirsh Service Card

4. Product Overview

The wirsh CM-119A Single-Serve Coffee Maker is designed for convenience and efficiency. Its compact design makes it ideal for small spaces, while its programmable features ensure your coffee is ready when you are.



Figure 1: wirsh Single-Serve Coffee Maker highlighting key features such as multiple use for coffee powder/pad/tea leaf, ultra-compact design, illuminated LCD display with 24-hour programmable timer, auto shut-off function, and a 14oz double-wall vacuum insulated stainless steel travel mug.

Key components include the water reservoir, filter basket, brewing head, control panel with LCD display, and the

mug rest area.



Figure 2: The wirsh coffee maker shown with its thermal travel mug (with lid) and the removable filter basket, illustrating the complete set of components.

The coffee maker features precise temperature control, ensuring your beverage is brewed at an optimal 208°F for rich flavor.



Figure 3: Illustration of the wirsh coffee maker's precise temperature control, indicating a brewing temperature of 208°F, perfect for both coffee and tea.

5. Setup

1. **Initial Cleaning:** Before first use, wash the reusable filter, travel mug, and lid with warm, soapy water. Rinse thoroughly. Wipe the exterior of the coffee maker with a damp cloth.
2. **First Water Cycle:** Fill the water reservoir with clean water up to the 14oz mark (visible inside the reservoir). Place the empty travel mug on the drip tray. Close the lid. Press the ON/OFF button to run a cycle without coffee. Discard this water. This cleans the internal components.
3. **Placement:** Place the coffee maker on a stable, flat, heat-resistant surface. Ensure it is near a power outlet and away from water sources.

6. Operating Instructions

Follow these steps to brew your coffee:

1. **Fill Water Reservoir:** Open the top lid of the coffee maker. Fill the water reservoir with fresh, cold water. You can use the included travel mug to measure the desired amount (up to 14oz). The internal markings indicate

8oz, 10oz, and 14oz levels.

2. **Add Coffee Grounds:** Place the reusable filter into the filter funnel. Add your desired amount of ground coffee to the filter. For fine grounds, use approximately 3 scoops (using the included spoon). For regular grounds, use approximately 4 scoops. Adjust to taste.
3. **Close Lid:** Securely close the top lid of the coffee maker.
4. **Place Mug:** Place the 14oz stainless steel travel mug (or your own mug that fits) on the drip tray.
5. **Start Brewing:** Plug in the coffee maker. The LCD display will illuminate. Press the **ON/OFF** button to start brewing. The indicator light will turn red during brewing.
6. **Programmable Brewing:** To set a delayed brew time, press the **PRO** button. Use the **HOUR** and **MIN** buttons to set your desired brew time. Once set, press the **ON/OFF** button. The indicator light will blink red, indicating the timer is active.
7. **Completion:** The brewing process will stop automatically. The indicator light will turn off (or green, depending on the model). Wait a few minutes after brewing is complete to allow any remaining drips to fall before removing your mug.

Your browser does not support the video tag.

Video 1: Official demonstration of the wirsh Single-Serve Coffee Maker, showing how to add water and coffee grounds, set the programmable timer, and initiate brewing. It also highlights the auto shut-off feature and the convenience of the travel mug.

7. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

1. **Unplug:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Clean Filter and Funnel:** Remove the reusable filter and filter funnel. Discard used coffee grounds. Rinse both thoroughly under running water. They are washable and do not require paper filters.
3. **Clean Travel Mug:** Wash the stainless steel travel mug and its lid with warm, soapy water. Rinse well. The travel mug is double-wall insulated but not dishwasher safe.
4. **Wipe Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Clean Water Reservoir:** Periodically wipe the inside of the water reservoir with a damp cloth to prevent mineral buildup.
6. **Descaling:** Depending on water hardness, descale the coffee maker every 2-3 months. Fill the reservoir with a mixture of water and white vinegar (1:1 ratio). Run a brew cycle. Repeat with clean water to rinse.

8. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; Power outage; Faulty outlet.	Ensure appliance is securely plugged in. Check power supply. Try a different outlet.
Coffee is not brewing.	Insufficient water in reservoir; Lid not closed properly.	Fill water reservoir to desired level. Ensure lid is securely closed.

Problem	Possible Cause	Solution
Coffee tastes weak.	Not enough coffee grounds; Coarse grind; Descaling needed.	Add more coffee grounds. Use a finer grind. Descale the machine.
Water leaks from the machine.	Overfilled water reservoir; Lid not closed properly.	Do not exceed the maximum fill line. Ensure lid is securely closed.
Programmable timer not working.	Time not set correctly; Program not activated.	Refer to operating instructions for setting time and activating program mode.

9. Specifications



Figure 4: Physical dimensions of the wirsh Single-Serve Coffee Maker.

Feature	Detail
Model Number	CM-119A
Brand	wirsh
Capacity	14 ounces
Color	Black
Product Dimensions (D x W x H)	5.1" x 7" x 11"
Item Weight	1.8 Pounds
Wattage	700 watts
Voltage	120 Volts (AC)
Material	Plastic, Stainless Steel
Special Features	Auto Shut-Off, Permanent Filter, Portable, Single Cup Brew, Timer
Coffee Input Type	Coffee Grounds
Filter Type	Reusable Mesh Filter

10. Warranty and Support

The wirsh CM-119A Single-Serve Coffee Maker comes with a 1-year hassle-free replacement warranty. For any inquiries or assistance, please contact our 7x24 hours customer service. Your satisfaction is our priority.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question