HCDZ RM-ADP017

HCDZ Replacement Remote Control User Manual

For Sony RM-ADP017, DAV-DZ850KW, HCD-DZ850KW, DAV-DZ830W, HCD-DZ830W DVD Home Theatre Systems

Introduction

This document provides essential instructions for the setup, operation, and maintenance of your HCDZ replacement remote control. This remote is designed to function as a direct replacement for various Sony DVD Home Theatre System models, requiring no programming.

Setup

Battery Installation

The remote control requires two (2) AA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote control with the battery compartment open, illustrating where to insert the AA batteries.

Once batteries are correctly installed, the remote control is ready for use without any additional programming.

Operating Instructions

Basic Functions

This HCDZ replacement remote control is designed to replicate the functions of your original Sony DVD Home Theatre System remote. Simply point the remote towards your home theatre system and press the desired function button.



Image: Front view of the HCDZ replacement remote control, displaying its layout and buttons.

Compatibility

This remote control is compatible with the following Sony DVD Home Theatre System models:

- RM-ADP017
- DAV-DZ850KW
- HCD-DZ850KW
- DAV-DZ830W
- HCD-DZ830W

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AA batteries. Do not mix old and new batteries, or different types of batteries.

Troubleshooting

Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AA batteries if necessary.
- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the infrared sensor on your DVD Home Theatre System. Obstructions can block the signal.
- **Distance:** Ensure you are within the effective operating range of the remote control.

Specifications

Brand	HCDZ
Model Number	RM-ADP017 (Replacement)
Compatible Devices	Sony DVD Home Theatre Systems (DAV-DZ850KW, HCD-DZ850KW, DAV-DZ830W, HCD-DZ830W)
Connectivity Technology	Infrared (IR)
Batteries Required	2 x AA (not included)
Special Feature	No programming needed, works out of the package

Support and Warranty

As a replacement remote control, specific warranty details may vary. For any issues not covered in this manual or for warranty inquiries, please contact the seller directly through your purchase platform. Ensure to provide your order details for efficient support.

© 2023 HCDZ. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question