Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NC266UH

ZdalaMit NC266UH NC266 Replacement Remote Control User Manual

Model: NC266UH / NC266 | Brand: ZdalaMit

Introduction

This manual provides comprehensive instructions for the ZdalaMit NC266UH NC266 Replacement Remote Control. This remote is designed to function as a direct replacement for original Magnavox HD DVR DVD Recorder remotes, offering seamless operation without the need for complex programming.

Compatibility

The NC266UH NC266 Replacement Remote Control is compatible with the following Magnavox HD DVR DVD Recorder models:

- MDR868H
- MDR868H/F7
- MDR865H
- MDR865H/F7
- MDR867H
- MDR867H/F7
- MDR515H/F7

Setup

Battery Installation

To begin using your remote control, install two (2) AAA alkaline batteries. Ensure correct polarity (+/-) as indicated inside the battery compartment.



Image: Back view of the remote control. The battery compartment is located on the lower half of the back, designed for easy access.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two 1.5V AAA alkaline batteries, matching the positive (+) and negative (-) terminals with the markings

inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.

Initial Use

No programming or pairing is required for this replacement remote control. Once batteries are installed, the remote is ready for immediate use with your compatible Magnavox HD DVR DVD Recorder.

Operating Instructions

The NC266UH remote control features a standard layout for Magnavox HD DVR DVD Recorders. Familiarize yourself with the button functions for optimal use.



Image: Front view of the remote control. Key buttons include Power (red, top left), Title, Home, Menu, Navigation Pad (OK in center), Playback controls (Rewind, Play, Fast Forward, Pause, Stop), Number Pad, Channel Up/Down, Volume Up/Down, and Record (red, bottom right).

Key Button Functions

- **Power ( ):** Turns the connected device on or off.
- **TITLE:** Accesses the title menu or disc menu.
- **HOME:** Returns to the main home screen or menu.
- **MENU:** Displays the system menu.
- **Navigation Pad (▲ ▼ ◄ ►):** Used to navigate through menus and options.
- **OK:** Confirms selections.
- **REPLAY / BACK / EXIT / SKIP:** Control playback and navigation within menus.
- **AUDIO / DISPLAY / INFO / SOURCE:** Access various audio, display, information, and input source settings.
- **Playback Controls (◄► ■):** Control media playback (Rewind, Play, Fast Forward, Pause, Stop).
- **Number Pad (0-9):** For direct channel input or numerical selections.
- **CH (+/-):** Changes channels.
- **REC (●):** Initiates recording.
- **HDD/EXT.HDD / DVD:** Selects between internal HDD, external HDD, or DVD functions.

MAINTENANCE

Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both AAA batteries simultaneously with new ones to ensure optimal performance.

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners, as these can damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity.
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote and the Magnavox device's infrared receiver.
  - Ensure you are within the maximum operating range (approximately 33 feet).
- **Buttons feel stiff or unresponsive:**
  - This can sometimes occur with new remotes. Continued use typically softens the buttons.
  - Ensure you are pressing the buttons firmly and directly.
- **Remote functions intermittently:**
  - This often indicates low battery power. Replace batteries.
  - Verify that the remote's infrared emitter is not blocked or dirty.
- **Advanced Troubleshooting (Specific to some Magnavox models):**

  Some users have reported that if the remote does not work immediately after inserting batteries, pressing and holding the "HOLD" button and the "TWO" key simultaneously might resolve the issue by matching the remote control to the DVR command code. This is an unofficial solution reported by users and may not apply to all devices or situations.

Specifications

Model Name	NC266UH / NC266
Brand	ZdalaMit
Connectivity Technology	Infrared
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Maximum Range	Approximately 33 feet (10 meters)
Dimensions (L x W x H)	5.96"L x 1.99"W x 0.55"H (approx. 15.14cm x 5.05cm x 1.4cm)
Item Weight	40 Grams (without batteries)
Color	Black
Special Feature	Ergonomic design

Warranty Information

This ZdalaMit remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

Support

If you encounter any issues or have questions regarding your ZdalaMit NC266UH NC266 Replacement Remote Control, please contact the seller or ZdalaMit customer support. Refer to your purchase documentation for specific contact details.
For general inquiries, you may also refer to the product listing on Amazon for seller contact information:Amazon Product Page

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P4N1DZR

More documents and user manuals: **https://manuals.plus/**