De'Longhi FH1163

De'Longhi Classic Multifryer FH1163 User Manual

Model: FH1163

1. Introduction

Thank you for choosing the De'Longhi Classic Multifryer FH1163. This appliance is designed to prepare a variety of dishes with minimal oil, offering a versatile cooking experience. To ensure safe and efficient operation, please read this instruction manual thoroughly before using the appliance and retain it for future reference.

Important Safety Instructions

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

2. Product Overview

The De'Longhi Classic Multifryer FH1163 is a versatile multicooker designed for various cooking methods, including frying, baking, and stewing. It features an automatic stirring function and requires minimal oil for many recipes.

Components

Familiarize yourself with the main parts of your Multifryer:



Figure 1: Front view of the De'Longhi Classic Multifryer FH1163, showing the main body, lid, and control panel.



Figure 2: Side view of the De'Longhi Classic Multifryer FH1163, highlighting its compact design and ventilation slots.



Figure 3: Top view of the De'Longhi Classic Multifryer FH1163 with french fries inside, illustrating the transparent lid and internal paddle.

- **Transparent Lid:** Allows monitoring of the cooking process.
- **Removable Bowl:** Non-stick cooking bowl.
- **Automatic Mixing Paddle:** Ensures even cooking and stirring.
- **Control Panel:** For setting cooking time and power level.
- **Heating Elements:** Upper and lower heating for consistent results.

3. Initial Setup and First Use

Before using your Multifryer for the first time, follow these steps:

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging.
2. **Clean:** Wash the removable bowl, lid, and mixing paddle with warm soapy water. Rinse thoroughly and dry completely. Wipe the exterior of the appliance with a damp cloth.
3. **Placement:** Place the Multifryer on a stable, heat-resistant, and level surface, away from walls or other

appliances to ensure proper ventilation.

4. **Power Connection:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before plugging in.

4. Operating Instructions

The De'Longhi Classic Multifryer FH1163 is designed for ease of use. Follow these general steps for cooking:

Control Panel

The control panel typically includes a timer knob and a power level selector. Refer to the markings on your specific unit for precise functions.

Automatic Stirring Function

The integrated mixing paddle automatically stirs ingredients during cooking, ensuring even heat distribution and consistent results, especially for dishes like fries or risotto. If a recipe does not require stirring, the paddle can be removed.

Cooking Process

1. **Prepare Ingredients:** Place your food into the removable cooking bowl. Add oil if required by the recipe (e.g., 1 tablespoon for 1kg of fresh potatoes).
2. **Close Lid:** Ensure the lid is securely closed.
3. **Set Power Level:** Use the power level selector to choose the desired heat setting.
4. **Set Timer:** Turn the timer knob to the desired cooking duration. The appliance will start heating once the timer is set.
5. **Monitor Cooking:** The transparent lid allows you to observe the cooking progress. The automatic stirring paddle will operate if installed.
6. **Finish Cooking:** The appliance will automatically switch off when the timer reaches zero. Carefully open the lid and remove the cooked food.

This Multifryer is suitable for preparing a wide range of dishes, including pizza, cake, pies, risotto, stew, fish, meat, and potatoes.

5. Cooking Tips

- For crispy results with fresh potatoes, use only 1 tablespoon of oil for 1kg of potatoes.
- The Multifryer can cook for up to 6 people, making it suitable for family meals.
- Preheating is generally not required for most recipes, saving time and energy.
- Experiment with different ingredients and recipes to discover the full potential of your Multifryer.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your De'Longhi Classic Multifryer FH1163.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Remove Components:** Detach the lid, removable bowl, and mixing paddle.
3. **Dishwasher Safe Parts:** The removable bowl, lid, and mixing paddle are dishwasher-safe for convenient cleaning. Alternatively, wash them by hand with warm soapy water and a non-abrasive sponge.

4. **Appliance Body:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are completely dry before reassembling and storing the appliance.

7. Troubleshooting

If you encounter any issues with your Multifryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; timer not set.	Ensure the power cord is securely plugged into a working outlet. Set the timer to the desired cooking duration.
Food not cooking evenly.	Too much food in the bowl; paddle not installed or obstructed.	Do not overload the cooking bowl. Ensure the mixing paddle is correctly installed and free to rotate.
Smoke coming from the appliance.	Excess oil or food residue; certain ingredients naturally produce smoke.	Ensure the appliance is clean before use. Reduce the amount of oil. If smoke persists, unplug and contact customer support.
Food is not crispy.	Too much moisture; insufficient cooking time/temperature.	Pat ingredients dry before cooking. Adjust cooking time or power level as needed.

8. Technical Specifications

Refer to the following specifications for your De'Longhi Classic Multifryer FH1163:

- **Brand:** De'Longhi
- **Model Name:** FH1163
- **Model Number:** 2724292792464
- **Color:** Black
- **Material:** Plastic
- **Product Dimensions (D x W x H):** 46.6 x 31.4 x 37.8 cm
- **Item Weight:** 5.7 Kilograms
- **Power / Wattage:** 200 watts
- **Oil Capacity:** 1.5 Liters
- **Manufacturer:** De'Longhi

9. Warranty and Customer Support

Your De'Longhi Classic Multifryer FH1163 comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or any questions regarding the operation of your appliance, please contact De'Longhi customer support. Contact information can typically be found on the warranty card or the official De'Longhi website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question