Ingersoll I07702

Ingersoll The Jazz Automatic Watch I07702 User Manual

Model: I07702

Introduction

Thank you for choosing the Ingersoll The Jazz Automatic Watch, Model I07702. This timepiece combines classic design with the precision of an automatic movement, featuring a skeleton dial, dual time display, and moon phase indicator. This manual provides essential information for the proper setup, operation, and care of your watch to ensure its longevity and accurate performance.
Please read these instructions carefully before using your watch.

Product Overview

The Ingersoll The Jazz I07702 features a silver stainless-steel case, a blue leather strap, and a silver skeleton dial. It is powered by an automatic movement and includes a buckle closure. Key features include a dual-time display and a moon phase indicator.



Image: Front view of the Ingersoll The Jazz I07702 watch dial, highlighting the automatic movement's visible gears, the dual time sub-dial at 9 o'clock, and the moon phase display at 12 o'clock.

Setup

1. Unboxing and Initial Inspection

Carefully remove the watch from its presentation box. Inspect the watch for any visible damage or defects. Ensure all protective films are removed from the crystal and case back.

2. Initial Winding

As an automatic watch, the I07702 is powered by the motion of your wrist. However, for the first use or after a period of inactivity, it is recommended to manually wind the watch. To do this, ensure the crown is in position 1 (fully pushed in). Rotate the crown clockwise approximately 20-30 times. This will provide sufficient power reserve to start the movement.

3. Setting the Time

1. Pull the crown out to position 3 (farthest out).
2. Rotate the crown clockwise or counter-clockwise to set the main time display.
3. Once the desired time is set, push the crown back into position 1 (fully pushed in) to engage the movement.



Image: Angled view of the watch, illustrating the position of the crown for winding and time setting.

4. Adjusting the Strap

The watch comes with a blue leather strap with a buckle closure. To adjust the fit, simply thread the strap through the buckle and secure it in the desired hole. Ensure the watch is snug but comfortable on your wrist, allowing for proper blood circulation.



Image: Detail of the leather strap and buckle mechanism.

Operating the Watch

1. Automatic Movement

Your Ingersoll The Jazz watch is equipped with an automatic mechanical movement. This means it is powered by the natural motion of your arm. When worn regularly (approximately 8-10 hours a day), the watch will remain wound. If the

watch is not worn for an extended period, it may stop. In this case, manually wind it as described in the 'Initial Winding' section before setting the time.

2. Dual Time Display

The watch features a sub-dial, typically located at the 9 o'clock position, which displays a second time zone. This sub-dial operates independently from the main time display. To set the dual time:

1. Locate the small pusher button on the side of the watch case, usually near the 8 or 10 o'clock position.
2. Use a small, non-sharp tool (like a toothpick) to gently press the pusher. Each press will advance the hour hand of the dual time sub-dial by one hour.
3. Continue pressing until the desired second time zone is displayed.

3. Moon Phase Indicator

The moon phase indicator, typically located at the 12 o'clock position, displays the current phase of the moon. This complication is often set via a separate pusher button on the watch case, similar to the dual time setting. To set the moon phase:

1. Locate the small pusher button on the side of the watch case, usually near the 2 or 4 o'clock position.
2. Use a small, non-sharp tool to gently press the pusher. Each press will advance the moon phase disc.
3. Consult a current moon phase calendar to set the indicator accurately.

Maintenance

1. Cleaning

To maintain the appearance of your watch, wipe the case and crystal with a soft, dry cloth regularly. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap becomes dirty, wipe it gently with a slightly damp cloth and allow it to air dry completely.

2. Water Resistance

Your Ingersoll The Jazz I07702 watch has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming, showering, or washing hands. It is **not** suitable for diving, snorkeling, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

- **50 Meters (5 ATM):** Suitable for everyday use, hand washing, rain, and short periods of recreational swimming.
- **Avoid:** Hot water, steam (e.g., sauna, hot showers), and chemical exposure, as these can compromise the water seals.


107702
RF
STAINLESS STEEL 316L
5ATM WATER RESISTANT
Inversoll
22 JEWELS
AUTOMATIC

Image: Rear view of the watch, displaying the transparent case back with movement details and water resistance markings.

3. Storage

When not wearing your watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. The original presentation box is ideal for storage.

4. Service

For optimal performance, mechanical watches typically require professional servicing every 3-5 years. Contact an authorized Ingersoll service center for maintenance.

Troubleshooting

- **Watch Not Running:** If the watch has stopped, it likely needs to be wound. Manually wind the watch by rotating the crown clockwise 20-30 times while it is in position 1 (fully pushed in). If it still does not start, ensure it is worn regularly to allow the automatic movement to function.
- **Time Inaccuracy:** Small variations in timekeeping are normal for mechanical watches. If the watch is consistently gaining or losing significant time, it may require adjustment by a professional watchmaker.
- **Condensation Under Crystal:** If you notice condensation inside the watch, this indicates a breach in the water resistance. Immediately take the watch to an authorized service center to prevent further damage to the movement.
- **Strap Discomfort:** If the leather strap causes irritation, ensure it is not too tight. Clean the strap regularly and allow it to dry completely after exposure to moisture.

Specifications

Model Name	The Jazz
Model Number	I07702
Movement Type	Automatic
Display Type	Analog
Case Material	Stainless Steel
Case Diameter	42 Millimetres
Case Thickness	15.50 Millimetres
Band Material	Leather
Band Color	Blue
Band Width	20 Millimetres
Dial Color	Silver
Crystal Type	Crystal
Water Resistance Depth	50 Metres (5 ATM)
Clasp Type	Buckle

Special Features	Dual-Time Display, Moon Phase Indicator, Skeleton Dial
Item Weight	95 Grams
Product Dimensions	27.5 x 1.55 x 4.2 cm

Warranty Information

Ingersoll watches are manufactured to high standards and are covered by a limited warranty against manufacturing defects. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

Customer Support

For any questions, service requests, or technical assistance regarding your Ingersoll The Jazz Automatic Watch I07702, please contact your authorized Ingersoll retailer or visit the official Ingersoll website for customer support contact information.
When contacting support, please have your watch model number (I07702) and proof of purchase readily available.

© 2024 Ingersoll. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question