Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ELECTROPRIME RENJOYQUI10040

User Manual for ELECTROPRIME Digital Alarm Clock

Model: RENJOYQUI10040

Introduction

Thank you for purchasing the ELECTROPRIME Digital Alarm Clock. This manual provides detailed instructions for setting up, operating, and maintaining your new alarm clock. Please read this manual thoroughly before use to ensure proper functionality and to extend the life of your device.

Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Use only the specified power source for the device.
- Keep out of reach of children.

Package Contents

Upon opening the package, please verify that you have received the following item:

- 1 x ELECTROPRIME Digital Alarm Clock (Model: RENJOYQUI10040)

Product Features

The ELECTROPRIME Digital Alarm Clock offers a range of convenient features:

- Clear Digital Display
- Alarm Function with Snooze
- Integrated Backlight for visibility in low light
- Time (12/24 hour format)
- Date (Month/Day) and Day of the Week Display
- Temperature Display (Celsius/Fahrenheit)
- Compact Tabletop Design

Product Overview



Figure 1: Front view of the alarm clock, highlighting the display area and the control buttons: MODE, SET, LIGHT, UP, and DOWN.



Figure 2: The alarm clock with its blue backlight activated, showing the time, date, day of the week, and current temperature. This image demonstrates the clock's display clarity in a lit environment.



Figure 3: The alarm clock with its blue backlight illuminated in a dark environment, showcasing its visibility at night. The display shows time, date, day, and temperature.

Setup

1. **Unpacking:** Carefully remove the alarm clock from its packaging.
2. **Power Connection:** Connect the appropriate AC power adapter (not included, as per "Are Batteries Included: No" and "Power Source: Ac") to the clock's power input port and then to a standard electrical outlet. The display should illuminate.
3. **Initial Display:** Upon first power-up, the clock may display a default time or a flashing indicator.

Operating Instructions

Button Functions:

- **MODE:** Cycles through display modes (e.g., Time, Alarm setting).

- **SET:** Enters setting mode for the currently displayed parameter.
- **LIGHT:** Activates the backlight.
- **UP:** Increases values during setting, or navigates up.
- **DOWN:** Decreases values during setting, or navigates down.

Setting Time and Date:

1. Press the **MODE** button until the time display is active.
2. Press and hold the **SET** button until the hour digit begins to flash.
3. Use the **UP** or **DOWN** buttons to adjust the hour.
4. Press **SET** again to move to the minute setting. Adjust with **UP** or **DOWN**.
5. Continue pressing **SET** to cycle through year, month, day settings, adjusting each with **UP** or **DOWN**.
6. Press **MODE** to exit the setting mode and save changes.

Setting the Alarm:

1. Press the **MODE** button until the alarm time display is active (often indicated by an alarm icon).
2. Press and hold the **SET** button until the alarm hour digit begins to flash.
3. Use the **UP** or **DOWN** buttons to adjust the alarm hour.
4. Press **SET** again to move to the alarm minute setting. Adjust with **UP** or **DOWN**.
5. Press **SET** again to confirm and exit alarm setting.
6. To activate/deactivate the alarm, press the **UP** button while in alarm display mode. An alarm icon will appear/disappear on the display.

Using the Backlight:

Press the **LIGHT** button to illuminate the display. The backlight will typically stay on for a few seconds and then automatically turn off to conserve power.

Temperature Display:

The clock automatically displays the ambient temperature. To switch between Celsius (°C) and Fahrenheit (°F), locate the small switch or button on the back or side of the unit (refer to physical unit for exact location), or press a combination of **UP**/**DOWN** buttons while in time display mode (consult specific model for details).

Maintenance

- **Cleaning:** Wipe the clock with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the clock for an extended period, disconnect it from the power source.
- **Power:** Ensure a stable power supply to prevent damage to the internal components.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	No power, loose connection, or power outage.	Check power adapter connection. Ensure power outlet is functional.
Alarm does not sound.	Alarm not activated, or alarm volume too low (if adjustable).	Ensure alarm is set and activated (alarm icon visible).

Problem	Possible Cause	Solution
Time is incorrect.	Time not set correctly after power loss or initial setup.	Refer to "Setting Time and Date" section to reset the time.

Specifications

Brand	ELECTROPRIME
Model Number	RENJOYQUI10040
Display Type	Digital
Special Features	Alarm, Backlight, Temperature Display
Power Source	AC (Electrical Operation)
Mounting Type	Tabletop
Material	Others
Colour	Multicolour
Batteries Included	No

Warranty and Support

This product comes with a standard 7-day warranty as per the purchase terms. For any issues, questions, or support needs, please contact your retailer or the ELECTROPRIME customer service. Please have your model number (RENJOYQUI10040) and purchase details ready when contacting support.
For further assistance, please visit the official ELECTROPRIME website or contact their customer support channels.

© 2023 ELECTROPRIME. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PG34S1C

More documents and user manuals: **https://manuals.plus/**