HUAWEI MRD-LX3

Huawei Y6 2019 MRD-LX3 User Manual

Comprehensive Guide for Your Huawei Y6 2019 Smartphone

1. Introduction

Welcome to the user manual for your new Huawei Y6 2019 (Model: MRD-LX3) smartphone. This guide provides detailed instructions on how to set up, operate, maintain, and troubleshoot your device. Please read this manual thoroughly to ensure optimal performance and longevity of your phone.

The Huawei Y6 2019 features a 6.09-inch Dewdrop Display, 32GB of internal storage, 2GB of RAM, and supports Dual SIM functionality. It is equipped with a 13MP rear camera, an 8MP front camera, and A-GPS for navigation. This model also includes a fingerprint sensor for enhanced security.

2. Product Overview

Familiarize yourself with the physical components and controls of your Huawei Y6 2019.





Figure 2.1: Front View. This image displays the front of the Huawei Y6 2019, highlighting its 6.09-inch Dewdrop Display with a small notch at the top for the front camera and sensors. The Huawei logo is visible at the bottom bezel.





Figure 2.2: Rear View. The back of the Huawei Y6 2019 is shown, featuring the 13MP main camera and LED flash in the upper left corner. The fingerprint sensor is centrally located on the upper half of the back panel. The Huawei branding is visible towards the bottom.



Figure 2.3: Bottom View. This image shows the bottom edge of the device, including the micro-USB charging port in the center, flanked by speaker grilles on both sides.



Figure 2.4: Top View. The top edge of the Huawei Y6 2019 is depicted. Please note that according to product specifications, this model does not feature a 3.5mm headphone jack, despite some visual representations that may suggest otherwise for other variants.

2.1 Package Contents

Upon unboxing your Huawei Y6 2019, ensure all items are present:

- Huawei Y6 2019 Smartphone (MRD-LX3)
- Charger
- Quick Start Guide (may vary by region)
- SIM Eject Tool (may vary by region)

3. Setup

3.1 Charging the Battery

Before first use, fully charge your phone's battery. Connect the charger to the micro-USB port at the bottom of the phone and plug it into a power outlet. The charging indicator will appear on the screen.

3.2 Inserting SIM Cards and microSD Card

The Huawei Y6 2019 supports Dual SIM cards and a microSD card for expandable storage.

1. Locate the SIM card tray on the side of the phone.
2. Insert the SIM eject tool (or a small paperclip) into the small hole next to the tray to pop it open.
3. Carefully pull out the tray.
4. Place your Nano-SIM cards and/or microSD card into the designated slots on the tray, ensuring correct orientation.
5. Gently push the tray back into the phone until it clicks into place.

3.3 Powering On/Off

- **To Power On:** Press and hold the Power button (located on the right side) until the Huawei logo appears.
- **To Power Off:** Press and hold the Power button until the power options menu appears, then select "Power off".
- **To Restart:** Press and hold the Power button until the power options menu appears, then select "Restart".

3.4 Initial Setup Wizard

Upon first power-on, the phone will guide you through an initial setup process. Follow the on-screen prompts to:

- Select your language and region.
- Connect to a Wi-Fi network.
- Sign in with your Google account (or create one).
- Set up screen lock (PIN, pattern, password).
- Configure fingerprint unlock.

4. Operating Your Device

4.1 Basic Navigation

The Huawei Y6 2019 operates on Android. Navigate the interface using touch gestures:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through screens or lists.
- **Pinch:** To zoom in or out on photos or web pages.
- **Long Press:** To access contextual menus or move icons.

4.2 Calls and Messaging

- **Making Calls:** Open the Phone app, enter the number, and tap the call icon.
- **Sending Messages:** Open the Messages app, tap to compose a new message, enter recipient(s) and text, then send.

4.3 Camera Usage

Your phone is equipped with a 13MP rear camera and an 8MP front camera.

1. Open the Camera app.
2. Select between photo, video, or other modes.
3. Tap the shutter button to capture an image or start/stop video recording.
4. Use the toggle to switch between front and rear cameras.

4.4 Connectivity

- **Wi-Fi:** Go to Settings > Network & internet > Wi-Fi to connect to available networks.
- **Bluetooth:** Go to Settings > Connected devices > Bluetooth to pair with other Bluetooth devices.
- **GPS:** Location services are enabled by default for navigation and location-based apps.

5. Maintenance

5.1 Cleaning Your Device

To keep your phone in optimal condition:

- Wipe the screen and back panel with a soft, lint-free cloth.
- Avoid using harsh chemicals, abrasive cleaners, or aerosol sprays.
- Keep ports free of dust and debris.

5.2 Battery Care

To maximize battery life:

- Avoid extreme temperatures.
- Use only the original charger or a certified compatible charger.
- Avoid fully discharging the battery frequently.

5.3 Software Updates

Regularly check for software updates to ensure your device has the latest features and security patches. Go to Settings > System > Software update.

5.4 Storage Management

To manage your 32GB internal storage:

- Regularly clear cache and unnecessary files.
- Uninstall unused applications.
- Utilize a microSD card for additional storage of photos, videos, and documents.

6. Troubleshooting

This section addresses common issues you might encounter with your Huawei Y6 2019.

6.1 Device Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

6.2 Network Connectivity Issues

- Check if Airplane mode is off (Settings > Network & internet).
- Ensure your SIM card is properly inserted and active.
- Restart the phone.
- Reset network settings (Settings > System > Reset options > Reset Wi-Fi, mobile & Bluetooth).

6.3 Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data (Settings > Apps & notifications > See all apps > [App Name] > Storage & cache).
- Update the app from the Google Play Store.
- Restart the phone.

6.4 Fingerprint Sensor Not Working

- Ensure your finger is clean and dry.
- Make sure the sensor area on the back of the phone is clean.
- Re-register your fingerprints (Settings > Security & privacy > Fingerprint ID).

6.5 Factory Reset

If issues persist, a factory reset may be necessary. This will erase all data on your phone, so back up important information first.

1. Go to Settings > System > Reset options.
2. Select "Erase all data (factory reset)".
3. Confirm your decision.

7. Specifications

Feature	Detail
Model Number	MRD-LX3
Display	6.09 inches Dewdrop Display
Operating System	Android
RAM	2 GB
Internal Storage	32 GB
Rear Camera	13 MP
Front Camera	8 MP
Battery	1 Lithium Ion battery required (Capacity not specified in input)
Connectivity	Wi-Fi, Bluetooth, A-GPS, 2G Cellular Technology
SIM Support	Dual SIM
Fingerprint Sensor	Yes
Audio Jack	No headphone jack
Color	Black
Item Weight	12 ounces
Dimensions	7.01 x 3.78 x 2.36 inches (Package Dimensions)

8. Warranty and Support

Please note that this specific product listing indicates "No Warranty US". For any support or service inquiries, it is recommended to contact the seller or the manufacturer, Huawei, directly. Keep your purchase receipt as proof of purchase.
For general information and support resources, you may visit the official Huawei support website. Search for your specific model (MRD-LX3) for relevant documentation and FAQs.

© 2025 Huawei. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question