**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## YING RAY 2019031124

# YING RAY Replacement Air Conditioner Remote Control User Manual

Model: 2019031124

## Introduction

This manual provides comprehensive instructions for the YING RAY Replacement Air Conditioner Remote Control. Designed to be compatible with various Keystone, Midea, and Indurama air conditioner models, including R09B/BGCE, R09/BGCE, RG09E/BGCEU1, and R09D/BGCE, this remote offers a straightforward solution for controlling your air conditioning unit. It operates without the need for complex programming, functioning directly upon battery insertion.






Figure 1: Front view of the YING RAY Replacement Air Conditioner Remote Control, showing the display and all function buttons.

## Setup

### Battery Installation

The remote control requires batteries for operation. Batteries are not included with the product.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert the required batteries (typically AAA, refer to the compartment for polarity) ensuring correct polarity (+ and -) as marked inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with compatible air conditioner models without any further programming.

## Operating Instructions

This section details the functions of each button on the remote control.




Figure 2: Overview of remote control features, including compatible models and key functionalities like heating, backlight, Follow Me, and temperature display options.

- **Power Button ( )**: Press to turn the air conditioner ON or OFF.
- **MODE Button**: Cycles through operating modes such as Cool, Heat (if supported by AC unit), Fan, Dry, and Auto.
- **FAN Button**: Adjusts the fan speed (Auto, Low, Medium, High).
- **Temperature Adjustment Buttons (+ / -)**: Increases or decreases the set temperature. The display shows temperature in Fahrenheit.
- **TIMER Button**: Sets the timer for automatic ON/OFF operation. Refer to your AC unit's manual for specific timer settings.
- **CANCEL Button**: Cancels active timer settings or other temporary functions.
- **ENERGY SAVER Button**: Activates or deactivates energy-saving mode, which may adjust temperature settings for efficiency.

- **FOLLOW ME Button**: Activates the Follow Me function, allowing the remote to act as a thermostat, sensing the temperature at its location and adjusting the AC accordingly.
- **RESET Button**: Resets certain settings or functions. Use with caution.
- **LOCK Button**: Locks the remote control buttons to prevent accidental changes. Press again to unlock.
- **CLOCK Button**: Sets the current time on the remote's display.
- **SLEEP Button**: Activates sleep mode, which typically adjusts temperature gradually for comfortable sleep and energy saving.
- **LED Button**: Controls the display light on the air conditioner unit (turns it ON/OFF).




Figure 3: Comparison image showing the YING RAY replacement remote control (left) and a smaller, compatible original remote (right), illustrating the size difference and compatibility.

## Maintenance

- **Cleaning**: Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's display becomes dim or when the remote no longer responds to button presses. Always replace all batteries at the same time with new ones of the same type.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote. Store in a cool, dry place.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not responding. | Dead or incorrectly installed batteries. Obstruction between remote and AC unit. Remote out of range. | Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit. |
| AC unit not responding to specific commands. | Function not supported by your specific AC model. Remote buttons locked. | Verify your AC unit's capabilities. Press the LOCK button to unlock the remote. |
| Display is dim or blank. | Low battery power. | Replace batteries. |

## Specifications

- **Brand**: YING RAY
- **Model Number**: 2019031124
- **Compatible Models**: R09B/BGCE, R09/BGCE, RG09E/BGCEU1, R09D/BGCE (Keystone, Midea, Indurama Air Conditioners)
- **Display**: Fahrenheit
- **Power Source**: Batteries (not included)
- **Item Weight**: 1.76 ounces
- **Package Dimensions**: 6.69 x 3.54 x 1.1 inches
- **Special Feature**: Ergonomic design

## Warranty and Support

This product is designed for reliable performance. For any issues or inquiries, please refer to the retailer or platform where the product was purchased for their specific return and support policies.
As a replacement part, this remote control is intended to function as a direct substitute for the original. Ensure compatibility with your air conditioner model before purchase.

© 2024 YING RAY. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07PHF995F**

More documents and user manuals: **https://manuals.plus/**