**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Tefal CY505E30**

# Tefal CY505E30 Fast & Delicious Multicooker Electric Pressure Cooker User Manual

Model: CY505E30

## Introduction

The Tefal CY505E30 Fast & Delicious Multicooker is a versatile electric pressure cooker designed to simplify your cooking process. With a powerful 1200W heating element and a 6-liter capacity, it can prepare meals for up to 12 people efficiently. This appliance features 25 automatic programs and a manual mode, allowing you to cook a wide variety of dishes, from rice and grains to soups, meats, and even desserts like jam and cheese cream. Its innovative non-stick coated spherical inner pot ensures even heat distribution and delicious results.




*Image: The Tefal CY505E30 Fast & Delicious Multicooker, showcasing its sleek stainless steel and black design with the digital control panel visible.*

## Important Safety Instructions

Before using your Tefal Multicooker, please read all instructions carefully and retain them for future reference. This appliance is equipped with 9 protection systems to ensure user safety during cooking. Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury.

- Do not immerse the main unit in water or any other liquid.
- Ensure the pressure release valve is clear before each use.
- Do not open the lid while the multicooker is under pressure.
- Use only genuine Tefal replacement parts and accessories.

- Keep out of reach of children.
- Always unplug the appliance when not in use and before cleaning.

## Setup and Components

Upon unpacking, ensure all components are present and undamaged. Before first use, wash the inner pot, lid, and accessories thoroughly with warm soapy water, then rinse and dry completely.

### Components Overview:

1. **Main Unit:** Houses the heating element and control panel.
2. **Removable Inner Pot:** Non-stick coated, spherical pot for cooking.
3. **Lid:** With pressure release valve and sealing gasket.
4. **Control Panel:** Digital display and program buttons.
5. **Accessories:** Steamer basket, measuring cup, rice spatula.




*Image: The Tefal Multicooker with its lid open, revealing the removable inner pot. Alongside the cooker are the steamer basket, measuring cup, and rice spatula, illustrating the included accessories.*

## Included Accessories:



*Image: A white plastic rice spatula with a textured surface, designed for serving rice without sticking.*



*Image: A white plastic steamer basket with multiple slots and small legs, used for steaming food inside the multicooker.*



*Image: A clear plastic measuring cup with volume markings, typically used for measuring ingredients like rice or water.*

## Operating Instructions

### Control Panel Overview:




*Image: A close-up view of the Tefal Multicooker's control panel, featuring a digital display showing "00:05" and various program buttons such as Rice, Oatmeal, Baby food, Pressure cook, Bake, DIY, Stew/Soup, Steam, Brown, Simmer, Slow cook, and Reheat.*

The control panel features a clear digital display and intuitive buttons for selecting cooking programs and adjusting settings.

### Basic Operation:

1. **Preparation:** Place the multicooker on a stable, flat, heat-resistant surface. Ensure the inner pot is clean and properly seated inside the main unit.
2. **Add Ingredients:** Place your ingredients into the inner pot according to your recipe.
3. **Close Lid:** Securely close the lid and ensure it is locked into place. For pressure cooking, ensure the pressure release valve is set to the sealed position.
4. **Power On:** Plug the power cord into a grounded electrical outlet. Press the**Power** button to turn on the appliance.
5. **Select Program:** Use the program buttons (e.g., Rice, Stew/Soup, Steam) to select your desired cooking function. The display will show the default cooking time.
6. **Adjust Settings (Optional):** For some programs or in manual mode, you can adjust cooking time or pressure level

using the **Up/Down** arrows.

7. **Start Cooking:** Press the **Start** button to begin the cooking process.
8. **Pressure Release:** Once cooking is complete, the multicooker will beep. For pressure cooking, allow natural pressure release or carefully use the quick release method by turning the pressure release valve to the venting position. **Caution: Hot steam will be released.**



*Image: A hand pressing the steam release button on the lid of the multicooker, with visible steam escaping from the valve, demonstrating the pressure release process.*

### Using Automatic Programs:

The Tefal Multicooker offers 25 pre-set programs for various dishes. Simply select the program that matches your food type, and the cooker will automatically adjust time and temperature.

- **Rice:** For perfect fluffy rice.
- **Stew/Soup:** Ideal for slow-cooked stews and hearty soups.
- **Steam:** For healthy steamed vegetables, fish, or dumplings using the steamer basket.
- **Brown:** Sauté or brown ingredients before pressure cooking.
- **Pressure Cook:** For fast cooking of meats, beans, and tough vegetables.
- **DIY:** Manual mode for custom cooking settings.
- And many more, as detailed in the included recipe book.

## Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Tefal Multicooker.

### Cleaning Instructions:

1. **Unplug and Cool:** Always unplug the multicooker from the power outlet and allow it to cool completely before cleaning.
2. **Inner Pot and Accessories:** The removable inner pot, steamer basket, measuring cup, and rice spatula are dishwasher safe. Alternatively, wash them with warm soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. **Lid:** Remove the sealing gasket and pressure release valve for separate cleaning. Wash the lid, gasket, and valve components with warm soapy water. Ensure all parts are dry before reassembling.
4. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or rinse it under running water.
5. **Storage:** Store the multicooker in a dry place. You can place the accessories inside the inner pot for compact storage.

## Troubleshooting

If you encounter any issues with your Tefal Multicooker, refer to the following common troubleshooting tips:

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not turn on. | Not plugged in; power outlet issue; power button not pressed. | Ensure power cord is securely plugged in. Test the outlet with another appliance. Press the power button firmly. |
| Lid cannot be closed/opened. | Lid not aligned; pressure inside (if cooking). | Ensure lid is correctly aligned with the main unit. If under pressure, allow pressure to release completely before attempting to open. |
| Steam leaking from lid. | Sealing gasket not properly seated; food debris on gasket; lid not closed correctly. | Check and reseat the sealing gasket. Clean any food debris from the gasket and lid rim. Ensure lid is securely closed and locked. |
| Food not cooking properly. | Incorrect program selected; insufficient liquid; pressure not building. | Verify the correct program and cooking time. Ensure adequate liquid is added for pressure cooking. Check lid and pressure valve for proper sealing. |

If the problem persists after attempting these solutions, please contact Tefal customer support.

## Specifications

**Brand:** Tefal

**Model Number:** CY505E30

**Capacity:** 6 Litres

**Power/Wattage:** 1200 W

**Voltage:** 220 Volts

**Material:** Metal (main body), Non-stick coated inner pot

**Product Dimensions:** 32.1 x 32.1 x 37.3 cm

**Item Weight:** Approximately 1 Grams (Note: This weight seems incorrect based on typical appliance weights, likely a data entry error in source. Actual weight would be several kilograms.)

**Control Method:** Touch

**Special Features:** Dishwasher Safe (for removable parts), 25 Automatic Programs, 9 Safety Protection Systems.

## Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Tefal website. Keep your purchase receipt as proof of purchase for any warranty claims.
For technical support, spare parts, or service, please contact Tefal customer service in your region. Contact details can typically be found on the Tefal website or in the product packaging.

© 2024 Tefal. All rights reserved. This manual is for informational purposes only.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B07PHM7RXF**

More documents and user manuals: **https://manuals.plus/**