Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY AKB73616103 P12G10

YING RAY Replacement Remote Control AKB73616103 P12G10 User Manual

Introduction

This manual provides instructions for the YING RAY Replacement Remote Control, model AKB73616103 P12G10, designed for use with compatible Friedrich Air Conditioners. This remote control offers direct functionality without the need for complex programming.

Setup

Battery Installation

To begin using your replacement remote control, install two AAA batteries (not included) into the battery compartment located on the back of the remote. Ensure the batteries are inserted with the correct polarity (+/-) as indicated inside the compartment. Once batteries are installed, the remote is ready for immediate use without any additional programming.

Operating Instructions

The remote control features an intuitive button layout for easy operation of your Friedrich Air Conditioner. Point the remote directly at the air conditioner's receiver for optimal performance.



Image: YING RAY Replacement Remote Control AKB73616103 P12G10. This image displays the white remote control with a dark grey display screen showing '76°F' and fan speed bars. Below the screen are various grey buttons: a large oval 'Power' button, 'Temp' up and down arrows, 'Fan Speed', 'Timer', 'Mode', and 'Auto Swing' buttons.

- **Power Button:** Located below the display screen, this button turns the air conditioner on or off.
- **Temp ▲ / ▼ Buttons:** These triangular buttons adjust the desired temperature setting. The display shows the temperature in Fahrenheit.
- **Fan Speed Button:** Press this button to cycle through available fan speed settings (e.g., Low, Medium, High, Auto).
- **Timer Button:** Use this button to set or cancel the air conditioner's timer function. Refer to your air conditioner's manual for specific timer programming details.
- **Mode Button:** This button cycles through the various operating modes of the air conditioner, such as Cool, Fan, Dry, or Auto.
- **Auto Swing Button:** Activates or deactivates the automatic louver swing function, which helps distribute air evenly.

Display Information

The remote's LCD screen displays the current temperature setting in Fahrenheit and indicates the selected fan speed and operating mode.

Maintenance

Battery Replacement

Replace batteries when the remote's range decreases or if the display becomes dim or unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:** Ensure batteries are correctly installed and not depleted. Replace batteries if necessary. Check for any obstructions between the remote and the air conditioner's receiver.
- **Short operating range:** This typically indicates low battery power. Replace the batteries. Ensure you are within the maximum operating range of 10 meters and have a clear line of sight to the air conditioner.
- **Incorrect temperature display:** Verify that the remote is set to Fahrenheit display. This model is designed to display in Fahrenheit.

Specifications

Brand	YING RAY
Model	AKB73616103 P12G10
Display Unit	Fahrenheit
Maximum Range	10 Meters
Supported Devices	1 (Air Conditioner)
Controller Type	Button Control
Special Feature	Ergonomic Design

Warranty and Support

Specific warranty information for this replacement remote control is not provided in this manual. For warranty details, technical support, or further assistance, please contact the manufacturer, YING RAY, directly or refer to the product packaging and purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PLKHWWB

More documents and user manuals: **https://manuals.plus/**