Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 19031210-C

YING RAY Replacement Remote Control User Manual

Model: 19031210-C

Introduction

This manual provides instructions for the YING RAY Replacement Remote Control, designed for Midea Air Conditioner models RG51G/E and RG51H/E. This remote control is ready to use without any programming once batteries are installed.

Product Overview



Image 1: Front view of the YING RAY Replacement Remote Control. It features a white body with a dark grey control panel. The top section includes a digital display for temperature and mode indicators. Below the display are various buttons for controlling air conditioner functions such as power, mode, fan speed, temperature adjustment, and timer settings.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA 1.5V ordinary batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

Note: Batteries are not included with the remote control. The remote control does not require any programming and will function immediately after battery installation.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the air conditioner.

Button Functions

ON/OFF: Press to turn the air conditioner on or off.

MODE: Press to cycle through operating modes:

- **AUTO:** Automatically selects the operating mode based on the room temperature.
- **COOL:** Cools the room to the set temperature.
- **DRY:** Reduces humidity in the room.
- **HEAT:** Heats the room to the set temperature.

TEMP ▼ / ▲: Press to decrease (▼) or increase (▲) the set temperature.

FAN SPEED: Press to adjust the fan speed:

- **HIGH:** Maximum fan speed.
- **MED:** Medium fan speed.
- **LOW:** Minimum fan speed.

SWING: Activates or deactivates the automatic vertical swing of the air deflector.

SLEEP: Activates the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.

TIMER ON: Sets a timer for the air conditioner to turn on automatically.

TIMER OFF: Sets a timer for the air conditioner to turn off automatically.

AIR DIRECTION: Adjusts the horizontal direction of the airflow.

LED DISPLAY: Toggles the LED display on the air conditioner unit on or off.

TURBO: Activates the turbo mode for rapid cooling or heating.

RESET/LOCK: Used for resetting settings or locking the remote to prevent accidental changes. Consult your air conditioner's manual for specific usage.

Maintenance

Battery Replacement

Replace batteries when the remote control's range decreases or if the display becomes dim. Always replace both batteries at the same time with new AAA 1.5V batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

Troubleshooting

Remote not responding:

- Check if batteries are inserted correctly with the correct polarity.
- Replace old batteries with new ones.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Confirm you are within the effective operating range of the air conditioner.

Air conditioner not responding to specific commands:

- Verify that the air conditioner unit is powered on.
- Some functions may be specific to certain air conditioner models; refer to your air conditioner's original manual.

Specifications

Feature	Detail
Brand	YING RAY
Model Number	19031210-C
Compatible Air Conditioner Models	Midea RG51G/E, RG51H/E
Battery Type	2 x AAA 1.5V Ordinary Batteries (not included)
Special Feature	Ergonomic design, no programming required

Warranty and Support

For information regarding warranty coverage or technical support, please contact the seller or the manufacturer directly. Details can typically be found on your purchase receipt or the product packaging.
Manufacturer: ZHUHAI YINGRAY TRADING CO., LTD.

© 2024 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PM2Q1KL

More documents and user manuals: **https://manuals.plus/**