Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 1903140007

YING RAY Replacement Air Conditioner Remote Control User Manual

Model: 1903140007

Introduction

This document provides comprehensive instructions for the setup, operation, and maintenance of your YING RAY Replacement Air Conditioner Remote Control, model 1903140007. This remote is designed to be compatible with various York air conditioner models, including RAEA30FS-ADA, RAEA30FS-ADR, RAKA30FS-ADA, RAKA30FS-ADR, TLEA07FS-ADR, TLEA09FS-ADR, TLEA12FS-ADR, TLEA18FS-ADR, TLEA21FS-ADR, and TLEA24FS-ADR. It operates without requiring any programming.

Remote Control Overview



Figure 1: Front view of the YING RAY Replacement Air Conditioner Remote Control. It features a digital display at the top, showing temperature, mode, and fan speed. Below the display are various control buttons for functions such as power, mode selection, fan speed, temperature adjustment, air direction, timer settings, and special functions like Turbo and Economic modes.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two "AAA" 1.5V normal batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.

4. Close the battery compartment cover securely.

Note: Batteries are not included with the remote control. No programming is required; the remote is ready for use once batteries are installed.

Operating Instructions

Familiarize yourself with the buttons and their functions:

- **ON/OFF Button:** Press to turn the air conditioner unit on or off.
- **MODE Button:** Cycles through operating modes:
  - **AUTO:** The unit automatically selects the operating mode based on the room temperature.
  - **COOL:** Provides cooling.
  - **DRY:** Dehumidifies the air.
  - **HEAT:** Provides heating (if supported by your AC unit).
  - **FAN:** Operates only the fan, without cooling or heating.
- **FAN SPEED Button:** Adjusts the fan speed. Options typically include HIGH, MED (Medium), and LOW.
- **TEMP Buttons (Up/Down):** Used to increase or decrease the set temperature. The display shows temperature in Celsius.
- **AIR HORIZONTAL Button:** Controls the horizontal swing of the air deflector.
- **AIR VERTICAL Button:** Controls the vertical swing of the air deflector.
- **TIMER ON Button:** Sets a timer for the unit to turn on automatically.
- **TIMER OFF Button:** Sets a timer for the unit to turn off automatically.
- **VENT Button:** Activates or deactivates the ventilation function.
- **TURBO Button:** Activates a powerful mode for rapid cooling or heating.
- **ECONOMIC Button:** Activates an energy-saving mode.
- **RESET Button:** Resets the remote control settings.
- **LOCK Button:** Locks the remote control buttons to prevent accidental changes.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the display becomes dim or the remote's range decreases. Always replace both batteries simultaneously with new "AAA" 1.5V normal batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding	Dead or incorrectly inserted batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Ensure remote is within effective range of the AC unit's receiver.

Problem	Possible Cause	Solution
Display is dim or blank	Low battery power.	Replace batteries with new ones.
AC unit not responding to specific commands	Incorrect mode selected. AC unit does not support the function.	Verify the operating mode. Consult your AC unit's manual to confirm supported functions.

Specifications

Feature	Detail
Brand	YING RAY
Model Number	1903140007
Compatible AC Models	York RAEA30FS-ADA, RAEA30FS-ADR, RAKA30FS-ADA, RAKA30FS-ADR, TLEA07FS-ADR, TLEA09FS-ADR, TLEA12FS-ADR, TLEA18FS-ADR, TLEA21FS-ADR, TLEA24FS-ADR
Controller Type	Button Control
Max Number of Supported Devices	1
Battery Type	2 x "AAA" 1.5V Normal Batteries (not included)
Display	Celsius Temperature Display
Special Feature	Ergonomic Design

Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to the product packaging or contact the seller directly for warranty terms and conditions.

Customer Support

For further assistance or inquiries regarding your YING RAY Replacement Air Conditioner Remote Control, please contact the seller or manufacturer directly. Contact information may be available on the product packaging or through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PMJW91Z

More documents and user manuals: **https://manuals.plus/**