Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 1903140005

YING RAY Replacement Remote Control

INSTRUCTION MANUAL FOR YORK AIR CONDITIONERS MODEL 1903140005

Introduction

This manual provides detailed instructions for the proper setup, operation, and maintenance of your YING RAY replacement remote control, Model 1903140005. This remote is designed to be compatible with various York Air Conditioner models, including HLKA07FS-ADA, HLKA07FS-ADR, HLKA09FS-ADA, HLKA09FS-ADR, HLKA12FS-ADA, HLKA12FS-ADR, HLKA18FS-ADA, HLKA18FS-ADR, HLKA24FS-ADA, and HLKA24FS-ADR. Please read this manual thoroughly before use to ensure optimal performance and longevity of your remote control.

Product Overview



Image: Front view of the YING RAY replacement remote control, displaying its LCD screen and various control buttons. The screen shows 'SET TEMPERATURE (°C)', 'AUTO', 'COOL', 'DRY', 'HEAT', '24', 'FAN', 'HIGH', 'MED', 'LOW'. Buttons include MODE, FAN SPEED, ON/OFF, AIR HORIZONTAL, AIR VERTICAL, TIMER ON, TIMER OFF, VENT, RESET, LOCK, TURBO, ECONOMIC, and TEMP adjustment buttons.

The YING RAY replacement remote control features an intuitive layout for easy operation of your York air conditioner. Key components include:

- **LCD Display:** Shows current settings such as temperature, operating mode, fan speed, and timer status.
- **ON/OFF Button:** Powers the air conditioner on or off.
- **MODE Button:** Cycles through operating modes (Auto, Cool, Dry, Heat).

- **FAN SPEED Button:** Adjusts fan speed (High, Medium, Low).
- **TEMP Buttons:** Adjusts the set temperature up or down.
- **AIR HORIZONTAL/VERTICAL Buttons:** Controls the direction of the air flow.
- **TIMER ON/OFF Buttons:** Sets the automatic power-on or power-off time.
- **VENT Button:** Activates the ventilation function.
- **TURBO Button:** Engages rapid cooling or heating.
- **ECONOMIC Button:** Activates energy-saving mode.
- **RESET/LOCK Buttons:** Used for resetting settings or locking the remote.

Setup

Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA 1.5V normal batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control.

Initial Use

This replacement remote control is designed to work without any programming. Once batteries are correctly installed, it should function immediately with compatible York Air Conditioner models.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating.

- **Power On/Off:** Press the **ON/OFF** button to turn the air conditioner on or off.
- **Selecting Operating Mode:** Press the **MODE** button repeatedly to cycle through the available modes: AUTO, COOL, DRY, HEAT. The selected mode will be displayed on the LCD screen.
- **Adjusting Temperature:** Use the **TEMP** up (▲) or down (▼) buttons to set your desired temperature. The display shows temperature in Celsius.
- **Setting Fan Speed:** Press the **FAN SPEED** button to select between HIGH, MED (Medium), or LOW fan speeds.
- **Controlling Air Direction:**
  - Press **AIR HORIZONTAL** to adjust the horizontal airflow direction.
  - Press **AIR VERTICAL** to adjust the vertical airflow direction.
- **Using the Timer Function:**
  - Press **TIMER ON** to set a time for the air conditioner to automatically turn on.
  - Press **TIMER OFF** to set a time for the air conditioner to automatically turn off.
- **Activating Special Functions:**
  - Press **VENT** to activate the ventilation mode.
  - Press **TURBO** for quick cooling or heating.
  - Press **ECONOMIC** to engage the energy-saving operation.

- **Resetting Settings:** Press the **RESET** button (often a small recessed button requiring a pointed object) to restore default settings.
- **Locking the Remote:** Press the **LOCK** button to prevent accidental changes to settings. Press again to unlock.

Maintenance

Battery Replacement

When the remote control's display becomes dim or its response time slows, it is time to replace the batteries. Follow the battery installation steps outlined in the 'Setup' section. Always replace both batteries simultaneously with new AAA 1.5V normal batteries. Do not mix old and new batteries or different types of batteries.

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Confirm the remote is within the effective operating range of the air conditioner.
- **Display is dim or blank:**
  - Replace the batteries.
- **Air conditioner not responding to specific functions:**
  - Ensure the remote control is compatible with your specific York Air Conditioner model.
  - Some advanced functions may vary or not be supported by all air conditioner models.

Specifications

- **Model:** 1903140005
- **Brand:** YING RAY
- **Power Source:** 2 x AAA 1.5V Normal Batteries (not included)
- **Display:** Celsius temperature display
- **Compatibility:** Designed for various York Air Conditioner models, including HLKA07FS-ADA, HLKA07FS-ADR, HLKA09FS-ADA, HLKA09FS-ADR, HLKA12FS-ADA, HLKA12FS-ADR, HLKA18FS-ADA, HLKA18FS-ADR, HLKA24FS-ADA, HLKA24FS-ADR.
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

Warranty and Support

For information regarding warranty coverage or technical support, please refer to the documentation provided with your purchase or contact the retailer directly. Keep your purchase receipt as proof of purchase.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PNHFT6D

More documents and user manuals: **https://manuals.plus/**