YING RAY 190316003-C

YING RAY Air Conditioner Remote Control User Manual

Model: 190316003-C

Introduction

This user manual provides detailed instructions for the operation and maintenance of your YING RAY replacement remote control for Midea Air Conditioners. This remote is designed to be compatible with various Midea models, including MPPD-12CRN1-BH9, MPPD-14CRN1-BH9, MPPD-12CRN1-BI0, MPPD-12HRN1-BH9, MPPD-14HRN1-BH9, MPPD-12ER-NB4, and MYPD-12CRN1-QB6. Please read this manual thoroughly before use to ensure proper functionality and extend the lifespan of your remote control.

Product Overview



Image: Front view of the YING RAY replacement remote control for Midea Air Conditioners. It features a white body with a dark grey control panel. The top section includes an LCD display for temperature and mode indicators. Below the display are various buttons for mode selection, temperature adjustment, fan speed, timer functions, and other controls. Key buttons like ON/OFF and SLEEP are highlighted in red.

Setup

Battery Installation

The remote control requires two "AAA" 1.5V ordinary batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or in the direction indicated by an arrow to open it.
3. Insert two "AAA" batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.

Operating Instructions

This section describes the functions of each button on the remote control.

Button Functions

- **ON/OFF Button:** Press to turn the air conditioner unit on or off. This button is typically red.
- **TEMP ▲ / ▼ Buttons:** Use these buttons to adjust the desired temperature setting. The display shows temperature in Celsius only.
- **MODE Button:** Press repeatedly to cycle through the available operating modes:
  - **AUTO:** The unit automatically selects the operating mode (Cool, Dry, Heat) based on the room temperature.
  - **COOL:** Operates in cooling mode.
  - **DRY:** Operates in dehumidifying mode.
  - **HEAT:** Operates in heating mode.
- **FAN SPEED Button:** Press to cycle through fan speed settings:
  - **HIGH:** Maximum fan speed.
  - **MED:** Medium fan speed.
  - **LOW:** Minimum fan speed.
- **SWING Button:** Activates or deactivates the automatic vertical swing of the air conditioner's louver, distributing air more evenly.
- **SLEEP Button:** Activates the sleep mode, which adjusts temperature and fan speed automatically for comfortable sleep and energy saving.
- **TIMER ON Button:** Press to set a time for the air conditioner to automatically turn on. Use the TEMP buttons to adjust the time.
- **TIMER OFF Button:** Press to set a time for the air conditioner to automatically turn off. Use the TEMP buttons to adjust the time.
- **AIR DIRECTION Button:** Adjusts the horizontal direction of the airflow.
- **LED DISPLAY Button:** Toggles the LED display on the air conditioner unit on or off.
- **TURBO Button:** Activates the turbo mode for rapid cooling or heating, operating at maximum fan speed and capacity.
- **RESET / LOCK Buttons:** These buttons are typically used for resetting the remote's settings or locking the buttons to prevent accidental changes. Refer to your air conditioner's main manual for specific functions if these are not immediately apparent.

Maintenance

Cleaning the Remote Control

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical sprays, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control's range decreases or the display becomes dim. Always replace both batteries at the same time with new "AAA" 1.5V batteries. Dispose of used batteries responsibly according to local regulations.

Troubleshooting

If you experience issues with your remote control, refer to the following common troubleshooting steps:

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range of the air conditioner.
- **Display is dim or blank:**
  - This usually indicates low battery power. Replace the batteries.
- **Air conditioner not responding to specific commands:**
  - Ensure the remote control is pointed directly at the air conditioner's receiver.
  - Verify that the air conditioner unit is powered on and not in a standby mode that prevents remote input.
  - Some functions may be specific to certain air conditioner models; consult your air conditioner's original manual.

Specifications

Attribute	Detail
Brand	YING RAY
Model Number	190316003-C
Compatible Devices	Midea Air Conditioners (MPPD-12CRN1-BH9, MPPD-14CRN1-BH9, MPPD-12CRN1-BI0, MPPD-12HRN1-BH9, MPPD-14HRN1-BH9, MPPD-12ER-NB4, MYPD-12CRN1-QB6)
Battery Type	2 x "AAA" 1.5V Ordinary Batteries
Display Temperature Unit	Celsius Only

Warranty and Support

For any questions, technical support, or warranty inquiries regarding your YING RAY remote control, please contact the seller or manufacturer directly through the platform where the purchase was made. Please retain your proof of purchase

for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question