Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 1903140008

YING RAY Replacement Remote Control for York Air Conditioners

MODEL: 1903140008

Introduction

This manual provides instructions for the setup, operation, and maintenance of your YING RAY replacement remote control for York Air Conditioners. This remote is compatible with various York models, including TLKA07FS-ADR, TLKA09FS-ADR, TLKA12FS-ADR, TLKA18FS-ADR, TLKA21FS-ADR, TLKA24FS-ADR, and TLKA28FS-ADR.

The remote control is designed to function immediately after battery installation, requiring no complex programming.

Product Overview

The YING RAY remote control offers a straightforward interface for managing your compatible York air conditioner. Its ergonomic design ensures comfortable handling, and the clear display provides essential information at a glance.



Image of the YING RAY replacement remote control for York Air Conditioners. The remote is white with a black display screen at the top showing 'SET TEMPERATURE (°C)', 'AUTO', 'COOL', 'DRY', 'HEAT', '24', 'FAN', 'HIGH', 'MED', 'LOW'. Below the screen are various blue and orange buttons for functions like MODE, FAN SPEED, ON/OFF, AIR HORIZONTAL, AIR VERTICAL, TIMER ON, TIMER OFF, VENT, RESET, LOCK, TEMP (temperature up/down), TURBO, and ECONOMIC.

Setup

Battery Installation

The remote control requires two "AAA" 1.5V normal batteries (not included).

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
3. Close the battery compartment cover securely.

Note: The remote control is ready for use immediately after battery installation; no programming is required.

Operating Instructions

Basic Operation

- **ON/OFF Button:** Press this orange button to turn the air conditioner on or off.
- **MODE Button:** Press to cycle through available operating modes: AUTO, COOL, DRY, HEAT. The selected mode will be displayed on the screen.
- **TEMP Buttons (Up/Down):** Use the blue up and down buttons labeled "TEMP" to adjust the desired temperature. The temperature is displayed in Celsius.
- **FAN SPEED Button:** Press to cycle through fan speed settings: HIGH, MED (Medium), LOW.

Advanced Functions

- **AIR HORIZONTAL Button:** Activates or adjusts the horizontal air swing function.
- **AIR VERTICAL Button:** Activates or adjusts the vertical air swing function.
- **TIMER ON Button:** Sets a timer for the air conditioner to turn on automatically. Refer to your air conditioner's main manual for specific timer setting procedures if needed.
- **TIMER OFF Button:** Sets a timer for the air conditioner to turn off automatically.
- **VENT Button:** Activates the ventilation function.
- **TURBO Button:** Engages a high-power mode for rapid cooling or heating.
- **ECONOMIC Button:** Activates an energy-saving mode.
- **RESET Button:** Used to reset certain settings. Consult your air conditioner's manual for specific reset functions.
- **LOCK Button:** Locks the remote control buttons to prevent accidental changes. Press again to unlock.

Maintenance

Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.

Battery Replacement

Replace batteries when the display becomes dim or the remote control's operational range decreases. Always replace both batteries simultaneously with new AAA 1.5V normal batteries. Remove batteries if the remote will not be used for an extended period (e.g., one month or more) to prevent potential leakage and damage.

Troubleshooting

Common Issues and Solutions

Problem	Solution
Remote not responding	Check battery polarity. Replace batteries if they are old or depleted. Ensure there are no obstructions between the remote and the air conditioner's receiver.
Display is dim or blank	Replace batteries.
Air conditioner not responding to commands	Verify the remote control is pointed directly at the air conditioner's infrared receiver. Ensure the air conditioner is powered on. Check for any strong light sources or electronic devices that might cause interference.
Temperature displayed incorrectly	This remote displays temperature in Celsius. Ensure your air conditioner is set to the correct unit if it has such a setting.

If issues persist after attempting these solutions, consult the original air conditioner's manual or contact customer support for further assistance.

Specifications

- **Model:** 1903140008
- **Compatible Air Conditioner Models:** TLKA07FS-ADR, TLKA09FS-ADR, TLKA12FS-ADR, TLKA18FS-ADR, TLKA21FS-ADR, TLKA24FS-ADR, TLKA28FS-ADR
- **Power Supply:** 2 x AAA 1.5V Batteries (not included)
- **Display Unit:** Celsius
- **Special Feature:** Ergonomic design
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

Warranty and Support

For warranty information or technical support regarding your YING RAY replacement remote control, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PRTNQRK

More documents and user manuals: **https://manuals.plus/**