Passion-Electro DVX267/5.1

Passion-Electro Replacement Remote Control for MAJESTIC DVX267/5.1 User Manual

Model: DVX267/5.1

1. Introduction

This manual provides instructions for the proper use and maintenance of your Passion-Electro replacement remote control, specifically designed for the MAJESTIC DVX267/5.1 device. This remote control offers full functionality similar to the original unit without requiring any programming. Simply insert batteries to begin operation.

2. Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Avoid exposing the remote control to direct sunlight, heat, or moisture.
- Do not attempt to disassemble or modify the remote control.

3. Setup

3.1 Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries (not included).

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: No programming is required. The remote is ready for use once batteries are installed.



Image: Rear view of the remote control, highlighting the battery compartment cover. This is where the AAA batteries are inserted.

4. Operating Instructions

This replacement remote control is designed to replicate the full functionality of your original MAJESTIC DVX267/5.1 remote. Point the remote control directly at your MAJESTIC DVX267/5.1 device for optimal performance.

4.1 Key Functions Overview



Image: Top-down view of the remote control, displaying the layout of all buttons including power, mute, number pad, navigation, and colored function keys.

- **POWER (Red Button):** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **Number Pad (0-9):** For direct channel selection or inputting numbers.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels.
- **MENU:** Accesses the main menu of the device.
- **EXIT:** Exits the current menu or function.
- **INFO:** Displays information about the current program or content.
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions displayed on your device's screen.
- **PLAY, PAUSE, STOP, REW, FF:** Media playback controls.



Image: Angled front view of the remote control, focusing on the navigation cluster, media playback buttons, and colored function keys.



Image: Another angled view of the remote control, showing the power button, mute button, and a portion of the number pad.

5. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new ones, ensuring correct polarity (+/-).
Remote control range is poor.	Weak batteries; Obstruction between remote and device.	Replace batteries. Ensure a clear line of sight to the device's IR receiver.
Specific buttons not responding.	Dirty contacts; Remote control malfunction.	Clean the remote control. If problem persists, the remote may be faulty.

7. Specifications

- **Brand:** Passion-Electro
- **Model Compatibility:** MAJESTIC DVX267/5.1
- **Battery Type:** 2 x AAA (LR03) 1.5V (not included)
- **Special Feature:** Ergonomic design
- **Programming:** Not required

8. Warranty and Support

This Passion-Electro replacement remote control is designed for reliable performance. For any issues or support inquiries, please contact your retailer or the Passion-Electro customer service. Please refer to your purchase documentation for specific warranty terms and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question