Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro NDVX-2502

Passion-Electro Replacement Remote Control for NORTEK NDVX-2502

Model: NDVX-2502

Introduction

This manual provides instructions for the Passion-Electro Replacement Remote Control, designed specifically for the NORTEK NDVX-2502 device. This remote offers full functionality comparable to your original remote control. It is a dedicated replacement, not a generic universal remote, and requires no programming. Simply install the batteries to begin operation.

Setup: Battery Installation

Follow these steps to install batteries into your remote control:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries for optimal performance.



Image: Rear view of the remote control, highlighting the battery compartment cover. This is where you will insert the two AAA batteries.

Operating Instructions

This replacement remote control is designed to function immediately with your NORTEK NDVX-2502 device without any prior programming. Ensure the remote is pointed directly at the infrared receiver of your device.

Key Functions Overview



Image: Front view of the remote control, displaying the full array of buttons for various functions.

- **POWER (Red Button):** Turns the device on or off.
- **MUTE:** Silences or restores audio.

- **Numeric Keypad (0-9):** For direct channel selection or inputting numbers.
- **Volume Up/Down (V+/V-):** Adjusts the audio volume.
- **Channel Up/Down (P+/P-):** Changes channels sequentially.
- **Directional Pad (Up, Down, Left, Right) and OK:**Navigates menus and confirms selections.
- **MENU:** Accesses the main menu of your device.
- **EXIT:** Exits the current menu or function.
- **SOURCE:** Selects input sources (e.g., TV, HDMI, AV).
- **INFO:** Displays information about the current program or content.
- **BACK:** Returns to the previous screen or menu.
- **Colored Buttons (Red, Green, Yellow, Blue):**These buttons typically correspond to specific functions displayed on-screen within menus or applications.

For specific functions related to your NORTEK NDVX-2502 device, refer to its original user manual, as the remote replicates those functions.

Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

Troubleshooting

Remote is not responding:

- Ensure the remote is pointed directly at the infrared sensor of your NORTEK NDVX-2502 device.
- Check if the batteries are inserted correctly with the correct polarity (+/-).
- Replace the batteries with new AAA 1.5V batteries.
- Remove any obstructions between the remote and the device.

Some buttons are not working:

- This remote is designed to replicate the original remote's functions. Verify if the specific function was available on your original remote.
- Ensure the batteries have sufficient power. Replace them if necessary.

Remote control range is reduced:

- Replace the batteries with new ones.
- Ensure there are no strong light sources (like direct sunlight or fluorescent lights) interfering with the infrared signal.

Specifications

Feature	Detail
Brand	Passion-Electro
Model Compatibility	NORTEK NDVX-2502
Connectivity Technology	Infrared
Battery Type	2 x AAA 1.5V (not included)
Item Weight	Approximately 100 grams
Programming Required	No

Warranty and Support

For warranty information or technical support regarding your Passion-Electro Replacement Remote Control, please refer to the seller's documentation or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PVNXGP6

More documents and user manuals: **https://manuals.plus/**