Passion-Electro MULTIBOXULTRA

Passion-Electro Replacement Remote Control User Manual

For MEDIASTAR MULTIBOXULTRA

1. Introduction

This manual provides instructions for the Passion-Electro replacement remote control designed for use with MEDIASTAR MULTIBOXULTRA devices. This specialized remote control is engineered to replicate all functions of your original remote without requiring any programming.

Please note that while this remote is a direct replacement, the physical button layout may vary slightly from your original remote depending on the specific model and brand of the original unit. Refer to the images provided for the typical layout of this replacement remote.

2. Safety Information

- Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Dispose of used batteries according to local regulations.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two (2) 1.5V AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Image: Back view of the remote control, illustrating the battery compartment cover.



Image: Bottom view of the remote control, showing the area where the battery compartment opens.

Once batteries are installed, the remote control is ready for immediate use with your MEDIASTAR MULTIBOXULTRA device. No additional programming is required.

4. Operating Instructions

This replacement remote control is designed to function identically to your original MEDIASTAR MULTIBOXULTRA remote. Simply point the remote at your device and press the desired function button.



Image: Front view of the Passion-Electro replacement remote control, displaying all buttons.



Image: Angled view of the remote control, showing the top buttons including Power, Mute, TV, SAT, DVD, and AUX.



Image: Another angled view of the remote control, focusing on the navigation pad and playback buttons.



Image: Side profile view of the remote control, illustrating its ergonomic design.

Key Functions:

- **Power Button:** Turns your MEDIASTAR MULTIBOXULTRA device on or off.
- **Number Buttons (0-9):** For direct channel selection or inputting numerical values.
- **Volume Up/Down:** Adjusts the audio level.
- **Channel Up/Down:** Navigates through channels.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu/Exit Buttons:** Access and exit device menus.
- **Playback Controls:** (e.g., Play, Pause, Stop, Fast Forward, Rewind) for media playback.
- **Input/Source:** Switches between different input sources (e.g., TV, SAT, DVD, AUX).

5. Maintenance

- Clean the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Avoid exposing the remote control to extreme temperatures, direct sunlight, or moisture.
- Do not drop or subject the remote control to strong impacts.

6. Troubleshooting

Remote Control Not Responding:

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-).
- **Replace Batteries:** If the batteries are old or depleted, replace them with new 1.5V AAA batteries.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and your MEDIASTAR MULTIBOXULTRA device. Obstructions can block the infrared signal.
- **Distance:** Make sure you are within the effective operating range of the device.

Specific Buttons Not Working:

- This remote is designed to mimic the original. If a specific function is not working, verify that the corresponding button on your original remote (if available) performed that function for your specific MEDIASTAR MULTIBOXULTRA model.
- Clean the remote control buttons and surrounding areas to ensure no debris is obstructing button presses.

7. Specifications

Feature	Detail
Brand	Passion-Electro
Model Compatibility	MEDIASTAR MULTIBOXULTRA
Color	Black
Batteries Required	2 x 1.5V AAA (LR03)
Programming	Not required
Manufacturer	Passion-Electro

© 2023 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question