Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro Q.1324

Passion-Electro Replacement Remote Control for QILIVE Q.1324

User Manual

Introduction

This manual provides instructions for the Passion-Electro replacement remote control, specifically designed for QILIVE Q.1324 televisions. This is a specialized replacement remote, not a universal remote, and is pre-programmed to function identically to your original QILIVE Q.1324 remote control. No additional programming is required. Simply insert the batteries to begin use.

Setup

1. Battery Installation

The remote control requires two 1.5V AAA (LR03) batteries. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the remote control with the battery compartment. This shows the area where batteries are inserted.

After installing the batteries, the remote control is ready for immediate use with your QILIVE Q.1324 television.

Operating Instructions

This replacement remote control provides access to all functions of your original QILIVE Q.1324 remote. Point the remote control directly at your television's infrared receiver for optimal performance.



Image: Front view of the remote control. This image displays the layout of the buttons, including power, channel, volume, and navigation controls.

- **Power Button:** Press to turn the television on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Channel Up/Down:** Navigate through channels sequentially.
- **Volume Up/Down:** Adjust the sound level.
- **Mute Button:** Temporarily silence the television audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Menu/Settings Button:** Access the television's main menu or settings.
- **Source/Input Button:** Switch between different input sources (e.g., HDMI, AV).
- **Colored Buttons (Red, Green, Yellow, Blue):** These buttons typically correspond to specific functions within certain menus or applications, as indicated on your television screen.

An LED indicator on the remote control will flash with each button press, confirming that a signal is being sent.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or the LED indicator no longer flashes consistently. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Ensure the remote is pointed directly at the television's infrared receiver.
  - Check if the LED indicator flashes when a button is pressed. If not, replace the batteries.
  - Verify that the batteries are inserted with the correct polarity (+/-).
- **Some buttons not working:**
  - This may indicate low battery power. Try replacing the batteries.
  - Ensure there is no obstruction between the remote and the TV.
  - Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris.
- **Remote works intermittently:**
  - This is often a sign of weak batteries. Replace them.
  - Ensure no other devices are interfering with the infrared signal.

Specifications

- **Product Type:** Replacement Remote Control
- **Brand:** Passion-Electro
- **Compatibility:** QILIVE Q.1324 Televisions
- **Battery Type:** 2 x AAA (LR03) 1.5V batteries (not included)
- **Color:** Black
- **Manufacturer:** Passion-Electro
- **Country of Origin:** China

Warranty and Support

This product is a new replacement remote control. For any issues not covered in this manual or for warranty inquiries, please contact your retailer or the manufacturer, Passion-Electro, directly. Please refer to your purchase documentation for specific warranty terms and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PVNYB9R

More documents and user manuals: **https://manuals.plus/**