Passion-Electro TXV-3250D

Passion-Electro Replacement Remote Control for TURBOX TXV-3250D

User Manual

Introduction

This manual provides comprehensive instructions for the Passion-Electro replacement remote control, specifically designed for the TURBOX TXV-3250D television model. This is a dedicated replacement remote, not a generic universal remote, ensuring full compatibility and functionality with your device.

No programming is required. Simply insert the batteries, and the remote control is ready for immediate use. It functions identically to your original remote, providing access to all standard features and controls.



Image: Front view of the Passion-Electro replacement remote control.

Product Features

- Dedicated replacement remote for TURBOX TXV-3250D.
- No programming or setup required.
- Functions identically to the original remote control.
- Features an LED indicator for operational feedback.
- Durable construction for reliable use.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new batteries for optimal performance.



Image: Back view of the remote control, illustrating the battery compartment.

Operating Instructions

Basic Operation

Once batteries are installed, the remote control is ready for use. Point the remote directly at your TURBOX TXV-3250D television. The buttons on this replacement remote are designed to correspond to the functions of your original remote control.

- **Power Button:** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Volume Up/Down:** Adjust the sound level.
- **Channel Up/Down:** Change channels sequentially.
- **Mute Button:** Silence the TV audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **Menu/Settings:** Access the TV's main menu or settings.
- **Source/Input:** Switch between different input sources (HDMI, AV, etc.).

Refer to your television's user manual for specific functions of advanced buttons if needed.



Image: Front view of the remote control, highlighting various buttons for operation.

Care and Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Remove old batteries promptly to prevent leakage.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent potential damage from battery leakage.
- **Environment:** Avoid exposing the remote to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting Guide

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Specific buttons not working:**
  - This remote is designed to replicate the original. If a specific function is not working, ensure your TV supports that function or that the button on the original remote performed that action.
  - Clean the remote control, as dirt or debris might be interfering with button contacts.

Technical Specifications

Specification	Detail

Specification	Detail
Brand	Passion-Electro
Model Compatibility	TURBOX TXV-3250D
Color	Black
Battery Type	2 x AAA (1.5V)
Maximum Range	10 Meters
Programming Required	No

Warranty and Returns

This product is typically covered by a 30-day refund or replacement policy from the date of purchase. Please refer to your purchase receipt or contact your retailer for specific warranty terms and conditions.

Customer Support

For any questions, issues, or assistance with your Passion-Electro replacement remote control, please contact the retailer from whom you purchased the product. They will be able to provide further support and guidance.

© 2026 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question