Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro TE28275B35TXB

Passion-Electro Replacement Remote Control User Manual

Model: **TE28275B35TXB**
Brand: **Passion-Electro**

Introduction

This manual provides comprehensive instructions for the Passion-Electro replacement remote control, specifically designed for TELEFUNKEN TE28275B35TXB television models. This remote is a direct replacement and offers full functionality without the need for complex programming. Please read this manual carefully to ensure proper use and longevity of your remote control.



Image 1: Front view of the Passion-Electro replacement remote control. This image displays the full layout of buttons, including power, mute, number pad, navigation, and various function keys.

Setup

1. Inserting Batteries

The remote control requires two 1.5V AAA batteries (not supplied). Follow these steps to insert them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image 2: Bottom view of the remote control, illustrating the location of the battery compartment cover. This is where AAA batteries are inserted.

2. No Programming Required

This Passion-Electro remote control is pre-programmed for the TELEFUNKEN TE28275B35TXB model. No additional setup or programming steps are necessary. Once batteries are correctly inserted, the remote is ready for immediate use with your compatible television.

Operating Instructions

The remote control provides access to all standard functions of your TELEFUNKEN TE28275B35TXB television. The button layout is designed to mimic the original remote for ease of use.

Basic Functions

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **VOL +/-:** Adjusts the volume level.
- **CH +/- (or P +/-):** Changes the TV channel.
- **Number Pad (0-9):** Directly selects channels or inputs numerical data.

- **SOURCE:** Selects input sources (e.g., HDMI, AV).
- **MENU:** Opens the TV's main menu.
- **EXIT:** Closes the current menu or on-screen display.
- **Navigation Buttons (Up, Down, Left, Right) & OK:** Used to navigate menus and confirm selections.

Advanced Functions

Depending on your TV model, the following buttons may provide additional functionality:

- **TV, SAT, DVD, AUX:** May switch to specific device modes or inputs if your TV supports them.
- **SHIFT:** May activate secondary functions of certain buttons.
- **SIZE, SETUP, BURST:** Specific functions that vary by TV model, often related to picture settings or advanced configurations.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the TV.
- **TWDTY, INFO, EPG, FAV:** Accesses specific TV features like Teletext, Information display, Electronic Program Guide, or Favorite channels.
- **NETTV, SMART:** Buttons for accessing smart TV features or internet-connected services.
- **Colored Buttons (Red, Green, Yellow, Blue):** Often used for specific functions within smart TV apps or interactive services.
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** For controlling media playback from connected devices or smart TV apps.

Note: The exact functionality and labeling of some buttons may vary slightly based on the specific firmware version of your TELEFUNKEN TE28275B35TXB television.



Image 3: Angled view of the remote control, providing a clearer perspective on the arrangement and labeling of various function buttons.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or the LED indicator (if present) does not light up consistently. Always replace both AAA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

Storage

When not in use for extended periods, it is recommended to remove the batteries to prevent leakage, which can damage the remote control. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Point the remote directly at the TV.
- **Specific buttons not working:**
  - This may indicate a dirty contact under the button. Try cleaning the remote as described in the Maintenance section.
  - Ensure the TV is in the correct mode (e.g., TV mode for channel changes).
- **LED indicator not lighting up:**
  - This usually indicates dead or incorrectly inserted batteries. Replace them.

If the issue persists after following these steps, please contact the seller or manufacturer for further assistance.

Specifications

Brand: Passion-Electro

Manufacturer: Passion-Electro

Model: TE28275B35TXB (Replacement for TELEFUNKEN)

Item Weight: Approximately 100 grams

Batteries: 2 x AAA (1.5V, LR03) - Not included

Compatible Devices: Television (Specifically TELEFUNKEN TE28275B35TXB)

Additional Features: Direct replacement, no programming required.



Image 4: Side profile of the remote control, showcasing its ergonomic design and slim form factor.

Warranty and Support

Warranty Information

For specific warranty details regarding your Passion-Electro replacement remote control, please refer to the documentation provided at the time of purchase or contact your retailer directly. As a new product, it is typically covered by standard consumer guarantees.

Customer Support

If you encounter any issues that cannot be resolved using the troubleshooting steps in this manual, or if you require further assistance, please contact Passion-Electro customer support or the seller from whom you purchased the product. Provide your product model (TE28275B35TXB) and a detailed description of the problem to facilitate quicker resolution.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PXS9W7D

More documents and user manuals: **https://manuals.plus/**