Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro SLE-1945DM4

Passion-Electro Replacement Remote Control for SENCOR SLE-1945DM4 User Manual

Model: SLE-1945DM4

Introduction

This manual provides instructions for the Passion-Electro Replacement Remote Control designed for the SENCOR SLE-1945DM4 television. This specialized remote control offers full functionality comparable to the original SENCOR remote, without the need for complex programming. Simply insert the batteries, and it is ready for use.

Package Contents

- 1 x Passion-Electro Replacement Remote Control for SENCOR SLE-1945DM4

Note: Batteries are not included and must be purchased separately.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA (LR03) 1.5V batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Close the battery compartment cover securely.



Image: Back view of the remote control, showing the battery compartment cover. This is where you will insert the AAA batteries.

No programming is required. The remote control is ready for use immediately after battery installation.

Operating Instructions

This replacement remote control is designed to replicate the functions of your original SENCOR SLE-1945DM4 TV remote. Point the remote control directly at your television's infrared receiver.

Key Functions Overview



Image: Front view of the remote control, displaying the power button, channel controls, volume controls, and navigation buttons.

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** Selects channels directly.
- **Channel Up/Down:** Navigates through channels sequentially.
- **Volume Up/Down:** Adjusts the sound level.
- **Mute Button:** Silences the TV audio.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used for menu navigation and selection.
- **Menu Button:** Accesses the TV's main menu.
- **Exit Button:** Exits current menu or function.

- **Input/Source Button:** Changes the input source (HDMI, AV, etc.).
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality depends on the TV model and current on-screen content.
- **Info/EPG Button:** Displays program information or Electronic Program Guide.



Image: A closer front view of the remote control, showing the numerical keypad and additional function buttons like Mute, Power, and Menu.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Environment:** Avoid exposing the remote control to extreme temperatures, direct sunlight, or high humidity.

Troubleshooting

Problem	Possible Cause	Solution
Remote control not working.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity (+/-).
Remote control range is poor.	Weak batteries or obstruction between remote and TV.	Replace batteries. Ensure there are no objects blocking the line of sight to the TV's IR receiver.
Specific buttons not responding.	Button malfunction or TV not supporting the function.	Ensure the button is clean and not stuck. Verify if your SENCOR SLE-1945DM4 TV model supports that specific function.

Specifications

Feature	Detail
Model	SLE-1945DM4 (Replacement)
Brand	Passion-Electro
Compatibility	SENCOR SLE-1945DM4 TV
Power Source	2 x AAA (LR03) 1.5V Batteries (not included)
Color	Black
Programming Required	No
Manufacturer	Passion-Electro
Country of Origin	China

Important Safety Information

- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control is not used for a long period.
- Keep batteries out of reach of children.
- Dispose of used batteries according to local regulations.

© 2023 Passion-Electro. All rights reserved.
For support, please contact your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PXSBT5L

More documents and user manuals: **https://manuals.plus/**