Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Passion-Electro LE-32Z1TS

User Manual: Replacement Remote Control

For SMART-TECH LE-32Z1TS Televisions

Brand: Passion-Electro

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Passion-Electro Replacement Remote Control, specifically designed for SMART-TECH LE-32Z1TS television models. This remote control is engineered to replicate the full functionality of your original remote without requiring any complex programming or setup procedures.

Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your remote control.



Figure 1.1: Front view of the Passion-Electro Replacement Remote Control, showing all buttons and the brand logo at the bottom.

2. Setup

2.1 Battery Installation

Your Passion-Electro Replacement Remote Control requires two (2) AAA 1.5V batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.



Figure 2.1: Rear view of the remote control, highlighting the battery compartment cover.



Figure 2.2: Side view of the remote control, illustrating the battery compartment opening.

2.2 Initial Use

This replacement remote control is pre-programmed for SMART-TECH LE-32Z1TS televisions. No additional programming or code entry is required. Once batteries are installed, the remote is ready for immediate use.

3. Operating the Remote Control

The layout of this replacement remote control is designed to be intuitive and familiar, mirroring the functionality of your original SMART-TECH remote. Below is a general guide to the main button functions:



Figure 3.1: Angled view of the remote control, providing a clear perspective of the button layout.



Figure 3.2: Top-down view of the remote control, detailing the arrangement of all functional buttons.

- **Power (Red Button):** Turns the television on or off.
- **Mute:** Mutes or unmutes the television sound.
- **TV/SAT/DVD/AUX:** Selects the input source (e.g., TV, Satellite, DVD player, Auxiliary input).
- **Menu:** Opens the television's main menu.
- **Exit:** Exits the current menu or on-screen display.
- **Shift:** Used for accessing secondary functions of certain buttons (if applicable).
- **Number Buttons (0-9):** Directly enters channel numbers.
- **Navigation (Up/Down/Left/Right Arrows):** Navigates through menus and options.
- **OK:** Confirms selections in menus.
- **Back:** Returns to the previous screen or menu.
- **Sleep:** Sets a sleep timer for the television.
- **TWDTY:** Specific function button (refer to your TV's manual for details).
- **Info:** Displays information about the current program or input.
- **EPG (Electronic Program Guide):** Opens the TV's program guide.
- **Fav:** Accesses favorite channels list.
- **NETTV:** Direct access to Smart TV applications or internet features.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the TV menu or application.

4. Maintenance

4.1 Cleaning

To clean your remote control, gently wipe the surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

4.2 Battery Care

If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent potential leakage, which can damage the remote's circuitry. Dispose of used batteries responsibly according to local regulations.

4.3 Storage

Store the remote control in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity. Avoid dropping the remote or exposing it to excessive force, which can cause internal damage.

5. Troubleshooting

- **Remote Control Not Responding:**
  - Ensure batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the television's infrared receiver.
  - Ensure you are within the effective operating range (up to 10 meters).
- **Specific Buttons Not Working:**
  - This remote is designed to replicate the original. If a specific function is not working, verify that your television model supports that function with its original remote.
  - Clean the remote control surface, especially around the non-working button, to ensure no debris is interfering.
- **No Programming Required:**
  - This remote control is a direct replacement and does not require any programming codes or setup procedures. If you are prompted for a code, ensure you are using the correct remote for your SMART-TECH LE-32Z1TS TV.

6. Specifications

Feature	Detail
Brand	Passion-Electro
Model Compatibility	SMART-TECH LE-32Z1TS
Color	Black
Battery Type	2 x AAA 1.5V (not included)
Maximum Range	10 Meters
Programming Required	No
Country of Origin	China

7. Warranty and Support

This Passion-Electro Replacement Remote Control is a new product designed to offer functionality similar to your original

remote control. It is typically shipped within 48 hours of order confirmation.

For any issues not covered in this manual or for further assistance, please contact your retailer or the manufacturer, Passion-Electro, through their official support channels. Please have your product model number (LE-32Z1TS) and purchase details ready when contacting support.

© 2024 Passion-Electro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PYWCHN1

More documents and user manuals: **https://manuals.plus/**