Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ENEGON EN-EL15

ENEGON EN-EL15C Battery & Smart Dual Charger Kit User Manual

Model: EN-EL15 | Brand: ENEGON

Introduction Safety Information Package Contents Compatibility Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the ENEGON EN-EL15C Battery & Smart Dual Charger Kit. This kit provides reliable power solutions for your Nikon digital cameras, ensuring extended shooting and recording times. Please read this manual thoroughly before use to ensure proper operation and safety.



Image: ENEGON EN-EL15C batteries in the smart dual charger, powered by a portable power bank.

2. Safety Information

To prevent damage, injury, or malfunction, observe the following safety precautions:

- Do not disassemble, open, or shred the battery pack.
- Do not expose the battery to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit a battery. Do not store batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by other metal objects.
- Do not subject batteries to mechanical shock.
- In the event of a battery leaking, do not allow the liquid to come into contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Keep batteries out of the reach of children.
- Seek medical advice immediately if a battery has been swallowed.
- The battery cell is UL certified and features four layers of protection: over-charging, short-circuit, high-temperature,

and surge protection.



Image: Smart IC Chip with multiple safety protections.

3. Package Contents

The ENEGON EN-EL15C Battery & Smart Dual Charger Kit includes:

- 2 x ENEGON EN-EL15C Replacement Batteries (1900mAh)
- 1 x ENEGON Smart LED Dual Charger
- 1 x Micro USB Cable

Your browser does not support the video tag.

Video: An unboxing of the ENEGON EN-EL15C Battery and Charger kit, showing the contents as they are removed from the packaging.

4. Compatibility

The ENEGON EN-EL15C replacement batteries and smart dual charger are fully compatible with the following Nikon camera models and chargers:

- Nikon D500, D600, D610, D750, D780, D800, D800E, D810, D810A, D850
- Nikon D7000, D7100, D7200, D7500
- Nikon 1 V1
- Nikon Z6, Z6 II, Z6 III, Z7, Z7 II, Z8, ZF
- Nikon MH-25, MH-25a chargers



Image: Visual representation of compatible Nikon camera models with the ENEGON EN-EL15 battery.

5. Setup

5.1. Charging the Batteries

1. Insert one or two ENEGON EN-EL15C batteries into the charging slots of the smart dual charger. Ensure the battery contacts align with the charger pins.
2. Connect the provided Micro USB cable to the charger's Micro-USB input port. Alternatively, you can use a Type-C cable (not included) with the Type-C input port.
3. Connect the other end of the USB cable to a 5V USB power source, such as a PC, car charger, or power bank.
4. The smart LED display on the charger will show the real-time charging status for each battery.



Image: Step-by-step guide for charging batteries with the ENEGON dual charger.



Image: Various power sources compatible with the ENEGON dual charger.

5.2. Understanding LED Indicators

The smart LED display provides real-time information on the battery charge level:

Indicator Status	Power Ratio	Statements
No bars	No power	No power
One bar	6%–25%	One LED on
Two bars	26%–50%	Two LEDs on
Three bars	51%–75%	Three LEDs on
Four bars	76%–100%	Four LEDs on



Image: Real-time charging status display on the ENEGON charger.

5.3. Inserting Batteries into Camera

1. Ensure your camera is powered off.
2. Locate and open the battery compartment on your Nikon camera.
3. Insert a fully charged ENEGON EN-EL15C battery into the compartment, ensuring correct orientation.
4. Close the battery compartment securely.

6. Operation

6.1. General Usage

Once the battery is inserted into your compatible Nikon camera, power on the camera as usual. The ENEGON EN-EL15C batteries are designed to provide stable and consistent power for extended periods, supporting approximately 1000 photos or over 2 hours of video recording per battery (based on 1900mAh capacity).

Your browser does not support the video tag.

Video: A review highlighting the versatility, portability, and dependability of the ENEGON EN-EL15C battery pack.

6.2. Maximizing Battery Life

- Turn off the camera when not in use.
- Reduce screen brightness or use the viewfinder when possible.
- Disable Wi-Fi, Bluetooth, or GPS functions if not needed.
- Avoid extreme temperatures, as they can affect battery performance.

7. Maintenance

7.1. Cleaning

- Wipe the battery and charger with a soft, dry cloth.
- Do not use liquid cleaners or solvents.
- Keep battery contacts clean to ensure optimal connection.

7.2. Storage

- Store batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- For long-term storage, charge batteries to approximately 50-60% capacity.
- Remove batteries from the camera and charger when not in use for extended periods.

8. Troubleshooting

8.1. Battery Not Charging

- Ensure the charger is properly connected to a 5V USB power source.
- Check that the USB cable is securely plugged into both the charger and the power source.
- Verify that the batteries are correctly inserted into the charger slots with contacts aligned.
- Try a different USB cable or power source to rule out external issues.

8.2. Camera Not Powering On with ENEGON Battery

- Ensure the battery is fully charged. Refer to the LED indicators on the charger.
- Check that the battery is correctly inserted into the camera's battery compartment.
- Verify that your camera model is listed in the compatibility section.
- Clean the battery contacts on both the battery and the camera with a dry cloth.

9. Specifications

Feature	Detail
Brand	ENEGON
Model Number	EN-EL15
Battery Capacity	1900mAh (each battery)
Input Voltage (Charger)	5 Volts

Feature	Detail
Output Voltage (Charger)	5 Volts
Number of Ports (Charger)	2 (Micro-USB, Type-C)
Product Dimensions	4.69"D x 3.34"W x 2.05"H
Item Weight	230 Grams
Safety Certification	UL Certified Battery Cell

10. Warranty & Support

ENEGON products come with a 1-year warranty. For any questions, technical support, or warranty claims, please contact ENEGON customer service through the retailer's platform or visit the official ENEGON website for contact information. Please retain your proof of purchase for warranty purposes.

© 2026 ENEGON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q1G83XK

More documents and user manuals: **https://manuals.plus/**