SYSKA HT3050

SYSKA HT3050 Corded & Cordless Men's Trimmer User Manual

Model: HT3050

Introduction Safety Instructions Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the SYSKA HT3050 Corded & Cordless Men's Trimmer. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new grooming device. Please read it thoroughly before first use and keep it for future reference.

Package Contents:

- 1N SYSKA HT3050 Beard Trimmer
- 1N USB Charging Cord
- 1N Cleaning Brush
- 1N User Manual & Warranty Card



Image 1.1: SYSKA HT3050 Trimmer highlighting its main features.

2. Important Safety Instructions

To reduce the risk of electric shock, injury, or fire, always follow these basic safety precautions:

- Do not immerse the trimmer in water or use it near water (e.g., in a bathtub, shower, or sink).
- Keep the appliance dry.
- Do not use the trimmer if it is damaged, or if the blades are broken or bent.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the provided USB charging cable.
- Do not attempt to modify or repair the trimmer yourself. Contact customer support for assistance.

3. Setup and Initial Use

3.1 Unpacking

Carefully remove all components from the packaging. Inspect the trimmer and accessories for any signs of damage. Retain the packaging for storage or in case of return.

3.2 Charging the Trimmer

Before first use, fully charge the trimmer for approximately 1 hour. The trimmer features a rapid charge function.

1. Connect the USB charging cord to the trimmer's charging port.
2. Plug the other end of the USB cable into a USB power source (e.g., laptop, power bank, or USB adapter).
3. The built-in LED indicator will illuminate to show charging status. It will indicate when the trimmer is charging and when it is fully charged.



Image 3.1: Trimmer connected to USB for charging.

3.3 Attaching the Stubble Comb

Align the stubble comb with the trimmer head and gently push it down until it clicks into place. Ensure it is securely attached before use.

4. Operating Instructions

4.1 Powering On/Off

Press the power button located on the front of the trimmer to turn it on or off.

4.2 Adjusting Length Settings

The trimmer features 10 lock-in length settings, ranging from 1mm to 10mm, with 1mm precision. To adjust the trimming length, slide the comb adjustment switch up or down to your desired setting.

4.3 Corded and Cordless Use

The SYSKA HT3050 can be used both corded (while plugged in) and cordless. A full charge provides up to 50 minutes of cordless operation.



Image 4.1: Trimmer highlighting corded/cordless functionality and battery runtime.

4.4 Trimming Techniques

For best results, ensure your beard is clean and dry. Hold the trimmer with the comb flat against your skin and move it against the direction of hair growth. Use slow, controlled movements. For detailing, remove the comb attachment.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your trimmer.

5.1 Cleaning the Blades

The trimmer features self-sharpening stainless steel blades designed for smooth contact with the skin. After each use:

1. Turn off the trimmer and disconnect it from the power source if charging.
2. Remove the comb attachment.
3. Use the provided cleaning brush to remove loose hairs from the blades and the trimmer head.
4. The blades can be rinsed under running water. Ensure the trimmer body remains dry. Allow blades to air dry completely before reattaching the comb or storing.



Image 5.1: Trimmer highlighting LED indicator and stainless steel blades.

5.2 Cleaning the Comb Attachment

Rinse the comb attachment under running water to remove any trapped hairs. Allow it to air dry completely before reattaching.

5.3 Storage

Store the trimmer in a cool, dry place, away from direct sunlight and moisture. Ensure the trimmer is clean and dry before storing.

6. Troubleshooting

If you encounter issues with your SYSKA HT3050 trimmer, refer to the following common problems and solutions:

- **Trimmer does not turn on:**
  Ensure the trimmer is charged. Connect it to the USB charger and check the LED indicator. If using corded, ensure the power source is active.
- **Poor trimming performance:**
  Clean the blades and comb attachment thoroughly to remove any hair buildup. Ensure the comb is correctly attached. The blades are self-sharpening, but if performance significantly degrades, contact support.
- **Battery not holding charge:**
  Ensure the charging cable is securely connected to both the trimmer and the power source. Allow the trimmer to charge for the recommended 1 hour. If the issue persists, the battery may need servicing.
- **Trimmer gets hot during use:**
  It is normal for the trimmer to warm up slightly during extended use. If it becomes excessively hot, turn it off and allow it to cool down before resuming. Ensure blades are clean and free of obstruction.

7. Product Specifications

Model Number	HT3050
Brand	SYSKA
Power Source	Battery Powered (Corded & Cordless)
Battery Type	1 AA battery (included)
Charging Time	Approx. 1 hour (Rapid Charge)
Working Time	Up to 50 minutes (cordless)
Blade Material	Stainless Steel (Self-Sharpening)
Length Settings	10 (1mm - 10mm with 1mm precision)
Dimensions (LxWxH)	18 x 6 x 4 cm
Item Weight	230 g

8. Warranty and Support

8.1 Warranty Information

The SYSKA HT3050 Trimmer comes with a **2-year warranty** from the date of purchase. Please retain your purchase receipt and the warranty card included in the package for any warranty claims. The warranty covers manufacturing defects and malfunctions under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact SYSKA customer support:

- **Customer Service Number:** 1800-102-8787
- **Manufacturer:** SYSKA, Songjiang Dict., Shanghai China
- **Packer:** Syska Led Lights Pvt. Ltd., Syska House, Office No. S2, 2nd Floor, Sakore Nagar, Pune 411014, Maharashtra