Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Catnapper 4847

Catnapper 4847 Burns Power Lift Recliner Chair User Manual

Model: 4847

Important Safety Information

WARNING:

- Do not exceed the maximum weight limit of 400 pounds.
- Keep hands and fingers away from moving parts when operating the reclining mechanism.
- Always use the chair under adult supervision.
- Never leave children unattended near the chair.
- Ensure the power cord is not pinched or damaged.
- Do not allow pets near the moving parts of the chair.

Product Overview

The Catnapper 4847 Burns Power Lift Recliner Chair is designed for comfort and ease of use, featuring a duo motor system for independent control of the backrest and ottoman. It supports users up to 400 lbs and offers a lay-flat reclining position.



This image shows the Catnapper 4847 Burns Power Lift Recliner Chair. The chair is upholstered in an ash-colored fabric with a subtle texture. It features plush cushioning on the backrest, seat, and armrests. The footrest is extended, indicating a reclined position. The chair's robust design is evident, supporting its 400 lbs capacity.

Key Features:

- **Duo Motor System:** Allows independent adjustment of the backrest and footrest.
- **Power Lift Function:** Assists users in standing up from the chair.
- **Lay-Flat Recline:** Extends to 72 inches for a fully reclined position.
- **High Weight Capacity:** Rated for up to 400 lbs.
- **Durable Construction:** Features an alloy steel frame.

Package Contents

Verify that all components are present before beginning assembly:

- Recliner Base
- Backrest
- Power Cord
- Hand-held Remote Control
- User Manual (this document)

Setup and Assembly

Step 1: Unpacking

1. Carefully remove all components from the packaging.
2. Place the recliner base in the desired location, ensuring sufficient space for reclining and lifting functions.
3. Remove any protective packaging materials from the chair components.

Step 2: Attaching the Backrest

1. Align the metal brackets on the backrest with the corresponding receivers on the recliner base.
2. Slide the backrest downwards until it securely locks into place. You should hear an audible click.
3. Gently push and pull on the backrest to ensure it is firmly attached.

Step 3: Connecting Power

1. Locate the power transformer and the power cord.
2. Connect the power cord to the transformer, then connect the transformer to the chair's power input cable, typically located at the rear or underside of the chair.
3. Plug the power cord into a grounded electrical outlet.
4. Ensure all connections are secure and the power cord is not obstructed or pinched.

Operating Instructions

The Catnapper 4847 features a duo motor system, allowing independent control of the backrest and footrest for personalized comfort.

Using the Hand-held Remote Control

The remote control has buttons to operate the chair's functions:

- **Up Arrow (Back):** Reclines the backrest backward.
- **Down Arrow (Back):** Brings the backrest upright.

- **Up Arrow (Footrest):** Raises the footrest.
- **Down Arrow (Footrest):** Lowers the footrest.
- **Lift Button:** Activates the lift mechanism to assist in standing.
- **Recline Button:** Fully reclines the chair to the lay-flat position.

Reclining and Lifting Functions

1. **To Recline the Backrest:** Press and hold the "Up Arrow (Back)" button until the desired angle is reached.
2. **To Raise the Footrest:** Press and hold the "Up Arrow (Footrest)" button until the desired height is reached.
3. **To Return to Upright Position:** Press and hold the "Down Arrow (Back)" and "Down Arrow (Footrest)" buttons as needed.
4. **To Activate Lift Function:** From the upright position, press and hold the "Lift Button". The chair will gently tilt forward and rise, assisting you to a standing position.
5. **To Achieve Lay-Flat Position:** Press and hold the "Recline Button" until the chair is fully extended to 72 inches.

Note: *Release any button to stop the chair's movement at any point.*

Maintenance and Care

Cleaning the Fabric

- **Spot Clean Only:** For spills or stains, immediately blot the affected area with a clean, dry cloth.
- Use a mild, water-free cleaning solvent or a dry-cleaning product. Do not use water-based cleaners, as they may cause shrinking or water stains.
- Test any cleaning product on an inconspicuous area first to ensure it does not damage or discolor the fabric.
- Vacuum regularly with a soft brush attachment to remove dust and debris.

General Maintenance

- Periodically check all power connections to ensure they are secure.
- Avoid placing the chair in direct sunlight or near heat sources to prevent fabric fading or damage.
- Do not sit on the armrests or footrest, as this can cause damage to the mechanism or frame.

Troubleshooting

Problem	Possible Cause	Solution
Chair does not move.	No power connection.	Ensure power cord is securely plugged into the wall outlet and the chair. Check if the outlet is functional.
Remote control is unresponsive.	Loose connection or remote malfunction.	Check the remote's cable connection to the chair. If still unresponsive, contact customer support.
Chair makes unusual noises.	Obstruction in mechanism or loose parts.	Inspect for any objects obstructing the moving parts. Do not attempt to lubricate or repair the mechanism yourself. Contact customer support.

Problem	Possible Cause	Solution
Footrest or backrest does not fully extend/retract.	Obstruction or motor issue.	Check for obstructions. Ensure the chair is not against a wall. If the issue persists, contact customer support.

Specifications

Feature	Detail
Model Name	Catnapper 4847 Burns
Brand	Catnapper
Color	Ash
Material	Alloy Steel Frame, Suede Upholstery, Foam Fill
Product Dimensions (D x W x H)	44"D x 39"W x 42"H
Extended Length	72 inches
Maximum Weight Capacity	400 pounds
Item Weight	137 pounds
Seat Depth	22 inches
Recommended User Height	5 ft 4 in to 5 ft 10 in
Motor Type	Duo Motor
Reclining Position Count	3 (Upright, Reclined, Lay-Flat)
Product Care	Spot Clean Only

Warranty Information

This product is covered by the manufacturer's limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your purchase or visit the official Catnapper website. Keep your proof of purchase for warranty claims.

Customer Support

If you have any questions, require assistance with assembly, or encounter issues not covered in this manual, please contact Catnapper customer support.

Website: www.catnapper.com

Phone: Refer to your product documentation for the most current contact number.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q3744SN

More documents and user manuals: **https://manuals.plus/**