LOKMAT MK18

LOKMAT MK18 Smartwatch User Manual

Model: MK18

1. Introduction

Thank you for choosing the LOKMAT MK18 Smartwatch. This device is designed to enhance your daily activities with its smart features, including activity tracking, notifications, and timekeeping. This manual provides essential information for setting up, operating, and maintaining your smartwatch to ensure optimal performance and longevity.

2. Safety Information

- Do not attempt to open or disassemble the smartwatch. Unauthorized repairs can void your warranty and cause damage.
- Avoid exposing the smartwatch to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.
- While the smartwatch is rated IP68 (5 ATM) for water resistance, it is not suitable for hot showers, saunas, or diving. Do not press any buttons while the watch is submerged in water.
- Keep the smartwatch away from strong magnetic fields.
- Clean the watch regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.

3. Package Contents

- LOKMAT MK18 Smartwatch (x1)
- User Manual (x1)

4. Product Overview

The LOKMAT MK18 Smartwatch features a durable design with a clear FSTN LCD display. It is equipped with a single button for navigation and various sensors for activity tracking.



Figure 4.1: Lokmat MK18 Smartwatch with various strap colors and display features. The image shows the watch in black, orange, and green strap options, highlighting its digital display and robust design.



Figure 4.2: Lokmat MK18 Smartwatch display showing various functions and icons. This image illustrates the watch face with indicators for steps, calories, distance, Bluetooth, calendar, alarm, stopwatch, remote camera, call reminder, and message reminder.



Figure 4.3: Dimensions of the Lokmat MK18 Smartwatch, showing dial diameter and thickness. The image indicates a 45mm dial diameter and 12mm thickness, providing a clear understanding of the watch's physical size.

5. Setup

5.1 Initial Power On

To power on your LOKMAT MK18 Smartwatch, press and hold the main button located on the side of the watch until the display illuminates.

5.2 App Installation and Pairing

To unlock the full functionality of your smartwatch, you need to connect it to your smartphone via Bluetooth 4.0 and the dedicated application.

1. **Download the App:** Search for the official LOKMAT smartwatch application in your smartphone's app store (e.g., Google Play Store for Android or Apple App Store for iOS).
2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open the App:** Launch the installed application on your smartphone.
4. **Pair Device:** Follow the in-app instructions to search for and pair with your LOKMAT MK18 Smartwatch. The connection is designed to be stable, fast, and consume extremely low power.
5. **Grant Permissions:** Allow necessary permissions for the app to function correctly, such as notification access and location services.

6. Operating Instructions

The LOKMAT MK18 Smartwatch features a simple and clear function menu, operated primarily with a single button.

6.1 Basic Navigation

- **Short Press:** A short press of the button typically cycles through different display modes or functions.
- **Long Press:** A long press may activate or confirm a function, or enter a setting mode. Refer to specific function sections for details.

6.2 Time Display

The LCD screen displays the current time. Ensure your watch is synced with the app for accurate timekeeping.

6.3 Pedometer and Activity Tracking

The smartwatch tracks your daily activity. You can set health goals and view your daily steps, distance, and calories burned directly on the LCD display. Data can be checked and analyzed at any time through the connected smartphone application.

6.4 Call and Message Reminders

Once paired with your smartphone, the watch will provide reminders for incoming calls, messages, and notifications from various social media applications such as Twitter, Facebook, WhatsApp, and Skype. The watch features three distinct warning sounds to ensure you don't miss important alerts.

6.5 Stopwatch

The professional stopwatch function allows for precise timing, including sub-time measurements. Activate and

control the stopwatch using the watch's button as indicated on the display.

6.6 Remote Camera Control

Use your smartwatch as a remote shutter for your smartphone's camera. Open the camera function in the app and use the watch button to capture photos.

6.7 Alarm Function

Set alarms through the connected application. The watch will vibrate or sound at the set time. It supports background alarms.

6.8 Data Cloud Memory

Your activity data is synchronized with the cloud via the application, allowing for long-term storage and analysis of your health and fitness progress.

7. Maintenance

- **Cleaning:** Wipe the watch case and strap with a soft, damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly, then dry completely.
- **Storage:** When not in use for extended periods, store the smartwatch in a cool, dry place away from direct sunlight.
- **Battery:** The watch is designed for extended standby time. If the battery level is low, charge it promptly to maintain optimal performance.

8. Troubleshooting

- **Watch not turning on:** Ensure the battery is charged. Connect it to a power source for at least 30 minutes.
- **Cannot pair with smartphone:**
  a. Ensure Bluetooth is enabled on your phone and the watch.
  b. Make sure the watch is within the Bluetooth range of your phone.
  c. Restart both the watch and your smartphone.
  d. Check if the app has all necessary permissions.
- **Notifications not received:**
  a. Verify that the watch is successfully paired with the app.
  b. Check notification settings within the app and your phone's system settings.
  c. Ensure the app is running in the background and not restricted by power-saving modes.
- **Inaccurate activity data:** Ensure the watch is worn correctly on your wrist. Calibrate the pedometer if an option is available in the app.
- **Water resistance concerns:** Remember that while IP68 rated, pressing buttons underwater or exposure to hot water can compromise the seal. If water ingress is suspected, discontinue use and contact support.

9. Specifications

Brand	LOKMAT

Model Number	PMF3839809604027GQ
Display Type	Digital FSTN LCD
Screen Size	1.9 Inches
Dial Diameter	Approx. 4.6 cm (45mm)
Dial Thickness	Approx. 1.2 cm (12mm)
Strap Width	Approx. 2.2 cm (22mm)
Strap Length	Approx. 25.0 cm
Case Material	316 Stainless Steel
Strap Material	Stainless Steel / Polyurethane (depending on color variant)
Water Resistance Rating	IP68 (5 ATM, up to 50 meters depth)
Connectivity	Bluetooth 4.0
Compatible Devices	Smartphones
Functions	Luminous display, Alarm, Call Reminder, Pedometer, Stopwatch, Calories, Remote Camera, Data Cloud Memory, Calendar, GPS (integrated)
Weight	Approx. 46g (product weight), 169.45g (package weight)
UPC / GTIN	791294449742

10. Warranty and Support

LOKMAT products are manufactured to high-quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

© 2023 LOKMAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question