Sena SRL-02

Sena SRL 2 Motorcycle Bluetooth Communication System User Manual

Model: SRL-02

1. Introduction

The Sena SRL 2 is a state-of-the-art Bluetooth communication system designed specifically for seamless integration with Shoei GT-Air 2 helmets. This system allows riders to stay connected, enjoy music, make phone calls, and communicate with other riders, enhancing the riding experience with advanced technology and intuitive controls.

Key Features:

- Bluetooth 4.1 technology for stable connections.
- Unibody design for perfect fit within compatible helmets.
- Universal Intercom for communication with other brand headsets.
- Group Intercom functionality.
- Built-in FM radio tuner.
- Active Noise Cancellation for clear audio.

2. Package Contents

Before beginning installation, please verify that all components are present in your package:

- Sena SRL 2 Main Unit
- Speakers (integrated)
- Microphone (integrated)
- Ear Cushions
- USB Power & Data Cable
- User Manual (this document)



Image: All components of the Sena SRL 2 communication system, including the main unit, speakers, and microphone.



Image: The Sena SRL 2 communication system components as they appear in their retail packaging.

3. Installation

The Sena SRL 2 is designed for integrated installation within the Shoei GT-Air 2 helmet. Follow these steps carefully for proper setup:

1. **Prepare the Helmet:** Remove the cheek pads and neck roll from your Shoei GT-Air 2 helmet. Locate the designated slots for the SRL 2 system.
2. **Install Speakers:** Carefully place the speakers into the helmet's ear pockets. Ensure the speaker wires are routed neatly along the helmet's interior channels.
3. **Install Main Unit:** Insert the main SRL 2 unit into its dedicated slot at the rear base of the helmet. Ensure it clicks securely into place.
4. **Connect Wires:** Connect the speaker and microphone wires to the main unit. Ensure all connections are firm.
5. **Reassemble Helmet:** Carefully reattach the cheek pads and neck roll, ensuring no wires are pinched.



Image: The Sena SRL 2 system fully installed within a Shoei GT-Air 2 helmet, showing the integrated speakers and main unit.



Image: A close-up view of the Sena SRL 2 main unit, highlighting its compact design and connection points.

4. Operating Instructions

Familiarize yourself with the SRL 2's controls and functions for optimal use.

4.1 Power On/Off

- **Power On:** Press and hold the Center Button and (+) Button for 1 second.
- **Power Off:** Tap the Center Button and (+) Button simultaneously.

4.2 Bluetooth Pairing

To pair with your mobile phone or other Bluetooth devices:

1. With the SRL 2 off, press and hold the Center Button for 5 seconds until you hear "Phone pairing."
2. On your mobile device, enable Bluetooth and select "Sena SRL 2" from the list of available devices.
3. Once paired, you will hear "Your headset is paired."

4.3 Intercom Communication

The SRL 2 supports both Universal Intercom and Group Intercom functions.

- **Start Intercom:** Tap the Center Button once to initiate intercom with a paired rider.
- **End Intercom:** Tap the Center Button once again.

4.4 Music and FM Radio

- **Play/Pause Music:** Press the Center Button.

- **Next Track:** Press the (+) Button.
- **Previous Track:** Press the (-) Button.
- **FM Radio On/Off:** Press and hold the (-) Button for 1 second.
- **Scan FM Stations:** Double tap the (+) or (-) Button while FM radio is on.

4.5 Volume Control

Adjust volume by tapping the (+) Button to increase and the (-) Button to decrease. The SRL 2 features intelligent volume control to adapt to riding conditions.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Sena SRL 2 system.

- **Cleaning:** Use a soft, damp cloth to clean the exterior of the unit. Avoid using harsh chemicals or abrasive cleaners. Ensure the unit is dry before use or charging.
- **Battery Care:** The SRL 2 uses a CR2 battery (included). For optimal battery life (up to 10 hours talk time), charge the unit fully before first use and regularly. Avoid extreme temperatures when storing the device.
- **Firmware Updates:** Regularly check the Sena website for firmware updates. Use the Sena Device Manager software on your computer to update the firmware. Updates often include performance improvements and new features. Ensure the "Sound Boost" option is enabled in the Device Manager for improved audio quality if desired.
- **Storage:** If storing the unit for an extended period, charge it to about 50% and store it in a cool, dry place.

6. Troubleshooting

Here are solutions to common issues you might encounter:

- **No Audio/Low Volume:**
  - Ensure volume is turned up on both the SRL 2 and your connected device.
  - Check speaker placement within the helmet.
  - Connect to Sena Device Manager and ensure "Sound Boost" is enabled in the firmware settings.
- **Difficulty with Button Usage:**
  - Practice button presses without gloves to understand the tactile feedback.
  - Be precise with short taps versus 1-second holds, as these often trigger different functions.
- **Connectivity Issues (Bluetooth):**
  - Ensure the SRL 2 is in pairing mode.
  - Forget the device on your phone's Bluetooth settings and re-pair.
  - Restart both the SRL 2 and your mobile device.
- **Poor FM Radio Reception:**
  - Reception can vary based on location and environmental factors.
  - Try rescanning for stations in a different area.
- **Voice Command Not Responding:**
  - Ensure you are speaking clearly and at a normal volume.

- Check for firmware updates, as these can improve voice recognition.

7. Specifications

Feature	Specification
Model Name	SRL
Connectivity Technology	Wireless (Bluetooth 4.1)
Noise Control	Active Noise Cancellation
Battery Life	10 Hours (Talk Time)
FM Radio Frequency Range	76 ~ 108 MHz
Water Resistance Level	Water Resistant
Dimensions	11 x 6.5 x 3 inches
Item Weight	15.5 ounces
Compatible Devices	Shoei GT-Air 2 Helmet and other Bluetooth-enabled devices

8. Warranty and Support

Sena products are manufactured with high-quality materials and craftsmanship. For detailed warranty information, please refer to the warranty card included with your product or visit the official Sena website. Keep your proof of purchase for warranty claims.

For technical support, firmware updates, and additional resources, please visit the official Sena website or contact Sena customer service. Online resources often include FAQs, video tutorials, and downloadable manuals.

Sena Official Website: www.sena.com

© 2024 Sena Technologies, Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question