Ciglow Ciglowvx05p3nco4

Ciglow Replacement Remote Control User Manual

For Sony AV Receiver Systems RM-AAU106, RM-AAU107, RM-AAU116, STR-DH830, STR-DH710

Introduction

This manual provides instructions for the Ciglow Replacement Remote Control, designed to operate various Sony AV Receiver Systems. This remote offers a convenient and reliable solution for controlling your audio-visual equipment.



Image: Front view of the Ciglow Replacement Remote Control.

The remote is compatible with the following Sony AV Receiver System models: **RM-AAU106, RM-AAU107, RM-AAU116, STR-DH830, STR-DH710**. It features an ergonomic design with large, easy-to-press buttons for comfortable and intuitive use.



Image: The remote control demonstrating compatibility with various entertainment devices.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards and remove it.

3. Insert two (2) AA batteries (not included) into the compartment, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Image: View of the remote control's battery compartment with the cover removed.

Note: Ensure batteries are inserted correctly to prevent damage to the remote control. Do not mix old and new batteries, or different types of batteries.

Operating Instructions

The Ciglow Replacement Remote Control operates via infrared (IR) technology. For optimal performance, ensure a clear line of sight between the remote's IR emitter and the receiver's IR sensor.

Basic Operation

1. Point the remote control directly towards your Sony AV Receiver System.
2. Press the desired function button (e.g., Power, Volume Up/Down, Channel Up/Down, Input Select).
3. The remote is pre-programmed for the compatible models listed and requires no additional setup or pairing.



Image: A hand demonstrating how to hold and point the remote control during use.

Operating Range

The maximum effective operating range for this remote control is approximately 10 meters (33 feet) under ideal conditions. Obstructions between the remote and the receiver may reduce this range.

Maintenance

Cleaning

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution, then wipe dry immediately.
- Do not use abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or buttons.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Refer to the "Battery Installation" section under Setup for instructions.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the device.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AA batteries, ensuring correct polarity.
Remote not responding.	No clear line of sight to the receiver.	Ensure no objects are blocking the path between the remote and the AV receiver. Point the remote directly at the receiver.
Limited operating range.	Weak batteries or environmental interference.	Replace batteries. Reduce distance to the receiver. Ensure no strong light sources (e.g., direct sunlight) are interfering with the IR signal.
Remote buttons are sticky or unresponsive.	Dirt or debris under buttons.	Clean the remote control as described in the Maintenance section.

Specifications

Brand	Ciglow
Model (Manufacturer)	Ciglowvx05p3nco4
Compatible Devices	Sony AV Receiver Systems (RM-AAU106, RM-AAU107, RM-AAU116, STR-DH830, STR-DH710)
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Maximum Range	10 meters (33 feet)
Battery Type	2 x AA batteries (not included)
Dimensions (L x W x H)	Approx. 21cm x 5cm x 2.3cm (8.27" x 1.97" x 0.91")
Material	ABS

Product Overview Video

[redacted]

Video: A brief overview of the Ciglow Replacement Remote Control for RM-AAU106 AV Receiver System. This video demonstrates the product's appearance and general functionality.

Warranty and Support

Information regarding product warranty and customer support is not available in this manual. Please refer to the product packaging or contact your retailer for details on warranty coverage and support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question