Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 19033101-C

YING RAY Replacement Remote Control User Manual

For Arctic King Air Conditioners (Model 19033101-C)

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your YING RAY replacement remote control, model 19033101-C. This remote is designed to be compatible with various Arctic King air conditioner models, including MWDUJ12ERMCJ9, MWDUJ08ERBCJ9, MWDUK18ERMCJ7, MWDUK05CRBCK0, and MWDUK15CRBCJ7. Please read this manual carefully to ensure proper use and longevity of your remote control.

Setup

Battery Installation

The remote control requires two (2) AAA 1.5V ordinary batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note:

- No programming is required. The remote control is ready for use immediately after battery installation.
- Ensure batteries are inserted correctly to avoid malfunction.

Operating Instructions

This section details the functions of the buttons on your remote control. Refer to the image below for button identification.



This image displays the YING RAY replacement remote control. On the left, the remote features a purple power button at the top, followed by gray buttons for Mode, Timer, Speed, One Touch, and Sleep, with directional arrows for temperature adjustment. On the right, a label indicates 'TYPE: RG32A/E' and 'Rated Voltage: 3VDC'. It also advises to 'To prevent damage, remove the batteries when not being used for a long time.'

Button Functions

- **Power Button** (**Purple button with circle and line**): Turns the air conditioner ON or OFF.
- **MODE Button**: Cycles through available operating modes (e.g., Cool, Fan, Dry, Heat, Auto).
- **Temperature Adjustment Arrows** (▲ / ▼): Increases or decreases the set temperature.
- **TIMER Button**: Sets the timer for automatic ON/OFF operations. Refer to your air conditioner's manual for specific timer settings.

- **SPEED Button**: Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **ONE TOUCH Button**: Activates a pre-programmed comfort setting with a single press.
- **SLEEP Button**: Activates the sleep mode, which adjusts temperature and fan speed for comfortable sleep and energy saving.

Maintenance

Battery Care

- To prevent damage from battery leakage, remove the batteries from the remote control when it will not be used for an extended period.
- Replace all batteries at the same time. Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.

Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity.
  - Replace the batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range of the air conditioner.
- **Air conditioner not responding to specific commands:**
  - Verify that the air conditioner is powered on and functioning correctly.
  - Some functions may be specific to your air conditioner model; consult your air conditioner's original manual.

If the problem persists after trying these steps, please contact the seller or manufacturer for further assistance.

Specifications

Model Number	19033101-C
Remote Type	RG32A/E
Rated Voltage	3VDC
Battery Type	2 x AAA 1.5V Ordinary Batteries
Compatible Devices	Arctic King Air Conditioners (e.g., MWDUJ12ERMCJ9, MWDUJ08ERBCJ9, MWDUK18ERMCJ7, MWDUK05CRBCK0, MWDUK15CRBCJ7)

Special Feature	Ergonomic Design

Warranty Information

This product is covered by the manufacturer's standard warranty. Please retain your purchase receipt as proof of purchase. For specific warranty terms and conditions, refer to the documentation provided at the time of purchase or contact the seller directly.

Customer Support

For any questions, technical assistance, or troubleshooting not covered in this manual, please contact the YING RAY customer support or the retailer from whom you purchased this product. Please have your product model number (19033101-C) and purchase information ready when contacting support.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q8F3WTF

More documents and user manuals: **https://manuals.plus/**