Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Truper LAVA-2000T

Truper Electric Pressure Washer 2000 PSI, Induction Motor

Model: LAVA-2000T

Brand: Truper

Important Safety Information

Read all instructions carefully before operating the pressure washer. Failure to follow these instructions may result in serious personal injury and/or property damage.

- Always wear appropriate personal protective equipment, including safety glasses, hearing protection, and protective footwear.
- Never point the spray gun at people, pets, or electrical devices.
- Ensure all connections are secure before starting the unit.
- Do not operate the pressure washer in an enclosed space.
- Disconnect the power supply before performing any maintenance or cleaning.
- Keep children and bystanders away from the operating area.
- Use only clean water for operation.
- Do not use the pressure washer if the power cord or hose is damaged.

Package Contents

Carefully unpack all items and ensure all components are present and undamaged. If any items are missing or damaged, contact customer support.



Image: All accessories included with the Truper Electric Pressure Washer, laid out for inspection. This includes various nozzles, the spray gun, hose, and cleaning tools.

- Truper Electric Pressure Washer Unit
- High-Pressure Hose
- Spray Gun
- Adjustable Spray Nozzle
- Turbo Nozzle
- Detergent Tank Nozzle
- Water Inlet Filter
- Hose Connector
- Nozzle Cleaning Pin
- User Manual (this document)

Assembly and Setup

Follow these steps to assemble your pressure washer before first use.

1. **Attach the Handle:** Slide the handle into the designated slots on the main unit until it clicks into place.
2. **Connect the High-Pressure Hose:** Securely screw the high-pressure hose to the outlet on the pressure washer unit and to the inlet on the spray gun. Ensure connections are hand-tight.
3. **Connect the Water Supply:** Attach a standard garden hose (not included) to the water inlet filter on the pressure washer. Ensure the water supply is clean and free of debris.
4. **Install the Nozzle:** Select the desired nozzle (e.g., adjustable, turbo, or detergent) and firmly push it into the end of the spray gun until it locks.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the power requirements specified in the 'Specifications' section.



Image: The fully assembled Truper Electric Pressure Washer, showing the main unit, high-pressure hose, spray gun, and various nozzles ready for use.



Image: Diagram illustrating key features such as the quick-connect system for the hose, the 5x more resistant metal braided high-pressure hose, and the wheels for easy transportation.

Operating Instructions

Before starting, ensure the water supply is turned on and the pressure washer is connected to power.

1. **Purge Air from System:** Squeeze the trigger on the spray gun for approximately 30 seconds with the water supply on and the unit off. This allows air to escape and fills the pump with water.
2. **Start the Unit:** Turn the ON/OFF switch to the 'ON' position. The motor will start.
3. **Begin Cleaning:** Aim the spray gun at the surface to be cleaned, maintaining a safe distance. Squeeze the trigger to begin spraying. Release the trigger to stop the flow.
4. **Using Detergent:** If using detergent, fill the detergent tank (if applicable) with pressure washer safe detergent. Attach the detergent nozzle. The pressure washer will automatically draw detergent when operating at low pressure.
5. **Adjusting Pressure/Spray Pattern:** Rotate the adjustable nozzle or switch between different nozzles to achieve the desired spray pattern and pressure for your cleaning task.
6. **Stopping Operation:** To stop, release the trigger, then turn the ON/OFF switch to the 'OFF' position. Turn off the water supply and disconnect the power cord.
7. **Relieve Residual Pressure:** After turning off the unit and water supply, squeeze the spray gun trigger to release any remaining pressure in the system.



Image: Visual guide showing the "Very Deep Cleaning" level achievable with the pressure washer and recommended uses including cleaning homes, RVs, cars, boats, and fences. Also displays the included angle, multiple, turbo, and detergent nozzles.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **Clean Nozzles:** Use the provided nozzle cleaning pin to clear any blockages from the nozzle tips.
- **Inspect Water Inlet Filter:** Regularly check the water inlet filter for debris. Clean or replace if necessary to prevent damage to the pump.
- **Hose and Cord Inspection:** Before each use, inspect the high-pressure hose and power cord for any cuts, abrasions, or damage. Do not use if damaged.
- **Winter Storage:** If storing in freezing temperatures, drain all water from the pump, hose, and spray gun to prevent damage from ice expansion. Consider using a pump protector.
- **General Cleaning:** Wipe down the exterior of the unit with a damp cloth. Do not use harsh chemicals.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Unit does not start	No power, tripped circuit breaker, faulty switch.	Check power connection, reset circuit breaker, contact service if switch is faulty.
Low pressure	Insufficient water supply, clogged nozzle, air in pump, kinked hose.	Ensure full water flow, clean nozzle, purge air from system, straighten hose.
Water leaks	Loose connections, damaged O-rings, cracked hose/gun.	Tighten connections, replace O-rings, replace damaged components.
Motor stops frequently	Overheating, low voltage, extended bypass operation.	Allow unit to cool, ensure proper voltage, avoid prolonged bypass.

Specifications

Technical specifications for the Truper Electric Pressure Washer.

- **Model:** LAVA-2000T
- **Maximum Pressure:** 2000 PSI (Pound per Square Inch)
- **Power Source:** Corded Electric
- **Motor Type:** Induction Motor
- **Item Weight:** Approximately 42.7 pounds (19.4 kg)
- **Manufacturer:** Truper
- **Certification:** OPEI

Warranty and Support

For warranty information or technical support, please refer to the official Truper website or contact their customer service department.
While specific warranty terms may vary by region and retailer, Truper typically offers a limited warranty covering manufacturing defects. Keep your proof of purchase for warranty claims.
For assistance, visit: www.truper.com

© 2024 Truper. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q8Q9K2W

More documents and user manuals: **https://manuals.plus/**