Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY YT1FF P69700313

YING RAY Replacement Remote Control for Friedrich Air Conditioner

Model: YT1FF P69700313

Introduction

This manual provides instructions for the YING RAY Replacement Remote Control, model YT1FF P69700313, designed for use with various Friedrich Air Conditioner models. This remote control is pre-programmed and ready for use upon battery installation.

Setup

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *This remote control is designed to work without any programming once batteries are installed. It displays temperature in Fahrenheit.*



Image: Front view of the YING RAY remote control, displaying 86°F and 12:00 time. The text "Display in Fahrenheit!" is visible on the image.

Operating Instructions

Familiarize yourself with the buttons and their functions for optimal use of your Friedrich Air Conditioner.

Key Functions:

- **Power Button ( ):** Turns the air conditioner ON or OFF.
- **Temperature Adjustment (▲ / ▼):** Adjusts the desired temperature setting.
- **Mode Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **Fan Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **Timer ON/OFF:** Sets the timer for the unit to turn ON or OFF automatically.
- **Sleep Button:** Activates or deactivates the sleep mode, which adjusts temperature for comfortable sleep.
- **Light Button:** Controls the display light on the air conditioner unit.

- **Blow Button:** Activates the blow function to dry internal components and prevent mold.
- **Turbo Button:** Engages maximum cooling or heating power for rapid temperature change.
- **I FEEL Button:** Activates the "I Feel" function, which senses the temperature at the remote's location for more precise comfort.
- **Clock Button:** Sets the current time on the remote's display.

Video Demonstrations:

Your browser does not support the video tag.

Video: A seller demonstrates the functions of a universal air conditioner remote control, showing button presses and display changes. This video provides a general overview of common remote functions.

Your browser does not support the video tag.

Video: A seller demonstrates the use of a remote control compatible with Friedrich Air Conditioners, highlighting its features and ease of operation.

Maintenance

Battery Replacement:

Replace batteries when the remote's display becomes dim or the remote stops responding. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these can damage the remote's surface or internal components.

Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with proper polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the air conditioner's receiver.
  - Ensure you are within the maximum operating range (up to 10 meters).
- **Display is dim or blank:**
  - Replace the batteries.
- **Temperature display is incorrect or in Celsius:**
  - This remote is designed to display in Fahrenheit. If it shows Celsius, try pressing the **Mode** and **Temp** buttons simultaneously while the remote is turned OFF to switch the unit. Repeat if necessary.

Specifications

Feature	Detail
Brand	YING RAY
Model Name	YT1FF
Model Number	2019040301
Compatible Devices	Friedrich Air Conditioners (e.g., MWM09Y1J, MRM09Y1J, MWM12Y1J, MRM12Y1J, BR0412W1A, BR1224W3A, MM09YJ, MM12YJ, MM18YJ, MM24YJ, MW09C1H, MW12C1H, MW12CH, MWD12Y1A, MWD12Y1B, MWD12Y1B-A, MWD24Y3A, MWM09Y1J, MWM12Y1J, MWM18Y3J, MWM24Y3J)
Display Unit	Fahrenheit
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 Meters
Item Weight	0.08 Kilograms
Manufacturer	ZHUHAI YINGRAY TRADING CO., LTD.

Warranty and Support

Specific warranty information is not provided in the product details. For support or warranty inquiries, please refer to the product packaging or contact the seller directly.

© 2024 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07Q9YK74Y

More documents and user manuals: **https://manuals.plus/**