Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 190403008-R

YING RAY Replacement Remote Control User Manual

For Pridiom Air Conditioner Models RG51M5/(C)EU & RG51M1/EU1

1. Overview

This manual provides comprehensive instructions for the YING RAY Replacement Remote Control, specifically designed for use with Pridiom Air Conditioner models RG51M5/(C)EU and RG51M1/EU1. This remote serves as a direct replacement and operates with a temperature display in Fahrenheit.





Figure 1: YING RAY Replacement Remote Control. This image displays the full remote control unit, highlighting its buttons and digital display.

Compatibility: This remote control is compatible with Pridiom air conditioner models RG51M5/(C)EU and RG51M1/EU1. Please verify your air conditioner's model number to ensure proper functionality.

2. Setup

2.1 Battery Installation

The remote control requires two AAA 1.5V normal batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) ends align correctly with the polarity indicators inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

Note: No pairing is typically required for this replacement remote. It should function immediately upon battery installation with compatible Pridiom air conditioner units.

3. Operating Instructions

3.1 Fahrenheit Display

This remote control displays temperature readings in Fahrenheit (°F).



Figure 2: Remote control highlighting Fahrenheit display and compatible model numbers. This image emphasizes the Fahrenheit temperature display and lists the compatible Pridiom air conditioner model numbers.

3.2 Button Functions

Button	Function
ON/OFF	Powers the air conditioner unit on or off.
MODE	Cycles through operating modes: Auto, Cool, Dry, Heat.

Button	Function
TEMP ▲/▼	Adjusts the temperature setting up or down.
FAN SPEED	Cycles through fan speeds: High, Med, Low, Auto.
SWING	Activates or deactivates the air swing function.
SLEEP	Engages sleep mode for quiet operation and energy saving.
TIMER ON/OFF	Sets a timer for the unit to turn on or off automatically.
RESET	Resets certain settings (specific function may vary by AC unit).
LOCK	Locks the remote to prevent accidental changes to settings.
LED	Controls the display light on the air conditioner unit.
TURBO	Activates maximum cooling/heating for rapid temperature change.
AIR DIRECTION	Adjusts the direction of airflow from the air conditioner.

4. Maintenance

4.1 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace the batteries when the remote's operational range decreases, the display becomes dim, or the remote stops responding. Always replace both batteries simultaneously with new ones of the same type (AAA 1.5V Normal Batteries).

4.3 Storage

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent potential leakage and damage to the remote.

5. Troubleshooting

5.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted with correct polarity and are not depleted. Replace with new batteries if necessary.
- **Obstruction:** Make sure there are no objects blocking the signal path between the remote control and the air conditioner's receiver.
- **Compatibility:** Verify that your air conditioner's model number is RG51M5/(C)EU or RG51M1/EU1. This remote is specifically designed for these models.

5.2 Display Issues

- **Dim or Blank Display:** This usually indicates low battery power. Replace the batteries with new ones.

6. Specifications

- **Product Model Number:** 190403008-R
- **Compatible AC Models:** Pridiom RG51M5/(C)EU, RG51M1/EU1
- **Display Unit:** Fahrenheit (°F)
- **Battery Type:** 2 x AAA 1.5V Normal Batteries (not included)
- **Manufacturer:** ZHUHAI YINGRAY TRADING CO., LTD.

7. Warranty and Support

For specific warranty information or technical support regarding your YING RAY Replacement Remote Control, please refer to your purchase documentation or contact the seller directly. The seller's contact information can typically be found on your order details or the product listing page.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question