LG MS2535GIB

LG NeoChef MS2535GIB Countertop Microwave Oven User Manual

Model: MS2535GIB

1. Introduction

Thank you for purchasing the LG NeoChef MS2535GIB Countertop Microwave Oven. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before using the microwave oven and keep it for future reference.

The LG NeoChef MS2535GIB is a 25-liter capacity microwave oven designed for countertop installation, featuring a sleek black finish and button controls. It is ideal for heating and defrosting a variety of foods.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens.
- This appliance is intended to be used in household and similar applications.
- Always supervise children when the microwave is in use.

3. Setup and Installation

3.1 Unpacking

Carefully remove the microwave oven from its packaging. Remove all packing materials, including any protective film or tape. Check the oven for any damage, such as dents or a misaligned door. If any damage is present, do not operate the oven and contact your retailer.

3.2 Placement

Place the microwave oven on a flat, stable surface, such as a kitchen countertop, that is strong enough to hold the oven and the food you place in it. Ensure there is adequate ventilation around the oven:

- Leave a minimum of 20 cm (8 inches) of space above the oven.
- Leave a minimum of 10 cm (4 inches) of space at the rear and sides.

Do not block any ventilation openings. Do not place the oven near heat sources like a stove or radiator, or in a damp area like near a sink.



Image: Side view of the LG NeoChef MS2535GIB microwave oven, illustrating the required ventilation space around the unit.

3.3 Electrical Connection

Plug the power cord into a properly grounded electrical outlet. Ensure the voltage and frequency match the specifications on the rating label of the oven. Do not use extension cords or adapters.

3.4 Turntable Assembly

The microwave oven comes with a glass turntable and a turntable ring. These must be correctly installed before operation.

1. Place the turntable ring on the oven cavity floor.

2. Place the glass turntable on top of the ring, ensuring it sits securely in the center support.



Image: Interior view of the LG NeoChef MS2535GIB microwave oven, demonstrating the correct placement of the glass turntable.

4. Operating Instructions

The LG NeoChef MS2535GIB features intuitive button controls and a digital display for easy operation.

4.1 Control Panel Overview



Image: Close-up of the LG NeoChef MS2535GIB control panel, highlighting the digital display and button layout.

The control panel includes a digital display, time adjustment buttons (+/-), and dedicated function buttons for various cooking modes and settings.

4.2 Setting the Clock

After plugging in the oven, the display will show '0:00' or '12:00'.

1. Press the **Clock** button (if available, otherwise consult the full manual for specific clock setting instructions).
2. Use the **+** and **-** buttons to set the hour.
3. Press the **Clock** button again.
4. Use the **+** and **-** buttons to set the minutes.
5. Press the **Clock** button one last time to confirm.

4.3 Basic Microwave Cooking (Time Cook)

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.

3. Use the **+** and **-** buttons to set the desired cooking time.
4. Press the **Start** button (often represented by a play/triangle icon or a dedicated start button). The oven will begin cooking.

4.4 Defrosting

The microwave oven includes a defrost function for various food types.

1. Place the frozen food in a microwave-safe container.
2. Press the **Defrost** button (often indicated by a snowflake icon).
3. Use the **+** and **-** buttons to select the food type or weight, if prompted.
4. Press **Start**. The oven may pause during defrosting to prompt you to turn or separate the food.

4.5 Smart Inverter Technology

The LG NeoChef series features Smart Inverter technology, which provides precise power control for more even heating and defrosting, preventing overcooked edges and uncooked centers. This technology automatically adjusts microwave power output during cooking cycles.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

5.1 Cleaning the Interior

- After each use, wipe the interior with a damp cloth to remove any food splatters.
- For stubborn stains, place a bowl of water with lemon slices or vinegar inside and microwave for 2-3 minutes. The steam will loosen the grime, making it easier to wipe away.
- Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the interior surfaces.

5.2 Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth.
- Clean the control panel gently with a soft, damp cloth. Avoid excessive moisture.

5.3 Cleaning the Turntable and Ring

- The glass turntable and turntable ring can be removed and washed in warm, soapy water or in the dishwasher.
- Ensure they are completely dry before placing them back in the oven.

6. Troubleshooting

If you encounter any issues with your microwave oven, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly; Power cord unplugged; Fuse blown or circuit breaker tripped.	Ensure door is firmly closed; Check power cord connection; Check household fuse/circuit breaker.
Food not heating	Incorrect cooking time/power level set; Microwave-safe dish not used.	Adjust cooking time/power; Use appropriate microwave-safe cookware.
Turntable not rotating	Turntable or ring not correctly placed; Obstruction under turntable.	Re-position turntable and ring; Remove any obstructions.
Light bulb not working	Light bulb burned out.	Contact qualified service personnel for replacement.
Excessive steam inside oven	High moisture content in food.	This is normal for foods with high moisture. Wipe interior after use.

7. Specifications

Feature	Specification
Brand	LG
Model Number	MS2535GIB
Type	Countertop Microwave Oven
Color	Black
Capacity	25 Litres
Power Output	300 Watts
Turntable Size	292 mm
Control Type	Button
Special Features	Smart Inverter, Interior Lighting, Timer
Material	Glass (turntable)

8. Warranty and Support

LG products are manufactured to high quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official LG website for your region. Keep your purchase receipt as proof of purchase for warranty claims.

For technical assistance, service, or to order replacement parts, please contact LG Customer Support. You can find

contact details on the LG website or in your product documentation.
When contacting support, please have your model number (MS2535GIB) and serial number ready.

© 2023 LG Electronics. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question