MEILAN C2

MEILAN C2 Universal Bike Computer Mount Instruction Manual

Model: C2 | Brand: MEILAN

Introduction

This manual provides detailed instructions for the installation, use, and maintenance of your MEILAN C2 Universal Bike Computer Mount. Designed for durability and versatility, this mount securely holds your bike computer, GoPro camera, or bicycle front light on handlebars with a 31.8mm diameter.



Image: The MEILAN C2 Bike Computer Mount, showcasing its sleek black design and universal compatibility features.

Package Contents

Please verify that all items are present in your package:

- Bike Computer Mount (1)
- Allen Key (1)
- Silicone Pads (2) - 1.5mm and 4mm thick



Image: The MEILAN C2 Bike Computer Mount shown with its components: the main mount body, an Allen key for installation, and two sets of silicone pads for handlebar diameter adjustment.

Setup and Installation

Follow these steps to correctly install your MEILAN C2 mount:

1. **Prepare the Handlebar:** Ensure your handlebar is clean and free of debris. The mount is designed for 31.8mm handlebars. If your handlebar is smaller, use the provided silicone pads to achieve a snug fit. The pads protect the handlebar surface and prevent slippage.
2. **Position the Mount:** Place the mount on your handlebar in the desired out-front position. The mount should be centered and oriented for optimal viewing of your device.



Image: The MEILAN C2 mount securely attached to a bicycle handlebar, demonstrating its out-front positioning.

3. **Secure the Mount:** Use the provided Allen key to tighten the screw on the handlebar clamp. Tighten until the mount is firm and does not rotate, but avoid over-tightening to prevent damage to the handlebar or mount.
4. **Attach Your Device:**
    - *For Bike Computers:* Align your compatible bike computer with the mount's interface and twist it clockwise until it locks securely into place.
    - *For GoPro Cameras/Front Lights:* The underside of the mount features an integrated adapter for GoPro cameras and bicycle front lights. Attach your device using its standard mounting hardware.



Image: A bike computer mounted on the MEILAN C2, ready for use, illustrating the clear viewing angle.

Installation Video Guide

Your browser does not support the video tag.

Video: This video provides a general product overview of an out-front bike mount, demonstrating its features and potential applications. While not specific to the MEILAN C2, it illustrates the typical functionality and benefits of such mounts.

Your browser does not support the video tag.

Video: This video demonstrates the installation process for an out-front bike mount compatible with Garmin Edge devices, similar to the MEILAN C2. It shows how to attach the mount to the handlebar and secure a bike computer.

Key Features

- **Durable Engineering Plastic Material:** Constructed from high-quality engineering plastic for lightweight yet strong support and long-lasting durability.
- **Fits 31.8mm Handlebars:** Designed for handlebars with a 31.8mm diameter, including 1.5mm and 4mm thick silicone pads for a secure, scratch-free fit on various handlebar sizes.
- **Versatile Compatibility:** Compatible with bike computers, GoPro cameras, and bicycle front lights, offering broad utility for cyclists.
- **Enhanced Stability:** Engineered to keep devices securely in place, minimizing vibrations on rough terrain for a safer and more comfortable riding experience.
- **Tool-Free Installation:** Quick and easy attachment to handlebars without the need for additional tools.

Specifications

Feature	Detail

Brand	MEILAN
Model Name	C2
Material	Nylon (Engineering Plastic)
Color	Black
Mounting Type	Handlebar
Compatible Devices	Bike Computer, GoPro Camera, Bicycle Front Light
Item Dimensions (LxWxH)	5.11 x 1.5 x 1.57 inches
Package Weight	0.04 Kilograms

Maintenance

To ensure the longevity and optimal performance of your MEILAN C2 mount:

- Regularly inspect the mount for any signs of wear or damage.
- Clean the mount with a damp cloth and mild soap. Avoid harsh chemicals.
- Periodically check the tightness of the handlebar screw to ensure a secure fit.
- Store the mount in a cool, dry place when not in use.

Troubleshooting

If you encounter any issues with your MEILAN C2 mount, consider the following:

- **Mount Slippage:** Ensure the handlebar screw is adequately tightened. Verify that the correct silicone pads are used for your handlebar diameter to provide sufficient grip.
- **Device Instability:** Confirm that your bike computer or accessory is properly aligned and locked into the mount's interface. For GoPro or lights, ensure their mounting hardware is securely fastened to the integrated adapter.
- **Difficulty Attaching Device:** Check for any obstructions or misalignment. Ensure the device is compatible with the mount's interface.

Warranty and Support

The MEILAN C2 Bike Computer Mount comes with a manufacturer's warranty for 90 days from the date of purchase. For any questions, technical assistance, or warranty claims, please contact MEILAN customer support. MEILAN is committed to providing excellent after-sales service. For further assistance, please refer to the contact information provided with your product packaging or visit the official MEILAN website.

MEILAN

Image: The MEILAN brand logo, representing the manufacturer of the bike computer mount.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question