SLOTHMORE HYX6009

SLOTHMORE HYX6009 Vibration Back Massager for Chair with Heat User Manual

Model: HYX6009

Important Safeguards

Please read all instructions carefully before using this product. Failure to follow safety guidelines may result in injury or product damage.

- Use caution while using this massager; avoid lying down or sleeping with it.
- Do not use on bare skin.
- Keep away from water. This product is not water resistant.
- Consult a doctor before use if you have any health conditions.

Package Contents

Verify that all items are present in the package:

- SLOTHMORE Vibration Back Massage Cushion with Heat
- Wired Remote Control
- AC Adapter (for home/office use)
- DC Adapter (for car use)
- User Manual



Figure 1: Package contents including the massage cushion, adapters, and user manual.

Setup

1. **Unpack the Cushion:** Carefully remove the massage cushion from its packaging.
2. **Position the Cushion:** Place the massage cushion on your desired chair (office chair, sofa, car seat, etc.). Ensure the cushion is securely positioned against the backrest and seat.
3. **Secure the Cushion:** Use the integrated straps and plastic hook to firmly attach the cushion to your chair, preventing it from slipping during use.
4. **Connect Power:**
   - For home or office use, connect the AC adapter to the cushion's power input and then plug it into a standard wall outlet.
   - For car use, connect the DC adapter to the cushion's power input and then plug it into your vehicle's 12V power outlet.

5. **Place Remote Control:** Position the wired remote control within easy reach.

Your browser does not support the video tag.

Video: Demonstrates the unboxing and setup process of the SLOTHMORE massage cushion on a chair, including connecting the power adapters.



Figure 2: The massage cushion is designed to fit most chairs, providing versatility for use in different environments.

Operation

The wired remote control allows you to customize your massage experience:

- **Power On/Off:** Press the 'POWER' button to turn the massager on or off.
- **Massage Modes:** Select from 5 different massage programs using the 'PROGRAM' button.
- **Vibration Speed:** Adjust the vibration intensity to High, Middle, or Low using the 'SPEED' button.
- **Targeted Massage Zones:** Activate specific massage areas (Shoulder, Back, Waist, Hip and Thighs) using

the dedicated 'M1' to 'M4' buttons.

- **Heat Function:** Press the 'HEAT' button to activate the soothing heat therapy in the lumbar area. The heat function can be used independently or in conjunction with massage programs.
- **Auto-Off Timer:** The massager features a 20-minute auto-off function for safety and convenience.



Figure 3: Detailed view of the remote control for selecting massage modes, speeds, heat, and specific body zones.



Figure 4: Soothing heat therapy is concentrated in the waist and lower back to promote comfort.



Figure 5: Multi-zone vibration massage targets key areas for comprehensive relief.

Product Features

- **Multi-Zone Massage Experience:** Designed with multiple vibration zones across the back and seat area to create a full-coverage massage experience. Provides a noticeable and relaxing sensation during daily use.
- **Soothing Heat Along Back:** Built-in heat runs along the center back area, adding a warm and comforting feeling while you sit. Great for relaxing after long hours of work or rest.
- **Full Back & Seat Coverage:** Covers both upper and lower back as well as the seat area, delivering a more complete experience compared to basic cushions.
- **Adjustable Modes & Easy Control:** Multiple modes and intensity settings allow you to customize your experience. Simple controller makes it easy to switch between settings.

Maintenance & Storage

- Always disconnect the power adapter from the outlet and the cushion before cleaning.
- Wipe the cushion with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- Ensure the cushion is completely dry before storing or reusing.

- Store the massager in a cool, dry place, away from direct sunlight and moisture.
- Do not tug or pull the device by the wire cable.

Troubleshooting

If the product does not operate as expected, please check the following:

- Ensure the power adapter is securely connected to both the cushion and the power outlet.
- Verify that the power outlet is functional.
- Check if the auto-off timer has activated (20 minutes). If so, simply restart the device.
- If issues persist, please contact customer support for assistance.

Specifications

Model Number	HYX6009
Product Dimensions	44.7 x 1.8 x 17.8 inches
Item Weight	2.27 Pounds
Power Source	Corded Electric
Massager Form	Massage Seat Pad
Massage Therapy Technique	Vibration
Water Resistance Level	Not Water Resistant
Manufacturer	SLOTHMORE
UPC	605646777424, 605646776762, 605646776496, 605646776595, 605646776540, 605646777905, 605646779411, 605646779176



Figure 6: Product details including dimensions and key features.

Warranty and Support

The SLOTHMORE HYX6009 Vibration Back Massager comes with a 2-year warranty. For warranty claims or any product-related inquiries, please contact SLOTHMORE customer support via Amazon.

Additional protection plans (2-Year and 3-Year) may be available for purchase separately.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question