Silentnight 497596GE

Silentnight Double Air Bed Instruction Manual

Model: 497596GE

Important Safety Information

Please read all instructions carefully before using your Silentnight Double Air Bed. Failure to follow these instructions may result in injury or damage to the product.

- Do not overinflate the air bed. Overinflation can cause the seams to burst.
- Keep the air bed away from sharp objects, heat sources, and open flames.
- This air bed is not a flotation device and should not be used in water.
- Ensure children are supervised when near or on the air bed.
- Do not jump on the air bed.
- Avoid exposing the air bed to extreme temperatures.

Package Contents

Verify that all items are present in the package:

- 1 x Silentnight Double Air Bed (191 x 137 x 28 cm)
- Built-in Foot Pump
- Heavy Duty Repair Patch



Image: The Silentnight Double Air Bed, showing its overall design and flocked surface.

Setup

Inflation using the Built-in Foot Pump

1. Unroll the air bed completely and lay it flat on a clean, smooth surface, free from sharp objects.
2. Locate the built-in foot pump valve.
3. Open the valve cap.
4. Place your foot over the pump opening and press down firmly and repeatedly. Lift your foot slightly between presses to allow air to be drawn in. Continue this action until the air bed is fully inflated and firm to the touch.
5. Once inflated, quickly close the valve cap to prevent air from escaping.



Image: A foot pressing down on the built-in foot pump to inflate the air bed.

Inflation using an External Pump (Not Included)

For faster inflation, an external electric or manual pump (not included) can be used. Locate the larger inflation valve, open the cap, and insert the pump nozzle. Inflate until firm, then quickly seal the valve.

Operating

The Silentnight Double Air Bed is designed for comfortable indoor and outdoor use, providing a temporary sleeping solution.

- **Comfort Features:** The air bed features a soft-touch flocked outer surface for enhanced comfort and to help prevent sheets from slipping. It also includes a raised pillow section for improved head and neck support.
- **Weight Capacity:** The air bed has a maximum weight capacity of 300 kilograms. Do not exceed this limit.



Image: Close-up view of the raised pillow section of the air bed, designed for comfort.



Image: Detailed view of the soft flocked finish on the air bed's surface.

Deflation and Storage

1. Locate the interlocking quick-release valve.
2. Open the valve completely to allow air to escape rapidly. You can gently press on the air bed to assist deflation.
3. Once deflated, fold the air bed neatly into a compact size for easy transportation and storage.

Maintenance

Cleaning

To clean the air bed, wipe the surface with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners. Allow the air bed to dry completely before folding and storing. The manufacturer's care instructions state "Dry Clean Only", however, for an inflatable product, a gentle wipe-down is the practical and recommended cleaning method.

Repairing Punctures

If a small puncture occurs, use the provided heavy-duty repair patch. Clean and dry the area around the puncture. Apply the patch firmly over the hole, ensuring good adhesion. Allow sufficient time for the adhesive to set before reinflating.

Troubleshooting

- **Air Bed Deflates Quickly:**
  - Ensure the inflation valve cap is securely closed.
  - Check for punctures or leaks. Use soapy water to locate small leaks (bubbles will form). Repair with the provided patch.
  - Verify that the air bed is not overinflated, which can stress seams.
- **Foot Pump is Slow/Ineffective:**
  - Ensure the foot pump valve is fully open and clear of obstructions.
  - Make sure your foot completely covers the pump opening during the downward press and lifts slightly to allow air intake.
  - For faster inflation, consider using an external electric or manual pump (not included).
- **Air Bed is Not Firm Enough:**
  - Continue pumping until the desired firmness is achieved.
  - Ensure the valve is sealed immediately after inflation.

Specifications

Feature	Detail
Model Name	Silentnight Double Air Bed
Model Number	497596GE
Dimensions (L x W x H)	191 x 137 x 28 cm
Weight	3.61 kg
Material	Polyester (Flocked)
Maximum Capacity	300 Kilograms
Included Components	Air bed, Built-in foot pump, Repair patch



Image: The Silentnight Double Air Bed with its length, width, and height dimensions indicated.

Warranty and Support

Silentnight products are manufactured to high standards and come with a manufacturer's warranty. For specific warranty details, claims, or further support, please refer to the documentation included with your purchase or visit the official Silentnight website. You can also visit the Silentnight Store on Amazon for more information and product range.

© 2025 Silentnight. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question