Hamzer KEY-UNIT-213X-BLK

Hamzer 61-Key Electronic Keyboard Instruction Manual

Model: KEY-UNIT-213X-BLK

Brand: Hamzer

Introduction

Welcome to your new Hamzer 61-Key Electronic Keyboard. This manual provides essential information for setting up, operating, and maintaining your digital piano. Please read it thoroughly to ensure optimal performance and longevity of your instrument.



The Hamzer 61-Key Electronic Keyboard with H-Stand, Stool, Headphones, and Microphone.

Safety Information

Please read all safety instructions before using the product to prevent damage or injury.

- Keep away from water and moisture. Do not operate in wet environments.
- Do not disassemble or attempt to repair the unit yourself. Refer all servicing to qualified personnel.
- Use only the provided power adapter or specified batteries (6 AA batteries, not included).
- Avoid exposing the instrument to extreme temperatures, direct sunlight, or heat sources.
- Ensure proper ventilation around the keyboard to prevent overheating.

Package Contents

Verify that all items are present in the package:

- 61-Key Electronic Keyboard
- H-Style Keyboard Stand
- Padded Piano Stool
- Headphones
- Microphone with 4' cord
- Transparent Key Stickers
- Power Adapter (US-standard DC 9V/AC)



All components included in the Hamzer 61-Key Electronic Keyboard package: keyboard, H-stand, stool, headphones, microphone, and key stickers.

Setup Guide

1. Assembling the H-Style Keyboard Stand

The H-style stand is designed for stability and adjustable height.

1. Unfold the stand components.
2. Secure the horizontal bar between the two vertical supports.
3. Adjust the height to one of the three positions: 22", 24-1/2", or 27". Ensure the locking pins are fully engaged for stability.



The H-Style Keyboard Stand, showing its sturdy metal construction and three adjustable height positions.

2. Assembling the Piano Stool

The stool is foldable and adjustable for comfortable seating.

1. Unfold the stool legs until they lock into place.
2. Adjust the height to 19", 20-1/2", or 21-1/2" as desired by securing the locking mechanism.



The cushioned piano bench, highlighting its foldable design and adjustable height.

3. Placing the Keyboard

Carefully place the 61-key electronic keyboard onto the assembled H-stand. Ensure it is centered and stable before use.

4. Power Connection

The keyboard can be powered by the included DC 9V/AC adapter or 6 AA batteries (not included).

- **For adapter use:** Plug the adapter into the DC 9V input jack on the keyboard and then into a standard wall outlet.
- **For battery use:** Open the battery compartment on the underside of the keyboard and insert 6 AA batteries, observing correct polarity.

5. Connecting Accessories

- **Headphones:** Plug the headphones into the 3.5mm headphone jack for private practice.
- **Microphone:** Plug the microphone into the microphone input jack to use the sing-along feature.
- **USB:** Connect a USB drive to the USB jack for MP3 audio playback.



The included microphone and headphones, ready for connection to the keyboard.

6. Applying Key Stickers (Optional)

For beginners, transparent key stickers are provided to label the piano keys, simplifying the learning process.

1. Carefully peel each sticker from the sheet.
2. Align and apply the stickers to the corresponding white keys as indicated on the sticker sheet.



Close-up view of the keyboard keys with optional transparent stickers applied for learning.

Operating Instructions

Power On/Off

Press the **POWER** button located on the control panel to turn the keyboard on or off.

Volume Control

Use the **Master Volume** knob to adjust the overall sound output level of the keyboard.

Timbres (Voices)

The keyboard features 300 Timbres (instrument voices). Use the number pad or dedicated buttons to select different instrument sounds. Refer to the keyboard's printed list on the control panel for timbre numbers.



The keyboard's control panel, highlighting the display and buttons for selecting from 300 different tones and 128 rhythms.

Rhythms

Select from 128 rhythms to add a backing track to your playing. Use the rhythm selection buttons or number pad to choose a rhythm.
Use **Rhythm Sync** and **Fill-in** buttons for dynamic rhythm control during playback.

Demonstration Songs

The keyboard includes 15 demonstration songs. Press **Demo All** to play all songs consecutively or **Demo One** to play a single song.

Learning Modes

The integrated learning system assists beginners with two modes:

- **One Key Teaching:** Learn songs by pressing any key to advance the melody.

- **Follow Teaching:** The keyboard waits for you to play the correct note before proceeding, guiding you through the song.

Recording and Playback

Record your performances for review and improvement:

1. Press the **Record** button to start recording.
2. Play your desired melody.
3. Press **Play** to listen to your recorded performance.

Effects

Enhance your sound with various effects:

- **Vibrato:** Adds a slight pitch variation to the notes.
- **Sustain:** Lengthens the decay of notes, allowing them to ring out longer.
- **Ensemble:** Creates a fuller, richer sound by layering multiple voices.

Chords

Utilize single-fingered and fingered auto-bass chords for automatic accompaniment. Use the**Chord Timbre** button to select the desired chord sound.

Maintenance

Cleaning

Wipe the keyboard and accessories with a soft, dry cloth. Do not use abrasive cleaners, solvents, or chemical sprays, as these can damage the surface and internal components.

Storage

Store the keyboard in a cool, dry place away from direct sunlight, high humidity, and extreme temperatures. If storing for an extended period, remove batteries to prevent leakage and potential damage to the electronic components.

Troubleshooting

No Sound

- Check if the power is on.
- Ensure the Master Volume knob is turned up.
- If headphones are plugged in, unplug them to hear sound from the built-in speakers.
- Verify the power adapter connection or ensure batteries are correctly installed and not depleted.

Keys Not Responding

- Ensure the keyboard is powered on.
- Check for any foreign objects lodged between the keys that might be preventing them from moving freely.

Distorted Sound

- Lower the Master Volume.
- Check for loose connections if using external speakers or headphones.

Product Specifications

Feature	Detail
Model Name	KEY-UNIT-213X-BLK
Number of Keys	61
Timbres (Voices)	300
Rhythms	128
Demonstration Songs	15
Power Source	Corded Electric, 6 AA Batteries (not included)
Product Dimensions	33.25"D x 12.75"W x 4"H
Item Weight	11 Pounds
Headphone Jack	3.5mm Jack
Connectivity	Auxiliary, USB
Stand Height Adjustment	22", 24-1/2", 27"
Stool Height Adjustment	19", 20-1/2", 21-1/2"

Warranty and Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Hamzer website. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question