Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit DX-RC01A-13

ZdalaMit DX-RC01A-13 Replacement Remote Control User Manual

For Dynex LCD TV Models DX-32L200NA14

1. Introduction

This manual provides instructions for the ZdalaMit DX-RC01A-13 replacement remote control. This remote is designed to be compatible with Dynex LCD TV models, specifically DX-32L200NA14. It functions as a direct replacement, requiring no programming or pairing.

2. Setup

2.1 Battery Installation

The remote control requires two (2) 1.5V AA alkaline batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Battery Compartment

Note: No programming or pairing is required. Once batteries are installed, the remote is ready for use with compatible Dynex LCD TVs.

3. Operating Instructions

This remote control provides full functionality for your compatible Dynex LCD TV. Below are the primary functions of the buttons:



Figure 2: Remote Control Layout

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **0-9 (Number Buttons):** Directly select TV channels.
- **RECALL:** Switches between the current and previously viewed channel.
- **PICTURE:** Adjusts picture settings.
- **AUDIO:** Adjusts audio settings.
- **MTS/SAP:** Selects Multi-channel Television Sound/Secondary Audio Program.
- **SLEEP:** Sets the TV sleep timer.
- **INPUT:** Selects the input source (e.g., HDMI, AV).
- **VOL +/-:** Increases or decreases the volume.
- **CH +/-:** Changes the TV channel up or down.
- **INFO:** Displays on-screen information about the current program.
- **CCD:** Activates or deactivates Closed Captioning.
- **CH-LIST:** Displays the channel list.
- **FAV:** Accesses favorite channels.
- **ZOOM:** Adjusts the screen zoom level.
- **MENU:** Opens the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **ENTER:** Confirms selections in menus.
- **EXIT:** Exits the current menu or on-screen display.

Ensure a clear line of sight between the remote control and the TV's infrared sensor for optimal performance.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are installed correctly with the correct polarity (+/-).
  - Replace the batteries with fresh 1.5V AA alkaline batteries.
  - Ensure there is a clear line of sight between the remote control and the TV's infrared sensor. Remove any obstructions.
  - Confirm the remote is pointed directly at the TV's sensor.
- **Specific buttons not working:**

- This may indicate a faulty button or low battery power. Try replacing the batteries.
- Ensure the remote is clean and free from debris that might obstruct button presses.

- **TV not compatible:**
  - This remote is specifically designed for Dynex LCD TV models DX-32L200NA14. Verify your TV model number.

6. Specifications

Feature	Detail
Model	DX-RC01A-13
Brand	ZdalaMit
Compatibility	Dynex LCD TV DX-32L200NA14
Power Supply	2 x 1.5V AA Alkaline Batteries
Connectivity Technology	Infrared (IR)
Product Dimensions	6.8 x 1.8 x 0.6 inches (approx.)
Item Weight	1.41 ounces (approx.)
Special Feature	Ergonomic design

7. Warranty and Support

Specific warranty information for this replacement remote control is not provided in the product details. For any warranty claims, technical support, or further assistance, please contact the seller or manufacturer directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QL1K46L

More documents and user manuals: **https://manuals.plus/**