Klipsch 1067557

Klipsch Heritage Wireless The Three II Tabletop Stereo User Manual

Model: 1067557 | Brand: Klipsch

Introduction

The Klipsch Heritage Wireless The Three II is a high-quality tabletop stereo designed to deliver exceptional audio performance with a classic aesthetic. This manual provides comprehensive instructions for setting up, operating, and maintaining your device, ensuring optimal performance and longevity.
It offers versatile connectivity options, allowing you to enjoy audio from various sources, including Bluetooth-enabled devices, turntables, computers, and CD players.

What's in the Box

Upon unboxing, please verify that all components are present:

- Klipsch The Three II Speaker
- Power Cord
- Remote Control
- User Manual (this document)

If any items are missing or damaged, please contact Klipsch customer support.

Product Overview

Familiarize yourself with the main components of your Klipsch The Three II speaker.



Figure 1: Front view of the Klipsch The Three II Tabletop Stereo in Matte Black. This image displays the speaker's classic design with its woven grille and top-mounted controls.



Figure 2: Side view of the Klipsch The Three II Tabletop Stereo, highlighting the matte black finish and the detailed grille texture.





Figure 3: The remote control for the Klipsch The Three II, showing buttons for power, volume, mute, playback control, and input selection (Bluetooth, AUX, USB, Phono, LED).

Controls and Indicators:

- **Power/Input Knob:** Located on the top panel, this knob controls power on/off and input selection.
- **Volume Knob:** Adjusts the master volume level.
- **LED Indicator:** Provides status feedback (e.g., pairing mode, active input).
- **Remote Control:** Full functionality for power, volume, input selection, and playback.

Rear Panel Connections:

- **Power Input:** For connecting the included power cord.
- **Auxiliary Input (3.5mm):** For connecting devices with a 3.5mm audio output.
- **Phono Input (RCA):** For connecting a turntable with a built-in pre-amplifier or an external phono pre-amplifier.
- **USB Type-B Input:** For connecting to a computer for high-resolution audio playback.

Setup

1. Placement:

Place the Klipsch The Three II on a stable, flat surface. For optimal sound dispersion, position it in a central location within the room, away from corners or walls that might cause excessive bass resonance. Ensure adequate ventilation around the unit.

2. Power Connection:

1. Connect the included power cord to the Power Input on the rear of the speaker.
2. Plug the other end of the power cord into a wall outlet.
3. The LED indicator on the top panel will illuminate, indicating the unit is in standby mode.

Operating Instructions

Power On/Off:

Rotate the Power/Input knob clockwise to turn the unit on. Rotate counter-clockwise to turn off. Alternatively, use the power button on the remote control.

Volume Adjustment:

Adjust the volume using the dedicated Volume knob on the top panel or the VOL+ / VOL- buttons on the remote control.

Input Selection:

Rotate the Power/Input knob to cycle through available inputs (Bluetooth, AUX, Phono, USB). The LED indicator will change color or pattern to indicate the active input. You can also select inputs directly using the corresponding buttons on the remote control.

Bluetooth Pairing:

1. Turn on the Klipsch The Three II.
2. Select the Bluetooth input using the Power/Input knob or the Bluetooth button on the remote. The LED indicator will begin flashing, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings and search for "Klipsch The Three II".
4. Select the speaker from the list of available devices to pair.
5. Once paired, the LED indicator will glow solid, and you can begin streaming audio.

Auxiliary Input (3.5mm):

Connect an audio device (e.g., CD player, MP3 player) to the 3.5mm AUX input on the rear panel using a 3.5mm audio cable. Select the AUX input on the speaker.

Phono Input (RCA):

Connect your turntable's RCA output cables to the PHONO input on the rear panel. Ensure your turntable has a built-in phono pre-amplifier or use an external one. Select the PHONO input on the speaker.

USB Audio:

Connect a computer to the USB Type-B input on the rear panel using a USB A-to-B cable. Select the USB input on the speaker. Your computer should recognize the speaker as an audio output device.

Remote Control Usage:

The remote control provides convenient access to all primary functions. Ensure the remote has 2 AAA batteries installed (not included with all models, check packaging). Point the remote towards the front of the speaker for best operation.

- **Power Button:** Turns the speaker on or off.
- **Mute Button:** Mutes or unmutes the audio.
- **Volume Up/Down:** Adjusts the volume level.
- **Playback Controls (Play/Pause, Skip Forward/Backward):** Controls media playback when using Bluetooth or USB audio.
- **Input Buttons (Bluetooth, AUX, USB, Phono):**Directly selects the desired audio input.
- **LED Button:** Controls the LED indicator light.

Maintenance

To ensure the longevity and optimal performance of your Klipsch The Three II, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior surfaces. Avoid abrasive cleaners, solvents, or sprays that may damage the finish.
- **Dust:** Regularly dust the speaker grille and vents to prevent accumulation, which can affect sound quality and internal components.
- **Ventilation:** Ensure the speaker has adequate airflow around it. Do not block ventilation openings.
- **Storage:** If storing the speaker for an extended period, disconnect it from power and store it in a cool, dry place, preferably in its original packaging.
- **Avoid Liquids:** Keep the speaker away from water or excessive moisture.

Troubleshooting

If you encounter issues with your Klipsch The Three II, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No Power	Power cord not connected; Outlet not active.	Ensure power cord is securely plugged into the speaker and a working wall outlet. Test the outlet with another device.

Problem	Possible Cause	Solution
No Sound	Incorrect input selected; Volume too low; Muted; Source device issue.	Verify the correct input is selected. Increase speaker and source device volume. Check if the speaker is muted (remote control). Ensure the source device is playing audio.
Bluetooth Disconnection/Cannot Pair	Device too far; Interference; Speaker not in pairing mode; Previous pairing conflict.	Move device closer to the speaker (within 10 meters). Ensure no strong interference sources. Put speaker into pairing mode. Forget "Klipsch The Three II" on your device's Bluetooth settings and re-pair.
Distorted Sound	Volume too high; Poor audio source quality; Cable issue.	Reduce volume on both speaker and source device. Try a different audio source. Check audio cables for damage or loose connections.
Remote Control Not Working	Dead batteries; Obstruction; Not pointed correctly.	Replace AAA batteries. Remove any obstructions between remote and speaker. Ensure remote is pointed towards the front of the speaker.

If the problem persists after trying these solutions, please contact Klipsch customer support.

Specifications

Detailed technical specifications for the Klipsch Heritage Wireless The Three II Tabletop Stereo:

- **Model Name:** The Three II
- **Speaker Type:** Wireless
- **Connectivity Technology:** Wireless (Bluetooth)
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Range:** 10 Meters
- **Audio Output Mode:** Stereo
- **Surround Sound Channel Configuration:** 2.0
- **Speaker Maximum Output Power:** 25 Watts
- **Audio Driver Type:** Hybrid Driver
- **Compatible Devices:** Personal Computer, Phones, Smartphone, Tablet
- **Recommended Uses For Product:** Indoor
- **Control Method:** App, Remote
- **Power Source:** Battery Powered *(Note: This typically refers to the remote control or internal settings battery; the main unit is AC powered via the included power cord.)*
- **Product Dimensions (D x W x H):** 7"D x 13.71"W x 7.99"H
- **Item Weight:** 12.62 pounds
- **Color:** Matte Black
- **Included Components:** Remote, Speaker, manual, power cord
- **Manufacturer:** Klipsch
- **Item Model Number:** 1067557
- **UPC:** 743878039665
- **Batteries:** 2 AAA batteries required (for remote)
- **Date First Available:** April 19, 2019

Warranty Information

Klipsch products are designed and manufactured to the highest quality standards. This product is covered by a Limited Warranty. For specific warranty terms and conditions, including duration and coverage details, please refer to the warranty card included with your product or visit the official Klipsch website. Keep your purchase receipt as proof of purchase for warranty claims.

Support

For further assistance, technical support, or service inquiries, please contact Klipsch customer support through the following channels:

- **Klipsch Official Website:** www.klipsch.com/support (for FAQs, product registration, and contact information)
- **Online Support:** Refer to the support section on the Klipsch website for online chat or email options.
- **Telephone Support:** Check the Klipsch website for regional contact numbers.

When contacting support, please have your product model number (1067557) and serial number ready.

© 2024 Klipsch. All rights reserved. Klipsch and The Three are trademarks of Klipsch Group, Inc.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question