Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UpStart Components AP-297147700-DL3656

UpStart Components 297147700 Freezer Door Key Replacement Manual

Model: AP-297147700-DL3656 | **Brand:** UpStart Components

Introduction

This instruction manual provides essential information for the proper installation, operation, and maintenance of your UpStart Components 297147700 Freezer Door Key. This key is designed as a compatible replacement for the 297147700 lock key used with Frigidaire WFC15M3AW0 freezers. Please read this manual thoroughly before use to ensure correct application and to maximize the lifespan of your product.

Product Overview

The UpStart Components 297147700 Freezer Door Key is a durable, high-quality plastic replacement part. It is designed to fit and operate the locking mechanism on compatible freezer models, providing security for your freezer contents.



Image 1: The UpStart Components 297147700 Freezer Door Key, shown in its retail packaging.



Image 2: A close-up view of the freezer door key, highlighting its design and material.

Setup and Installation

This replacement key features an easy, tool-free installation process. No special tools or technical expertise are required.

1. **Identify the Lock:** Locate the keyhole on your Frigidaire WFC15M3AW0 freezer door.
2. **Insert the Key:** Gently insert the tip of the 297147700 replacement key into the keyhole. Ensure it is fully seated.
3. **Test Operation:** Turn the key clockwise to lock the door and counter-clockwise to unlock it. The key should turn smoothly without excessive force.



Image 3: Side profile of the key, showing the shape designed for insertion into the lock mechanism.

Operating Instructions

To operate the freezer door lock using your UpStart Components replacement key:

- **To Lock:** Insert the key into the keyhole and turn it clockwise until the door is securely locked. Remove the key.
- **To Unlock:** Insert the key into the keyhole and turn it counter-clockwise until the door is unlocked. Remove the key.

Always remove the key after locking or unlocking to prevent it from being lost or damaged.

Maintenance

Proper care will ensure the longevity of your replacement key:

- **Cleaning:** Wipe the key with a soft, dry cloth if it becomes dirty. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the key in a safe, easily accessible location when not in use, away from extreme temperatures or direct sunlight.
- **Handling:** Avoid applying excessive force when turning the key, as this can damage both the key and the freezer's lock mechanism.

Troubleshooting

If you encounter issues with your freezer door key, consider the following:

- **Key Does Not Turn:** Ensure the key is fully inserted into the keyhole. Check for any obstructions within the keyhole. Do not force the key.
- **Door Remains Unlocked/Locked:** Verify that the key is turned completely in the desired direction. If the issue persists, the freezer's internal lock mechanism may require inspection by a qualified technician.
- **Key Feels Loose:** This may indicate wear on the key or the lock. If the key is new, ensure it is the correct replacement part for your specific freezer model.
- **Key is Damaged:** If the key is bent, broken, or shows significant wear, it should be replaced to prevent damage to the freezer lock.

Specifications

Attribute	Detail
Product Type	Freezer Door Key Replacement
Brand	UpStart Components
Compatible Part Number	297147700
Compatible Freezer Model	Frigidaire WFC15M3AW0
Material	High-quality Plastic
Manufacturer Part Number	AP-297147700-DL3656

ASIN	B07QZ6B224
Date First Available	April 18, 2019
Additional Compatible Part Numbers	AP4301346, 216702900, 06599905, 08037402, 1259502, 216388700, 5308027402, 5308037402, 6599905, AH1991481, C000460771, EA1991481, F000113978, F000115646, F113978, F115646, G157033, K1235141, K1244302, PS1991481, WR05X0065, WR05X0072, WR05X5010, WR05X5029, WR05X5036, WR05X5050, WR5X5010, WR5X5029, WR5X5036, WR5X5050, WR5X65, WR5X72

Warranty and Support

This product is a replacement part manufactured by UpStart Components. Any warranties for this product are offered solely by UpStart Components and are not affiliated with the original equipment manufacturer (OEM). For warranty claims, technical assistance, or product support, please contact UpStart Components directly through their official customer service channels.
Please note that this product is not covered under any warranties offered by the original manufacturers of the appliance it is compatible with.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07QZ6B224

More documents and user manuals: **https://manuals.plus/**