AICOOK B07R6RQ26J

AICOOK 3-in-1 Espresso and Coffee Maker Instruction Manual

1. Introduction

Thank you for purchasing the AICOOK 3-in-1 Espresso and Coffee Maker. This appliance is designed to provide you with a versatile coffee experience, allowing you to prepare espresso, drip coffee, and frothed milk for cappuccinos and lattes. Please read this instruction manual carefully before operating the machine to ensure safe and optimal performance. Keep this manual for future reference.

Important Safety Instructions

- Read all instructions before use.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Close supervision is necessary when the appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only accessories recommended by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use the appliance for other than intended use.

2. Product Overview and Components

Familiarize yourself with the various parts of your AICOOK 3-in-1 Espresso and Coffee Maker before initial use.



Image: Numbered diagram illustrating the components of the AICOOK 3-in-1 Espresso and Coffee Maker.

1. **Drip Coffee Button:** Initiates the drip coffee brewing process.
2. **Espresso Button:** Activates the espresso brewing function.
3. **Steam:** Button to activate the steam function for frothing milk.
4. **One Cup:** Button for brewing a single cup of espresso.
5. **Two Cups:** Button for brewing two cups of espresso simultaneously.
6. **Manual Operation:** Button for manual control of brewing.
7. **Steam Tube Assembly Parts:** Components of the steam wand.
8. **Steam Tube Sheath:** Protective covering for the steam tube.
9. **Steam Knob:** Controls the steam output.

10. **LED Display:** Shows operational status and settings.

3. Setup

Initial Cleaning

1. Remove all packaging materials and labels.
2. Wash the removable parts (water tank, filter, funnel, drip tray, cup plate) with warm, soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the machine with a damp cloth.

Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the tank with fresh, cold water up to the 'MAX' level indicated. Do not exceed the 'MAX' line.
3. Place the water tank back into its position, ensuring it is securely seated.

First Use (Priming the Machine)

1. Ensure the water tank is filled.
2. Place a large cup or container under the coffee outlet.
3. Plug the machine into a grounded electrical outlet.
4. Press the power button to turn on the machine.
5. Press the 'One Cup' or 'Two Cups' button to run water through the system without coffee. This primes the pump and cleans the internal components. Repeat this process 2-3 times.

4. Operation

Making Drip Coffee



Image: Visual guide demonstrating the steps for preparing drip coffee, espresso, and cappuccino.

1. **Pour Water:** Ensure the water tank is filled with fresh water.
2. **Add Coffee Powder:** Open the top lid for drip coffee and add your desired amount of ground coffee into the reusable filter.
3. **Press the On/Off Key:** Close the lid and press the Drip Coffee Button (1) to start brewing.
4. **Delicious Drip Coffee:** The machine will brew and dispense drip coffee into your carafe or cup.

Making Espresso

1. **Pour Water:** Ensure the water tank is filled with fresh water.
2. **Add Coffee Powder:** Place the appropriate filter basket into the portafilter. Add finely ground espresso coffee into the filter basket. Tamp the coffee evenly.
3. **Attach Portafilter:** Attach the portafilter to the group head by aligning it and twisting it firmly to the right.
4. **Press the One/Two Cups Key:** Place your espresso cup(s) under the portafilter spouts. Press the 'One Cup' (4) or 'Two Cups' (5) button to start brewing.
5. **Rich Espresso:** The machine will extract espresso. Press the button again to stop brewing if you prefer a manual stop.

Making Cappuccino (Frothing Milk)

1. **Prepare Milk:** Fill a stainless steel frothing pitcher with cold milk (dairy or non-dairy) to just below the spout.
2. **Activate Steam:** Press the 'Steam' button (3). Wait for the machine to heat up to steaming temperature (indicated by the LED display).
3. **Rotary Steam Switch:** Position the steam wand into the milk, just below the surface. Turn the 'Steam Knob' (9) to release steam.

4. **Make Milk Foam:** Move the pitcher up and down to create foam. Once desired foam and temperature are reached, turn off the steam knob and remove the pitcher.
5. **A Fragrant Cappuccino:** Combine the frothed milk with your freshly brewed espresso.
6. **Clean Steam Wand:** Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying. Briefly purge steam to clear any internal blockages.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker.



Image: Illustration of the removable parts of the AICOOK 3-in-1 Espresso and Coffee Maker, highlighting components that are easy to clean.

Daily Cleaning

- **Drip Tray:** Empty and clean the removable drip tray (7) after each use.
- **Water Tank:** Empty any remaining water from the removable tank (9) and rinse it. Refill with fresh water for the next use.
- **Portafilter and Filter Baskets:** Remove spent coffee grounds and rinse the portafilter and filter baskets (2, 4, 5) under warm water.
- **Steam Wand:** As mentioned in the operation section, wipe and purge the steam wand immediately after frothing milk.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth.

Descaling

Over time, mineral deposits (limescale) can build up in the machine, affecting performance. Descale your machine every 2-3 months, or more frequently if you have hard water.

1. Prepare a descaling solution according to the descaler manufacturer's instructions, or use a mixture of white vinegar and water (1:1 ratio).
2. Fill the water tank with the descaling solution.
3. Place a large container under the coffee outlet and steam wand.
4. Run the machine through several brewing cycles (without coffee) until half of the solution has passed through.
5. Run steam through the steam wand for about 30 seconds.
6. Turn off the machine and let it sit for 15-20 minutes.
7. Turn the machine back on and run the remaining solution through the brewing cycle and steam wand.
8. Empty the water tank and rinse it thoroughly.
9. Fill the tank with fresh water and run several full tanks of clean water through the machine to rinse out any descaling solution residue.

6. Troubleshooting

If you encounter issues with your AICOOK coffee maker, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on	Not plugged in; Power outlet malfunction	Ensure plug is securely inserted; Test outlet with another appliance.
No coffee dispenses	Water tank empty; Clogged filter; Machine not primed	Fill water tank; Clean filter; Prime the machine as per 'First Use' instructions.
Coffee is too weak	Insufficient coffee grounds; Coarse grind; Too much water	Increase coffee amount; Use finer grind; Adjust water volume.
Steam wand not producing steam	Steam button not activated; Clogged wand; Not heated sufficiently	Press steam button and wait for heating; Clean steam wand; Allow machine to reach full steam temperature.

Problem	Possible Cause	Solution
Water leaking from machine	Water tank not seated correctly; Drip tray full; Loose portafilter	Ensure water tank is firmly in place; Empty drip tray; Securely attach portafilter.

7. Specifications

- **Brand:** AICOOK
- **Model:** B07R6RQ26J
- **Capacity:** 1.2 Liters (Water Tank)
- **Pressure:** 15 Bar (Espresso Pump)
- **Functions:** Espresso, Drip Coffee, Steam (for frothing milk)
- **First Available Date:** April 29, 2019

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact AICOOK customer service through the retailer where the product was purchased. Please have your model number (B07R6RQ26J) and purchase date available when contacting support.

© 2023 AICOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question